



U.S. Department of Transportation  
Federal Aviation Administration  
Washington, D.C.

---

# Master Minimum Equipment List (MMEL)

---

Revision: 16a  
Date: 03/26/2015

## **Airbus** **A330-200, A330-200F, A330-300**

James P. Culet, Chair  
Flight Operations Evaluation Board (FOEB)

Federal Aviation Administration  
Seattle Aircraft Evaluation Group  
1601 Lind Ave. S.W.  
Renton, WA 98057-3356

Telephone: (425) 917-6600  
FAX: (425) 917-6638

## MASTER MINIMUM EQUIPMENT LIST

Revision: 16a

Date: 03/26/2015

A330-200, A330-200F, A330-300

SYSTEM	PAGES	REVISION	DATE
-- Cover Page	I	16a	03/26/2015
-- Table of Contents	II	16a	03/26/2015
-- Highlights of Change	III	16a	03/26/2015
-- Definitions	IV	16a	03/26/2015
-- Preamble	V	16a	03/26/2015
21 Air Conditioning	21-1, THRU 25	16a	03/26/2015
22 Auto Flight	22-1, THRU 10	13	06/11/2012
23 Communications	23-1, THRU 26	14	05/31/2013
24 Electrical Power	24-1, THRU 8	16	07/01/2014
25 Equipment/Furnishings	25-1, THRU 23	16	07/01/2014
26 Fire Protection	26-1, THRU 16	14	05/31/2013
27 Flight Controls	27-1, THRU 19	14	05/31/2013
28 Fuel	28-1, THRU 26	16a	03/26/2015
29 Hydraulic Power	29-1, thru 5	15	04/07/2014
30 Ice and Rain Protection	30-1, THRU 13	13	06/11/2012
31 Indicating/Recording Systems	31-1, THRU 7	14	05/31/2013
32 Landing Gear	32-1, THRU 9	13	06/11/2012
33 Lights	33-1, THRU 17	14	05/31/2013
34 Navigation	34-1, THRU 15	14	05/31/2013
35 Oxygen	35-1, THRU 9	14	05/31/2013
36 Pneumatic	36-1, THRU 6	13	06/11/2012
38 Water/Waste	38-1, 2	9	09/26/2007
45 Central Maintenance Computer	45-1, 2	13	06/11/2012
46 Information Systems	46-1, 2	12a	06/18/2010
47 Inert Gas System	47-1	12b	03/07/2011
49 Airborne Auxiliary Power	49-1, 2	13	06/11/2012
52 Doors	52-1, THRU 18	14	05/31/2013
56 Windows	56-1	12	12/14/2009
73 Engine Fuel & Control	73-1, THRU 6	16a	03/26/2015
74 Ignition	74-1, 2	13	06/11/2012
75 Bleed Air	75-1, 2	13	06/11/2013
77 Engine Indicating	77-1	13	06/11/2012
78 Engine Exhaust	78-1, THRU 5	13	06/11/2012
79 Engine Oil	79-1, THRU 5	14	05/31/2013
80 Starting	80-1	9	09/26/2007

A330-200, A330-200F, A330-300

## Highlights of Change

EFFECTIVE ABOVE DATE, the A330 Master Minimum Equipment List has been revised. Please replace affected pages with Revision 16a for a complete up-to-date MMEL. All changes are reflected in the Highlights of Change listed below and are indicated by revision bars in the associated ATA chapter. The main change is for the introduction of the A330-300 configured with center fuel tank. For any change affecting an ATA chapter, all pages in that associated ATA chapter are re-dated accordingly.

ATA 21 AIR CONDITIONING

Item: 28-04 Clarified (O) procedure to include AFT cargo compartment.

ATA 28 FUEL

Item: 12-01 Adds new relief for A330-300 configured with center fuel tank.  
Item: 23-01 Adds new relief for A330-300 configured with center fuel tank.  
Item: 25-03 Adds new relief for A330-300 configured with center fuel tank.  
Item: 25-04 Added new relief for A330-300 configured with center fuel tank.  
Item: 26-02 Adds new relief for A330-300 configured with center fuel tank.  
Item: 27-03 Adds new relief for A330-300 configured with center fuel tank.  
Item: 27-04 Adds new relief for A330-300 configured with center fuel tank.  
Item: 27-06 Adds new relief for A330-300 configured with center fuel tank.  
Item: 40-02 Adds new relief for A330-300 configured with center fuel tank.  
Item: 40-04 Adds new relief for A330-300 configured with center fuel tank.  
Item: 40-15 Adds new relief for A330-300 configured with center fuel tank.  
Item: 42-01 Adds new relief for A330-300 configured with center fuel tank.  
Item: 46-02 Adds new relief for A330-300 configured with center fuel tank.  
Item: 51-01 Adds new relief for A330-300 configured with center fuel tank.

ATA 73 ENGINE FUEL & CONTROL

Item: 30-01 Adds new relief for A330-300 configured with center fuel tank.

A330-200, A330-200F, A330-300

#### Definitions

For the Master Minimum Equipment List, Definitions addendum, refer to the current FAA MMEL Policy Letter PL-25, *Policy Concerning MMEL Definitions*, as found on the Flight Standards Information Management System (FSIMS) website. <http://fsims.avs.faa.gov/>

FSIMS - Publications - MMEL Policy Letters

A330-200, A330-200F, A330-300

Preamble

For the Master Minimum Equipment List, Preamble addendum as used for operations under 14 CFR Parts 121, 125, 129, and 135, refer to the current FAA Policy Letter PL-34, *MMEL and MEL Preamble*, as found on the Flight Standards Information Management System (FSIMS) website.  
<http://fsims.avs.faa.gov/>

FSIMS - Publications - MMEL Policy Letters

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 16a

PAGE:

DATE: 03/26/2015

21-1

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
21 AIR CONDITIONING					
21-01 Cabin Fans (Recirculation Fans)					
1)	A330-200, A330-300	C	2	1	(O)One may be inoperative provided: a) Both air conditioning packs operate normally, and b) HI Flow is selected.
2)	A330-200F	D	2	1	(O)One may be inoperative provided both air conditioning packs operate normally.
		C	2	0	(O)Both may be inoperative provided: a) Both air conditioning packs operate normally, and b) HI Flow is selected.
21-02 Recirculation Valves (A330-200, A330-300)					
		C	2	0	(O)May be inoperative provided alternate procedures are established and used.
21-03 CAB FANS Pb Sw					
1)	OFF Light	C	1	0	
21-04 Lower Deck Cabin *** Crew Rest Compartment Ventilation (A330-200, A330-300)					
1)	Low Flow Buzzer	C	1	0	(M)May be inoperative provided: a) The isolation valve is closed, and b) The lower deck cabin crew rest compartment is locked closed and not used.
21-05 Indications on ECAM COND Page					
1)	Cabin FAN	C	2	0	(O)May be inoperative provided a procedure is used to periodically check that the operative LEAVE MCR sign or the low flow lamp are not illuminated when the lower deck cabin crew rest compartment is used.

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 16a

PAGE:

DATE: 03/26/2015

21-2

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3.	NUMBER REQUIRED FOR DISPATCH	
21 AIR CONDITIONING					
21-06 ***	Bulk Crew Rest Compartment Ventilation (With STC No. ST11686SE-T)	D	1	0	(M)(O)May be inoperative provided: a) The isolation valve is closed, and b) The Bulk Crew Rest Compartment is locked closed, not used, and considered inoperative.
	1) LOW FLOW Lighted Signs	D	3	1	May be inoperative provided The LOW FLOW aural alert is operational.
		D	3	0	(M)(O)May be inoperative provided the bulk crew rest compartment is locked closed, not used, and considered inoperative.
	2) LOW FLOW Aural Alert	D	1	0	(M)(O)May be inoperative provided the bulk crew rest compartment is locked closed, not used, and considered inoperative.
	3) LOW PRESSURE Lighted Indication/ Aural Warning	D	1	0	(M)(O)May be inoperative provided the bulk crew rest compartment is locked closed, not used, and considered inoperative.
21-07	Flight Crew Rest Compartment (FCRC) Heater System	C	1	0	(O)May be inoperative provided FCRC use is acceptable to crewmembers.
		C	1	0	(O)May be inoperative provided a passenger seat in the cabin is made available for the crewmember(s).

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 16a

PAGE:

DATE: 03/26/2015

21-3

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
21 AIR CONDITIONING					
21-08	Lower-Deck Mobil Crew Rest Area (LD-MCR) Heater System	C	1	0	(O)May be inoperative provided LD-MCR use is acceptable to crewmembers.
		D	1	0	(O)May be inoperative provided LD-MCR is locked closed and not used.
21-09	Bulk Crew Rest Compartment Heater System (With STC No. ST11686SE-T)	C	1	0	(M)(O)May be inoperative provided: a) The heaters are deactivated, and b) Bulk crew rest compartment use is acceptable to crewmembers.
		D	1	0	(M)(O)May be inoperative provided the bulk crew rest compartment is locked closed, not used, and considered inoperative.
	1) Electric Heaters	C	3	1	(M)May be inoperative provided affected heater(s) is deactivated.
21-10	Bulk Crew Rest Compartment Temperature Sensor (With STC No. ST11686SE-T)	C	2	0	May be inoperative provided the bulk crew rest compartment heater system is considered inoperative.

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 16a

PAGE:

DATE: 03/26/2015

21-4

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH		4. REMARKS OR EXCEPTIONS
21 AIR CONDITIONING							
21-11 Main Deck Cargo Isolation valve (FWD and AFT) (A330-200F)							
1) Isolation Valve	C	4	2	2	(M)(O)May be inoperative provided: a) Affected isolation valves are deactivated in the closed position, b) Associated trim air valves are deactivated in the closed position, and c) Access to the main deck cargo compartment is not authorized during flight.		
	B	4	0	0	(M)(O)May be inoperative provided: a) All the isolation valves are deactivated in the closed position, b) Associated trim air valves are deactivated in the closed position, c) The total air temperature (TAT) is monitored in flight and remains above -15°C, and d) Access to the main deck cargo compartment is not authorized during flight.		
	C	4	0	0	May be inoperative in the open position provided the main deck cargo compartment is empty or does not contain flammable or combustible materials.		

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 16a

PAGE:

DATE: 03/26/2015

21-5

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3.	NUMBER REQUIRED FOR DISPATCH	
21 AIR CONDITIONING					
21-11	Main Deck Cargo Isolation valve (FWD and AFT) (A330-200F) (Cont'd)				
	2) ISOL VALVES pb-sw				
	a) FAULT Light	D	1	0	May be inoperative.
	b) OFF Light	D	1	0	May be inoperative.
21-42	Aft Galley Area Heater System	D	1	0	(M)May be inoperative provided it is deactivated.
23-01	Lavatory and Galley Extraction Fan	C	1	0	(O)May be inoperative.
23-02	Lavatory and Galley Differential Pressure Switch	C	1	0	
23-05	In Flight Entertainment Center Bay Ventilation (A330-200, A330-300)	D	1	0	(M)May be inoperative provided the In Flight Entertainment System is deactivated.
23-06	GALY & LAV FAN pb-sw (A330-200F)				
	1) OFF Light	D	1	0	May be inoperative.
25-01	Air Conditioning Compartment Ventilation Turbofan	C	1	0	(M)(O)May be inoperative provided: a) Alternate procedures are established and used, and b) Turbofan is deactivated.

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16a  
 DATE: 03/26/2015

PAGE:  
 21-6

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
21 AIR CONDITIONING						
25-02 Air Conditioning Compartment Turbofan Supply Valve	C	1	1	0	(M)(O)May be inoperative closed provided alternate procedures are established and used.	NOTE: Failure of the turbofan supply valve in open position is indicated by a MAINTENANCE STATUS message.
25-03 Air Conditioning Compartment Turbofan Pressure Switch	C	1	1	0	(M)May be inoperative provided turbofan operates normally.	
26-01 Avionics Equipment Ventilation Extract Fan	C	1	1	0	(M)(O)May be inoperative provided: a) Both cabin fans operate normally, b) EXTRACT pb sw is selected to OVRD, and c) Airplane remains at or below FL 290 if dispatch is also combined with one air conditioning pack inoperative.	

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 16a

PAGE:

DATE: 03/26/2015

21-7

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3.	NUMBER REQUIRED FOR DISPATCH	
21	AIR CONDITIONING				
26-02	Avionics Equipment C Ventilation Overboard Extract Valve	1	1	0	(M)(O)May be inoperative provided: a) Valve is manually set in full open position for ground operations with engines not running, b) Valve is manually set in partially open position just prior to engine start, c) EXTRACT pb sw is selected to OVRD just prior to engine start, and d) Airplane remains at or below FL 290 if dispatch is also combined with one air conditioning pack inoperative.
26-03	Avionics Equipment C Ventilation Underfloor Extract Valve	1	1	0	(M)(O)May be inoperative in closed position provided: a) EXTRACT pb sw is selected to OVRD just prior to engine start, and b) Airplane remains at or below FL 290 if dispatch is also combined with one air conditioning pack inoperative.
26-04	Avionics Equipment C Ventilation Controller (AEVC)	1	1	0	(M)May be inoperative provided: a) Overboard valve is manually set in full open position, without deactivation, for ground operations with engines not running, b) OVRD function of the EXTRACT pb sw operates normally, c) Underfloor extract valve is manually set in open position, without deactivation, and d) Overboard valve is manually set in closed position, without deactivation, before engine start.

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16a  
 DATE: 03/26/2015

PAGE:  
 21-8

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3.	NUMBER REQUIRED FOR DISPATCH	
21 AIR CONDITIONING					
26-05	Cooling Effect Detector (CED)	C	1	0	(M)May be inoperative provided: a) Both cabin fans and both air conditioning packs operate normally, and b) Ventilation airflow through avionics racks is verified before each departure.
26-06	EXTRACT Pb Sw				
	1) FAULT Light	C	1	0	
	2) OVRD Light	C	1	0	
26-07	Indications on ECAM CAB PRESS Page				
	1) EXTRACT (Valve position)	C	1	0	
26-08	Warning and Caution on ECAM E/WD				
	1) VENT BLOWING FAULT	C	1	0	(M)May be inoperative provided: a) Both cabin fans and both air conditioning packs operate normally, and b) Ventilation airflow through avionics racks is verified before each departure.
27-01	Avionics *** Equipment Ground Cooling System	D	1	0	
27-02	Avionics Equipment *** Ground Cooling Skin Valve	D	1	0	(M)May be inoperative in closed position.

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16a  
 DATE: 03/26/2015

PAGE:  
 21-9

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
21 AIR CONDITIONING						
28-01 Cargo Compartment Ventilation Controller						
	1) Channels	C	2	1		
28-02 FWD Lower Deck Cargo Compartment Ventilation and Cooling ***						
	1) Extraction Fan	C	1	0		(O)May be inoperative provided alternate procedures are established and used.  NOTE: For live animal transportation, refer to the Live Animal Transportation Calculation tool (LATC).
	2) Isolation Valves					
	a) A330-200, A330-300	C	3	0		(M)(O)May be inoperative provided affected valves are verified closed.  NOTE: For live animal transportation, refer to the Live Animal Transportation Calculation tool (LATC).
		C	3	0		(O)May be inoperative in open position provided procedures are established and used to ensure the associated compartment remains empty, or is verified to contain only empty cargo handling equipment, ballast (ballast may be loaded in ULDs), and/or Fly Away Kits.  (Continued)

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16a  
 DATE: 03/26/2015

PAGE:  
 21-10

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
21 AIR CONDITIONING					
28-02 FWD Lower Deck Cargo Compartment Ventilation and Cooling (Cont'd)					
2) Isolation Valves (Cont'd)					
a) A330-200, A330-300 (Cont'd)					
	b) A330-200F	D	3	0	(M)(O)May be inoperative provided affected valves are verified closed.
		C	3	0	NOTE: Only apply the maintenance procedure when the valve is failed in open position.  (O)May be inoperative in open position provided procedures are established and used to ensure the associated compartment remains empty, or is verified to contain only empty cargo handling equipment, ballast (ballast may be loaded in ULDs), and/or Fly Away Kits.  NOTE: Operator MELs must define which items are approved for inclusion in the Fly Away Kits, and which materials can be used as ballast.

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16a  
 DATE: 03/26/2015

PAGE:  
 21-11

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
21 AIR CONDITIONING						
28-02 FWD Lower Deck Cargo Compartment Ventilation and Cooling (Cont'd)						
3) ISOL VALVES Pb Sw						
a) FAULT Light	C	1	0			
b) OFF Light	C	1	0			
4) Cargo Cooling System						
	D	1	0		(O)May be inoperative provided: a) COOLING selector is positioned OFF, and b) FWD CRG ISOL FAULT caution is not displayed on the EWD.  (M)(O)May be inoperative provided: a) COOLING selector is positioned OFF, and b) The cold air valve of the FWD LDCC is deactivated in the closed position.	
						NOTE: For live animal transportation, refer to the Live Animal Transportation Calculation tool (LATC).

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 16a

PAGE:

DATE: 03/26/2015

21-12

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
21 AIR CONDITIONING						
28-03 AFT Lower Deck *** Cargo Compartment Ventilation and Cooling						
	1) Extraction Fan	C	1	0	(O)May be inoperative provided alternate procedures are established and used.	
	2) Isolation Valves					
	a) A330-200, A330-300	C	3	0	(M)(O)May be inoperative provided affected valves are verified closed.	
		C	3	0	(O)May be inoperative in open position provided procedures are established and used to ensure the associated compartment remains empty, or is verified to contain only empty cargo handling equipment, ballast (ballast may be loaded in ULDs), and/or Fly Away Kits.	
					NOTE: Operator MELs must define which items are approved for inclusion in the Fly Away Kits, and which materials can be used as ballast.	
					(Continued)	

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 16a

PAGE:

DATE: 03/26/2015

21-13

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH		4. REMARKS OR EXCEPTIONS
21 AIR CONDITIONING							
28-03 AFT Lower Deck *** Cargo Compartment Ventilation and Cooling. (Cont'd)							
2) Isolation Valves (Cont'd)							
b) A330-200F	D	2	0	0	(M)(O)May be inoperative provided affected valves are verified closed.  NOTE: Only apply the maintenance procedure when the valve is failed in open position.	(O)May be inoperative in open position provided procedures are established and used to ensure the associated compartment remains empty, or is verified to contain only empty cargo handling equipment, ballast (ballast may be loaded in ULDs), and/or Fly Away Kits.  NOTE: Operator MELs must define which items are approved for inclusion in the Fly Away Kits, and which materials can be used as ballast.	
	C	2	0	0			
3) ISOL VALVES Pb Sw							
a) FAULT Light	C	1	0	0			
b) OFF Light	C	1	0	0			

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16a  
 DATE: 03/26/2015

PAGE:  
 21-14

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
21 AIR CONDITIONING					
28-04 BULK Cargo Compartment Ventilation					
1) Extraction Fan		C	1	0	(O)May be inoperative provided alternate procedures are established and used.  NOTE: For live animal transportation, refer to the Live Animal Transportation Calculation tool (LATC).
2) Isolation Valves					
a) A330-200, A330-300		C	2	0	(M)(O)May be inoperative provided affected valves are verified closed.  NOTE: For live animal transportation, refer to the Live Animal Transportation Calculation tool (LATC).
		C	2	0	(O)May be inoperative in open position provided procedures are established and used to ensure the AFT and the BULK lower deck cargo compartments remain empty, or are verified to contain only empty cargo handling equipment, ballast (ballast may be loaded in ULDs), and/or Fly Away Kits.  NOTE: Operator MELs must define which items are approved for inclusion in the Fly Away Kits, and which materials can be used as ballast.
(Continued)					

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16a  
 DATE: 03/26/2015

PAGE:  
 21-15

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED			3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
21 AIR CONDITIONING							
28-04	BULK Cargo *** Compartment Ventilation (Cont'd)						
	2) Isolation Valves (Cont'd)						
	b) A330-200F	D	2	0	0	(M)(O)May be inoperative provided affected valves are verified closed.	
		C	2	0	0	NOTE: Only apply the maintenance procedure when the valve is failed in open position.	
	(O)May be inoperative in open position provided procedures are established and used to ensure the AFT and the BULK lower deck cargo compartments remain empty, or are verified to contain only empty cargo handling equipment, ballast (ballast may be loaded in ULDs), and/or Fly Away Kits.						
	NOTE: Operator MELs must define which items are approved for inclusion in the Fly Away Kits, and which materials can be used as ballast.						
	3) ISOL VALVES Pb Sw						
	a) FAULT Light	C	1	0	0		
	b) OFF Light	C	1	0	0		

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16a

PAGE:

DATE: 03/26/2015

21-16

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH		4. REMARKS OR EXCEPTIONS
21 AIR CONDITIONING							
31-01 Automatic Cabin Pressure Control Systems (CPC, Outflow Valve AUTO Channels)							
1) Without Mod. 53145/MP D44784	C	2	0	0	(O)May be inoperative provided: a) Flight is conducted in an unpressurized configuration, and b) Extended overwater flight is prohibited.		
a) System 1	C	1	0	0		(O)Except for ER operations, may be inoperative provided: a) Cabin pressure indications are available on ECAM CAB PRESS in manual mode, b) System 2 operates normally, and c) Extended overwater flight is prohibited.	
b) System 2	C	1	0	0			(O)May be inoperative provided: a) Cabin pressure indications are available on ECAM CAB PRESS in manual mode, and b) System 1 operates normally.
Continued)							

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16a

PAGE:

DATE: 03/26/2015

21-17

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3.	NUMBER REQUIRED FOR DISPATCH	
21 AIR CONDITIONING					
31-01	Automatic Cabin Pressure Control Systems (CPC, Outflow Valve AUTO Channels) (Cont'd)				
	2) With Mod. 53145/MP D44784	C	2	0	(O)May be inoperative provided: a) Flight is conducted in an unpressurized configuration, and b) Extended overwater flight is prohibited.
	a) System 1	C	1	0	(M)Except for ER operations, may be inoperative provided: a) Manual Cabin Pressure Control System is verified to operate normally, b) System 2 operates normally, and c) Extended overwater flight is prohibited.
	b) System 2	C	1	0	(M)May be inoperative provided: a) Manual Cabin Pressure Control System is verified to operate normally, and b) System 1 operates normally.
31-02	Manual Cabin Pressure Control System (Outflow Valve MAN Channel. MAN V/S CTL Sel)	C	1	0	(O)May be inoperative provided flight is conducted in an unpressurized configuration.
		C	1	0	(M)May be inoperative provided both automatic cabin pressure control systems are verified to operate normally before each flight.
31-03	Outflow Valves Automatic Motors	C	4	0	Deleted, Rev. 9. (Included with item 21-31-01.)

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16a

PAGE:

DATE: 03/26/2015

21-18

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			2.	3. NUMBER REQUIRED FOR DISPATCH	
21 AIR CONDITIONING					
31-04 Safety Valves	C	2	1	1	(M)One may be inoperative in closed position provided: a) Both automatic cabin pressure control systems operate normally, and b) The three motors on each outflow valve operate normally.
1) With Mod. 48980	C	3	2	2	(M)One may be inoperative in closed position provided: a) Both automatic cabin pressure control systems operate normally, and b) The three motors on each outflow valve operate normally.
31-05 Landing Elevation Selection					
1) Auto Function	C	1	0	0	(O)May be inoperative provided LDG ELEV is set manually.
31-06 MODE SEL Pb Sw FAULT Light	C	1	1	0	
31-07 Negative Relief Valve	C	1	1	0	(O)May be inoperative provided flight is conducted in an unpressurized configuration.
43-01 Forward Cargo *** Compartment Heating	D	1	1	0	(O)May be inoperative provided: a) FWD temperature selector is positioned COLD, and b) On the COND SD page, the FWD trim air valve arrow indicates C.
NOTE: For live animal transportation, refer to the Live Animal Transportation Calculation tool (LATC).					
(Continued)					

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 16a

PAGE:

DATE: 03/26/2015

21-19

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
21 AIR CONDITIONING						
43-01 Forward Cargo *** Compartment Heating (Cont'd)		D	1	0	(M)(O)May be inoperative provided: a) FWD temperature selector is positioned COLD, and b) The FWD trim air valve is deactivated in the closed position.  NOTE: For live animal transportation, refer to the Live Animal Transportation Calculation tool (LATC).	
43-02 Bulk Cargo *** Compartment Heating		C	1	0	(O)May be inoperative provided the BULK HOT AIR pb sw is selected OFF.  NOTE: For live animal transportation, refer to the Live Animal Transportation Calculation tool (LATC).	
		D	1	0	(M)(O)May be inoperative provided fan heater is deactivated.  NOTE: For live animal transportation, refer to the Live Animal Transportation Calculation tool (LATC).	
43-03 AFT Lower Deck *** Cargo Heating System (A330-200F)		D	1	0	(M)(O)May be inoperative provided that the associated trim air valve is deactivated in the closed position.	

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 16a

PAGE:

DATE: 03/26/2015

21-20

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
21 AIR CONDITIONING						
43-04 Fwd/Aft/Bulk *** Cargo Compartment Heating Indications on ECAM page						
1) CRUISE Page (A330-200, A330-300)		D	-	0	May be inoperative provided the associated cargo compartment heating is considered inoperative.	
2) COND Page (A330-200F)		D	-	0	May be inoperative provided the associated cargo compartment heating is considered inoperative.	
51-01 Pack Flow Control Valves		C	2	0	(M)May be inoperative provided: a) Valve is secured closed, and b) Associated air conditioning pack is considered inoperative.	

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16a

PAGE:

DATE: 03/26/2015

21-21

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
21 AIR CONDITIONING					
51-02 Pack Flow Selection					
	1) Manual Selection (Aircraft with PW 4000 Engines, RR TRENT Engines, and GE CF6-80E1 Series Engines With Mod. 56554.)	C	1	0	
	2) Manual Selection (Aircraft with GE CF6-80E1 Series Engines Without Mod. 56554.)	C	1	0	Except for ER operations, may be inoperative provided airplane is not operated in known or forecast icing conditions.
51-03 PACK 1(2) Pb Sw					
	1) FAULT Lights	C	2	0	
	2) OFF Lights	C	2	0	
51-04 Indications on ECAM					
	1) BLEED Page	C	-	-	Pack related indications may be inoperative.
	2) CAB PRESS Page	C	-	-	Pack 1 and 2 indications may be inoperative.

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16a  
 DATE: 03/26/2015

PAGE:  
 21-22

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			2.	3. NUMBER REQUIRED FOR DISPATCH	
21 AIR CONDITIONING					
52-01	Air Conditioning Packs	C	2	1	(M)(O)Except for ER operations, one may be inoperative provided: a) Airplane remains at or below FL 350 (A330-200, A330-200F) or FL 370 (A330-300), b) Pack controller associated with the non-affected air conditioning pack operates normally on both channels, c) Affected PACK pb sw is selected OFF and associated pack flow control valve is verified closed on ECAM BLEED or CAB PRESS page, and d) Speed brakes operate normally.
		C	2	1	(M)(O)Except for ER operations, one may be inoperative provided: a) Airplane remains at or below FL 310, b) Pack controller associated with the non-affected air conditioning pack operates normally on both channels, and c) Affected PACK pb sw is selected OFF and associated pack flow control valve is verified closed on ECAM BLEED or CAB PRESS page.
		C	2	0	(O)May be inoperative provided flight is conducted in an unpressurized configuration.  (Continued)

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 16a

PAGE:

DATE: 03/26/2015

21-23

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
21 AIR CONDITIONING					
52-01 Air Conditioning Packs (Cont'd)					
	1) Air Cycle Machine	C	2	1	(O)One pack may be operated on heat exchanger cooling only (PACK 1(2) IN BY-PASS MODE) provided: a) Affected air conditioning pack is not operated until airborne and the TAT is below 12 degrees Celsius, and b) Affected pack outlet temp indication is available on ECAM BLEED page.
53-01 Pack Controllers					
	1) Channels	C	4	2	One may be inoperative on each pack controller.
		C	4	2	Both may be inoperative on one pack controller provided the associated air conditioning pack is considered inoperative.
53-02 Bypass Valves (Without Mod. 55313 or Mod. 55514)					
		C	2	0	(M)May be inoperative in closed position provided air cycle machine of associated air conditioning pack operates normally.
53-03 Temperature Control Valves					
		C	2	1	May be inoperative provided pack controller of other air conditioning pack operates normally.
53-04 Air Conditioning RAM Air Inlet/Outlet Flaps					
		C	4	0	(M)(O)May be inoperative in open position.

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16a

PAGE:

DATE: 03/26/2015

21-24

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
21 AIR CONDITIONING					
53-05	Indications on ECAM BLEED page				
	1) Temperature Control Valve Position	C	2	0	
55-02	Indications on ECAM BLEED Page				
	1) RAM AIR	C	1	0	
63-01	Zone Controller				
	1) Channels	C	2	1	
63-02	Trim Air Valves				
	1) A330-200, A330-300	C	7	0	(O)May be inoperative provided the closure function of the associated pack flow control valve is checked to operate normally on the ECAM BLEED page before each flight.
		C	7	0	May be inoperative provided the associated pack flow control valve is considered inoperative.
		C	7	-	(M)Trim air valves associated with the temperature control of the economy class may be inoperative provided it is deactivated in the closed position.
	2) A330-200F	C	6	0	(O)May be inoperative provided the closure function of the associated pack flow control valve is checked to operate normally on the ECAM BLEED page before each flight.
		C	6	0	May be inoperative provided the associated pack flow control valve is considered inoperative.

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 16a

PAGE:

DATE: 03/26/2015

21-25

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
21 AIR CONDITIONING					
63-03	Hot Air Valves	C	2	0	(O)May be inoperative provided the closure function of the associated pack flow control valve is verified to operate normally on the ECAM BLEED page before each flight.
		C	2	0	May be inoperative provided the associated pack flow control valve is considered inoperative.
63-04	Hot Air X Valve	C	1	0	
63-05	HOT AIR 1(2) Pb Sw				
	1) FAULT Lights	C	2	0	May be inoperative provided zone duct temperature indications are available on ECAM.
	2) OFF Lights	C	2	0	
63-06	Cabin and Cockpit Zone Indications on ECAM				
	1) COND Page	C	-	0	
	2) CRUISE Page	C	-	0	
63-07	Main Deck Cargo Cooling System (A330-200F)	D	1	0	(O)May be inoperative.

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 13  
 DATE: 06/11/2012

PAGE:  
 22-1

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
22 AUTO FLIGHT					
10-01	Autopilot Systems	C	2	1	One may be inoperative provided approach minimums do not require its use.
		B	2	0	May be inoperative provided: a) Approach minimums do not require their use, b) Enroute operations do not require their use, and c) Number of flight segments and segment duration is acceptable to flight crew.  NOTE: Any mode which operates normally may be used.
10-02	Flight Director Systems	C	2	0	(O)May be inoperative provided operations or procedures do not require their use.
10-03	Take Over Pb Switches				
	1) AP Disconnect Function Only	C	2	1	One may be inoperative provided: a) Autopilots are not utilized below 1500 feet AGL, b) Approach minimums do not require the use of the autopilot, and c) Priority function is verified to operate normally before each departure.
		B	2	0	May be inoperative provided: a) Both autopilots are not used, and b) Priority function is verified to operate normally before each departure.

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 13  
 DATE: 06/11/2012

PAGE:  
 22-2

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
22 AUTO FLIGHT					
10-04	AUTO LAND Lights	C	2	0	May be inoperative provided approach minimums do not require use of autoland.
10-05	AP Disengagement Warning System	B	1	0	May be inoperative provided both autopilots are not used.
10-06	Sticks and Rudder Pedals Locking Solenoids in AP Mode	C	3	2	One may be inoperative unlocked provided: a) Approach minimums do not require its use, and b) No autoland is performed.
30-01	Autothrust Function	C	1	0	(M)Except for ER operations beyond 180 minutes, may be inoperative provided: a) All thrust lever sensors are verified to operate normally, and b) Approach minimums do not require its use.  NOTE: Alpha floor is not available with autothrust function inoperative.
30-02	Autothrust Instinctive Disconnect Switches	B	2	1	(M)One may be inoperative provided ability to disconnect A/THR by means of remaining Instinctive Disconnect Pb and by FCU A/THR Pb is verified prior to each departure.
30-03	Autothrust Disengagement Warning System	C	1	0	(O)May be inoperative provided autothrust is disconnected and considered inoperative.

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 13  
DATE: 06/11/2012

PAGE:  
22-3

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
22	AUTO FLIGHT				
66-03	Windshear Warning and Flight Guidance System (Reactive)	B	-	0	(O)May be inoperative provided alternate procedures are established and used.  NOTE: Operator's alternate procedures should include reviewing windshear avoidance and windshear recovery procedures.
		C	-	0	(O)May be inoperative provided: a) Alternate procedures are established and used, and b) Windshear Detection and Avoidance System (Predictive) operates normally.
72-01	Lateral Navigation	C	2	1	(O)One may be inoperative provided: a) Operations or procedures do not require its use, and b) One NAV B/UP function is verified to operate normally.
72-02	IRS (and GPS) Initialization	C	2	1	
72-03	Nav aids Selection and Tuning	C	2	1	
73-01	Performance Information and Vertical Navigation	C	2	0	May be inoperative provided operations or procedures do not require their use.
73-02	Fuel/Time Prediction	C	2	0	
73-05	Navigation Database				Deleted, Rev. 7. (See Item 34-61-01)

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 13  
 DATE: 06/11/2012

PAGE:  
 22-4

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
22 AUTO FLIGHT						
75-01 SWITCHING Panel						
1) FM Selector						
	a) NORM Position	C	1	0	May be inoperative provided: a) The intended flight does not require dual FM capability or NAV B/UP function, and b) Lateral navigation can be displayed on at least one ND unit.	
	b) BOTH ON 1, BOTH ON 2 Positions	C	2	0	May be inoperative provided: a) Selector operates normally in NORM position, and b) Lateral navigation can be displayed on at least one ND unit.	
75-02 MCDU Switching Function of BRT Knob						
		C	2	0	May be inoperative provided other functions of MCDU 1 and MCDU 2 operate normally.	

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 13  
 DATE: 06/11/2012

PAGE:  
 22-5

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH		4. REMARKS OR EXCEPTIONS
22 AUTO FLIGHT							
81-01 Auto Flight Control Panel							
1) Mode Engagement Pb							
a) LOC		C	1	0	May be inoperative provided approach minimums do not require its use.		
b) ALT		C	1	0	May be inoperative provided crew procedures do not require its use.		
c) APPR		C	1	0	May be inoperative provided approach minimums do not require its use.		
2) Selection Windows		C	4	0	May be inoperative provided: a) Associated indications operate normally on both PFD's and both ND's, and b) Inoperative windows are blank or masked.		
3) HDG-V/S TRK-FPA Change Over Pb		C	1	0	May be inoperative provided: a) HDG-V/S selection operates normally, and b) Crew procedures do not require its use.		
4) SPD/MACH Change Over Pb		C	1	0	May be inoperative provided SPD selection operates normally.		
5) METRIC ALT Pb		C	1	0	(O)May be inoperative provided alternate procedures are established and used.		
		D	1	0	May be inoperative provided procedures do not require its use.		
(Continued)							

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 13  
DATE: 06/11/2012

PAGE:  
22-6

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
22 AUTO FLIGHT					
81-01	Auto Flight Control Panel (Cont'd)				
	6) Engagement Pb Light Bars	D	6	0	May be inoperative provided associated indication is available on both PFD's.
	7) V/S FPA Selection Knob	C	1	0	May be inoperative provided procedures do not require its use.
	8) V/S FPA Push To Level Off Function	C	1	0	(O)May be inoperative provided alternate procedures are established and used.
81-02	EFIS Control Panel				
	1) Baro Reference Display Windows	C	2	0	May be inoperative provided associated indications operate normally on both PFD's.
	2) Baro Reference Sel				
	a) Outer Ring (in Hg/ hPa)	C	2	0	May be inoperative provided required units for the intended flight is available on both EFIS control panels.
	3) LS Pb	C	2	0	May be inoperative provided approach minimums do not require their use.
	4) Optional Data (ARPT, NDB, VOR.D, WPT, CSTR) Display Pb	C	10	2	May be inoperative provided: a) Operations or procedures do not require their use, and b) One ARPT and one CSRT pb are available on either side.
(Continued)					

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 13  
 DATE: 06/11/2012

PAGE:  
 22-7

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
22 AUTO FLIGHT					
81-02	EFIS Control Panel (Cont'd)				
	5) ND Range Sel	C	2	1	One may be inoperative provided off side ND unit operates normally.
	6) ND Mode Sel	C	2	1	One may be inoperative provided: a) Off side ND unit operates normally, and b) Procedures do not require its use.
	7) ADF/VOR Sel	C	4	-	As required by 14 CFR.
	8) Display Pb Light Bars	D	14	0	May be inoperative provided associated indication is available on associated PFD or ND.
82-01	Multipurpose Control And Display Units (MCDU)				
	1) MCDU (With Mod. 47457/MP S14273 or Mod. 47462/MP S14275 or Mod. 48765/MP S14270 or Mod. 48766/MP S14271 or Mod. 51138/MP S16696 or Mod. 51139/MP S16697)	C	3	2	(O)MCDU 2 or 3 may be inoperative provided operations or procedures do not require its use.
		C	3	1	(O)MCDU 2 and 3 may be inoperative provided: a) Operations and procedures do not require two MCDU's, or b) Flight remains within radio navaid coverage.

Continued

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 13  
 DATE: 06/11/2012

PAGE:  
 22-8

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
22 AUTO FLIGHT						
82-01 Multipurpose Control And Display Units (MCDU) (Cont'd)						
*** 6) ATC COMM Page Keys						

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 13  
 DATE: 06/11/2012

PAGE:  
 22-9

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
22 AUTO FLIGHT	83-01 Flight Management Guidance and Envelope Computers (FMGEC)	A	2	1	(M)(O)Except for ER operations, one may be inoperative provided: a) Alternate procedures are established and used, b) Departure and destination airport weather is at and forecast to remain within VFR minimums for proposed departure and arrival times, and c) Repairs are made within three flight legs.  NOTE: (Without Mod. 53919) If FMGEC 1 is inoperative, the Terrain function of the TAWS is inoperative.

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 13  
 DATE: 06/11/2012

PAGE:  
 22-10

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
22 AUTO FLIGHT						
83-02 FMA Indications on PFD						
1) AP/FD Related Indications	C	-	-	-		Indications may be inoperative on PNF side FMA.
2) A/THR Related Indications	C	-	0			Indications may be inoperative on both FMA's provided Autopilot and Flight Director are not used.
2) A/THR Related Indications	A	-	-			Indications may be inoperative on PNF side FMA provided repairs are made within three flight days.
3) Approach and Landing Capabilities	C	-	0			(O)Indications may be inoperative on both FMA's provided autothrust is disconnected and considered inoperative.
3) Approach and Landing Capabilities	C	-	-			(O)Indications may be inoperative on PNF side FMA provided: a) Approach minimums do not require their use, and b) Alternate procedures are developed and used.
3) Approach and Landing Capabilities	C	-	0			Indications may be inoperative on both FMA's provided approach minimums, operations or procedures do not require their use.

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 23-1

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
23 COMMUNICATIONS						
11-01 High Frequency (HF) Communication Systems	D	2	-		Any in excess of those required by 14 CFR may be inoperative.	
	C	2	1		(O)May be inoperative while conducting operations that require two Long Range Communication Systems (LRCS) provided: a) SATCOM Voice or Data Link operates normally, b) Alternate procedures are established and used, c) SATCOM Voice coverage is available over the intended route of flight, and d) If SATCOM Voice is to be used over the intended route of flight, SATCOM Voice short codes (INMARSAT) or direct dial commercial numbers (IRIDIUM) must be available. If not available, prior coordination with the appropriate ATS (FIR) facility is required.  NOTE: SATCOM Voice is to be used only as a backup to normal HF communications.	
12-01 VHF Systems	D	3	-		Any in excess of those required by 14 CFR may be inoperative provided it is not powered by an Essential Bus and not required for emergency procedures.	
24-01 ACARS ***	D	1	0		May be inoperative provided operations or procedures do not require its use.	

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14  
DATE: 05/31/2013

PAGE:  
23-2

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
23 COMMUNICATIONS						
28-01 ***	Satellite Communication (SATCOM) System	C	1	0	(O)Except for ER operations beyond 180 minutes, may be inoperative provided alternate procedures are established and used.	
		D	1	0	Except for ER operations beyond 180 minutes, may be inoperative provided operations or procedures do not require its use.	
	1) Voice Channels	C	-	0	(O)Except for ER operations beyond 180 minutes, may be inoperative provided alternate procedures are established and used.	
		D	-	0	Except for ER operations beyond 180 minutes, may be inoperative provided operations or procedures do not require its use.	
	2) Data Channel	C	1	0	(O)May be inoperative provided alternate procedures are established and used.	
		D	1	0	May be inoperative provided operations or procedures do not require its use.	

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 23-3

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
23 COMMUNICATIONS						
31-01 Passenger/Super-numerary Address System (PA)						
1) A330-200, A330-300	B	1	0	0	(O)May be inoperative provided: a) Alternate, normal and emergency procedures and/or operating restrictions are established and used, and b) Flight attendant alerting system (audio and visual) operates normally.	
	C	1	0	0	(O)May be inoperative provided: a) PA not required by 14 CFR, and b) Alternate, normal, and emergency procedures and/or operating restrictions are established and used.	
a) Lavatory Speakers	C	-	0	0	(O)May be inoperative provided alternate procedures are established and used.	
2) A330-200F	C	1	0	0	(O)May be inoperative provided alternate, normal, and emergency procedures, and/or operating restrictions are established and used.	
	D	1	0	0	May be inoperative provided procedures do not require its use.	
a) Lavatory Speaker	C	1	0	0	(O)May be inoperative provided alternate procedures are established and used.	
	D	1	0	0	May be inoperative provided procedures do not require its use.	

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 23-4

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3.	NUMBER REQUIRED FOR DISPATCH	
23 COMMUNICATIONS					
32-01 ***	Prerecorded Announcement and Music Reproducer (PRAM)	C	1	0	(O)May be inoperative provided alternate procedures are developed and used.
		D	1	0	May be inoperative provided procedures do not require its use.
42-01	Cockpit to Ground Crew Call System				
1)	MECH Call/COCKPIT Call	C	1	0	(O)Cockpit to ground or ground to cockpit calls may be inoperative provided alternate procedures are developed and used.
2)	Ground External Horn	C	1	0	(O)May be inoperative provided personnel are available to monitor APU.
		C	1	0	(O)May be inoperative provided alternate procedures are developed and used.

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 23-5

SYSTEM & SEQUENCE NUMBERS	1. ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
23 COMMUNICATIONS					
43-01 Crewmember Interphone System(s)					
1) Flight Deck to Ground, Ground to Flight Deck Functions					
a) Flight Interphone	C	1	0	(O)May be inoperative provided: a) Alternate procedures are established and used, and b) Service interphone jack at external power panel location operates normally.	
	B	-	0	(O)May be inoperative provided alternate procedures are established and used.	
b) Service Interphone Jacks	C	-	0	(O)May be inoperative provided: a) Alternate procedures are established and used, and b) Flight interphone jack at external power panel location operates normally.	
	B	-	0	(O)May be inoperative provided alternate procedures are established and used.	
(Continued)					

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 23-6

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
23 COMMUNICATIONS						
43-01	Crewmember Interphone System(s) (Cont'd)					
	2) Flight Deck to Cabin/Supernumerary Compartment, Cabin/Supernumerary Compartment to Flight Deck Functions					
	a) A330-200, A330-300	B	-	-		(O)May be inoperative provided: a) Flight deck to cabin and cabin to flight deck interphone functions operate normally on at least fifty percent of the cabin handsets, b) Flight deck to cabin and cabin to flight deck interphone function operates normally at one door for each pair of exit doors, and c) Alternate communication procedures between the affected flight attendant stations are established and used.
	b) A330-200F	C	1	0		(O)May be inoperative provided alternate, normal, and emergency procedures, and/or operating restrictions are established and used.
		D	1	0		May be inoperative provided procedures do not require its use.
(Continued)						

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 23-7

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
23 COMMUNICATIONS						
43-01	Crewmember Interphone System(s) (Cont'd)					
3) Cabin to Cabin Function (A330-200, A330-300)	B	-	-	-	(O)May be inoperative provided: a) Cabin to cabin interphone functions operate normally on at least fifty percent of the cabin handsets, b) Cabin to cabin interphone function operates normally at one door for each pair of exit doors, and c) Alternate communication procedures between the affected flight attendant stations are established and used.	
4) Bulk Crew Rest Compartment Cabin Interphone Function (With STC No. ST11686SE-T)	C	1	0	0	(O)May be inoperative provided alternate procedures are developed and used.	
	D	1	0	0	(M)(O)May be inoperative provided the bulk crew rest compartment is considered inoperative.	
(Continued)						

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 23-8

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
23 COMMUNICATIONS						
43-01 Crewmember Interphone System(s) (Cont'd)						
5) Handset System(s)						
a) Flight Deck Handset		D	1	0	May be inoperative provided operations/procedures do not require its use.	
i) A330-200, A330-300		C	1	0	(O)May be inoperative provided: a) Flight deck to cabin communication operates normally, and b) Alternate procedures are established and used.	
ii) A330-200F		C	1	0	May be inoperative provided flight deck to supernumerary compartment communication operates normally.	
b) Cabin Attendant Handsets (A330-200, A330-300)		B	-	-	(O)May be inoperative provided: a) Fifty percent of cabin handsets operate normally, b) One handset must operate normally at each pair of exit doors, and c) Alternate communications procedures between the affected Flight Attendants station(s) are established and used.	
NOTE 1: An operative handset at an inoperative flight attendant seat shall not be counted to satisfy the fifty percent requirement.						
NOTE 2: Any handset function(s) that operate normally may be used.						
(Continued)						

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 23-9

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
23 COMMUNICATIONS						
43-01	Crewmember Interphone System(s) (Cont'd)					
	5) Handset System(s) (Cont'd)					
	c) Supernumerary Handset (A330-200F)	C	1	0	(O)May be inoperative provided alternate, normal and emergency procedures, and/or operating restrictions are established and used.	
		D	-	0	NOTE: Any handset function(s) that operate normally may be used. All may be inoperative provided the supernumerary compartment remains unoccupied.	
	d) Crew Rest Compartment Handset	C	-	0	(O)May be inoperative provided: a) One loudspeaker is operative in the associated crew rest compartment, and b) Alternate procedures are established and used.	
***	e) Lower Deck Cabin Crew Rest Compartment Handset	C	-	0	(O)May be inoperative provided alternate procedures are developed and used.	
		D	-	0	May be inoperative provided lower deck cabin crew rest compartment is considered inoperative.	
(Continued)						

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 23-10

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
23 COMMUNICATIONS						
43-01	Crewmember Interphone System(s) (Cont'd)					
	5) Handset System(s) (Cont'd)					
***	f) Bulk Crew Rest Compartment Handset (With STC No. ST11686SE-T)	C	5	0	(0)May be inoperative provided alternate procedures are developed and used.	
		D	5	0	May be inoperative provided lower deck cabin crew rest compartment is considered inoperative.	
	i) Pilot Area Handset	C	3	1	Two may be inoperative in the pilot area.	
	ii) Flight Attendant/ Common Area Handset	C	2	1	One may be inoperative in either the flight attendant or common area.	
(Continued)						

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 23-11

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
23 COMMUNICATIONS						
43-01	Crewmember Interphone System(s) (Cont'd)					
	6) Alerting System (Chime/Light)					
	a) ATT Call Lights (Flight Deck Call Lights/ CAPT and F/O ACP)					
	i) A330-200, A330-300	B	2	0		May be inoperative provided the flight deck buzzer is operative.
						NOTE: The flight deck buzzer must always be operative.
	ii) A330-200F	B	2	0		May be inoperative provided the flight deck buzzer is operative.
		D	2	0		May be inoperative provided supernumerary compartment remains unoccupied.
(Continued)						

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 23-12

SYSTEM & SEQUENCE NUMBERS	1. ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
23 COMMUNICATIONS					
43-01	Crewmember Interphone System(s) (Cont'd)				
6)	Alerting System (Chime/Light) (Cont'd)				
b)	Cabin Attendant/ Supernumerary Compartment Call Light System				
i)	A330-200, B A330-300	1	0		(O)May be inoperative provided: a) Passenger address (PA) system operates normally, b) If affected visual alerting system is used for lavatory smoke detector alerting, an alternate lavatory smoke alert (audio or visual) is installed and operates normally, and c) Alternate procedures are established and used.
					NOTE 1: Passenger to attendant call light system is considered Non-Essential Equipment and Furnishing (NEF).
					NOTE 2: Any visual alerting system function(s) that operates normally may be used.
					(Continued)

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 23-13

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
23 COMMUNICATIONS					
43-01	Crewmember Interphone System(s) (Cont'd)				
	6) Alerting System (Chime/Light) (Cont'd)				
	b) Cabin Attendant/Supernumerary Compartment Call Light System (Cont'd)				
	ii) A330-200F B	1	0		May be inoperative provided: a) Supernumerary address (PA) system operates normally, and b) Alternate procedures are established and used.  NOTE 1: Lavatory to supernumerary compartment call light system is considered Non-Essential Equipment and Furnishing (NEF).  NOTE 2: Any visual alerting system function(s) that operates normally may be used.
	D	1	0		May be inoperative provided supernumerary compartment remains unoccupied.  (Continued)

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 23-14

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
23 COMMUNICATIONS					
43-01	Crewmember Interphone System(s) (Cont'd)				
	6) Alerting System (Chime/Light) (Cont'd)				
	c) Cabin Attendant/Supernumerary Compartment Chime System				
	i) A330-200, B A330-300	-	0		(O)May be inoperative provided: a) Passenger address (PA) system operates normally, b) If affected chime is used for lavatory smoke detector alerting, an alternate lavatory smoke alert (audio or visual) is installed and operates normally, and c) Alternate procedures for are established and used.
					NOTE 1: Passenger to attendant chime system is considered Non-Essential Equipment and Furnishing (NEF).
					NOTE 2: Any audio alerting system function(s) that operates normally may be used.
					(Continued)

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 23-15

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
23 COMMUNICATIONS					
43-01	Crewmember Interphone System(s) (Cont'd)				
	6) Alerting System (Chime/Light) (Cont'd)				
	c) Cabin Attendant/ Supernumer- ary Compart- ment Chime System (Cont'd)				
	ii) A330-200F B	1	0		May be inoperative provided: a) Supernumerary address (PA) system operates normally, and b) Alternate procedures are established and used.  NOTE 1: Any audio alerting system function(s) that operates normally may be used.  NOTE 2: Lavatory to supernumerary compartment chime system is considered Non-Essential Equipment and Furnishing (NEF).
		D	1	0	May be inoperative provided supernumerary compartment remains unoccupied.
***	7) ATTND ADV Light System	C	1	0	(O) May be inoperative provided alternate procedures are established and used.
		D	1	0	May be inoperative provided procedures do not require its use.

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 23-16

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
23 COMMUNICATIONS					
51-01	SELCAL	C	1	0	(O)May be inoperative provided alternate procedures are established and used.
		D	1	0	May be inoperative provided procedures do not require its use.
51-02	Audio Control Panel (ACP)				
	1) CAPT and F/O	C	2	1	(O)One may be inoperative provided: a) ACP 3 operates normally, and b) AUDIO SWITCHING selector operates normally.
	2) ACP 3				See Primary Observer Seat for relief.
***	3) Fourth Occupant	D	1	0	
***	4) Avionics Compartment	D	1	0	
	5) Transmission Key(s)	C	-	-	One may be inoperative on each ACP provided: a) VHF 1 transmission key operates normally on either CAPT ACP or F/O ACP, and b) HF 1 transmission key (If HF is required) operates normally on either CAPT ACP or F/O ACP.
	6) Reception Knob(s)	C	-	-	One may be inoperative on each ACP provided: a) VHF 1 reception knob operates normally on either CAPT ACP or F/O ACP, and b) HF 1 reception knob (If HF is required) operates normally on either CAPT ACP or F/O ACP.
	7) Reception Knob Lights	C	-	0	

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14  
DATE: 05/31/2013

PAGE:  
23-17

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
23 COMMUNICATIONS					
51-03 SWITCHING Panel					
	1) AUDIO Selector	C	1	0	
51-04 Flight Deck Headsets/Headphones					
	1) Headset Boom Microphones	A	-	0	May be inoperative provided: a) Associated hand microphone is installed and operates normally, b) Flight Data Recorder (FDR) operates normally, and c) Repairs are made within three flight days.
	2) Headset Earphones/Headphones	C	-	1	Either Captain's or First Officer's earphone/headphones may be inoperative provided associated flight deck speaker operates normally.
51-05 Hand Microphone Systems					
	1) Captain and First Officer	C	2	0	May be inoperative provided associated boom microphone operates normally.
	2) Observer Seats/Avionics Compartment	D	-	0	May be inoperative provided procedures do not require their use.
51-06 Cockpit Loudspeakers					
		C	2	1	One may be inoperative provided associated headset earphones or headphones are installed and operate normally, and compatible with quick donning oxygen mask.

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14  
DATE: 05/31/2013

PAGE:  
23-18

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
23 COMMUNICATIONS					
51-07	Side Stick Radio Selector (PTT)	C	2	0	May be inoperative in open position provided INT/RAD switches on CAPT ACP, F/O ACP and ACP3 operate normally.
		C	2	0	(M)May be inoperative provided: a) INT/RAD switches on CAPT ACP, F/O ACP and ACP3 operate normally, and b) Affected switch is deactivated in open position.
70-01	Emergency Evacuation Signaling System	C	1	0	(O)May be inoperative provided alternate procedures are developed and used.
		D	1	0	May be inoperative provided procedures do not require its use.
71-01	Cockpit Voice Recorder System (CVR)	A	1	0	May be inoperative provided: a) Flight Data Recorder (FDR) operates normally, and b) Repairs are made within three flight days.
***	1) Independent Power Source	C	1	0	
72-01	Cockpit Door Surveillance System (CDSS)	D	1	-	Any in excess of those required by 14 CFR may be inoperative.
***					

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14  
DATE: 05/31/2013

PAGE:  
23-19

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
23 COMMUNICATIONS						
73-01	Cabin Inter-communication Data System (CIDS)					
	1) DEU A					
	a) Loud-speakers (Cabin)	C	-	-		One or more may be inoperative and passengers may be carried provided: a) Passenger Address System operates normally, and b) No seat may be occupied from which a passenger cannot clearly hear a passenger address announcement.
		B	-	-		One or more may be inoperative provided Passenger Address System is considered inoperative.
***	b) Loud-speakers (Lower Deck Cabin Crew Rest Compartment)	D	-	0		(O)May be inoperative provided alternate procedures are developed and used.
***	c) Loud-speakers (Lower Deck Facilities)	C	-	0		(O)May be inoperative provided alternate procedures are developed and used.
***	d) Loud Speakers (Bulk Crew Rest Compartment) (With STC No. ST11686SE-T)	D	3	1		Two speakers may be inoperative provided the speaker on the auxiliary panel is operational.
(Continued)						



U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 23-21

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
23 COMMUNICATIONS						
73-01 Cabin Inter-communication Data System (CIDS) (Cont'd)						
1) DEU A (Cont'd)						
e) Main Deck Cargo Loudspeaker and Indicator Box(LIB)						
i) A330-200F without MOD 200261 (No access to Main Deck Cargo during flight)		C	8	0	(0)One or more may be inoperative.	
ii) A330-200F with MOD 200261 (Access to Main Deck Cargo during flight)		C	12	11	(0)One may be inoperative provided that all MDCC Leave Compartment Signs are operative.	
		C	12	0	(0)One or more may be inoperative provided that access to the MDCC during flight is not authorized.	
(Continued)						

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14

PAGE:

DATE: 05/31/2013

23-22

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
23 COMMUNICATIONS						
73-01 Cabin Inter-communication Data System (CIDS) (Cont'd)						
2) DEU B						
	a) Cabin Attendant Stations	C	-	-	(0) One or more at stations designated as not required by 14 CFR may be inoperative provided alternate procedures are developed and used.	
***	b) Lower Deck Cabin Crew Rest Compartment Attendant Indication Panel (AIP)	D	1	0		
***	c) Lower Deck Facilities Cabin Attendant Station	C	-	1	One or more may be inoperative provided at least one handset is operative.	
	3) Cabin Assignment Module (CAM)	C	1	0		
(Continued)						

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 23-23

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED			3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
23 COMMUNICATIONS							
73-01 Cabin Inter-communication Data System (CIDS) (Cont'd)							
***	4) Emergency Cockpit Alerting System (ECAS)	C	-	0		(O)May be inoperative provided alternate procedures are established and used.	
		D	-	0		May be inoperative provided operations or procedures do not require its use.	
	5) Attendant Indication Panels (AIP) (A330-200, A330-300)	C	-	0		May be inoperative at non required cabin attendant stations.	
		C	-	0		(O)May be inoperative at required cabin attendant stations provided: a) Corresponding Area Call Panel operates normally, b) Passenger address and cabin interphone at affected station operate normally, and c) Alternate procedures are established and used.	
	(A330-200F)	C	-	0		May be inoperative.	
(Continued)							

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 23-24

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
23 COMMUNICATIONS					
73-01 Cabin Inter-communication Data System (CIDS) (Cont'd)					
6) Area Call Panel (ACP) (A330-200, A330-300)	C	-	0		May be inoperative at non required cabin attendant stations.
	C	-	0		(O)May be inoperative at required cabin attendant stations provided: a) Corresponding Attendant Indication Panel operates normally, b) Passenger address and cabin interphone at affected station operate normally, and c) Alternate procedures are established and used.

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 23-25

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
23 COMMUNICATIONS					
73-02	Forward/Flight Attendant Panel (FAP)	C	-	0	(M)(O)May be inoperative provided: a) Associated FAP functions are considered inoperative, and b) Alternate procedures are established and used.  NOTE: EMER Pb must always be operative.
	1) Cabin Lighting Control on FAP	C	-	0	(O)May be inoperative provided alternate procedures are established and used.
***	2) Prerecorded Announcement and Music Reproducer Control on FAP	C	1	0	(O)May be inoperative provided alternate procedures are established and used.
***	3) Cabin Ready on FAP	C	-	0	(O)May be inoperative provided alternate procedures are established and used.
***	4) EVAC CMD on FAP	C	-	0	(O)May be inoperative provided alternate procedures are established and used.
		D	1	0	May be inoperative provided procedures do not require its use.
	5) Slide Bottle Pressure Indication on FAP	C	8	0	(O)May be inoperative provided alternate procedures are used to verify affected slide bottle pressure prior to first departure of each day.  (Continued)

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14  
DATE: 05/31/2013

PAGE:  
23-26

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
23 COMMUNICATIONS						
73-02 Forward/Flight Attendant Panel (FAP) (Cont'd)						
6) Door Bottle Pressure Indication on FAP	C	8	0	0	(O)May be inoperative provided bottle pressure at each affected door is verified prior to first departure of each day.	
7) Other Indications on FAP	D	-	-	0		
8) Cabin Items Indicated by FAP Related Class 1 Messages (Not listed in MMEL)		-	-		CIDS/FAP messages displayed without associated Cockpit Effect that are not associated with an MMEL item do not require MEL entry.	
81-01 Radio Management Panels (RMP)						
1) RMP 1						
a) Radio Comm. Selection Keys	C	6	5	5	One key may be inoperative except HF 1 key (if required) and VHF 1 key.	
2) RMP 2 and 3	C	2	1	1		
82-01 Wheelchair Accessible Lavatory						
Deleted Rev 14						

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16  
 DATE: 07/01/2014

PAGE:  
 24-1

1. SYSTEM & SEQUENCE NUMBERS	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
24 ELECTRICAL POWER  22-01 AC Main Generation B (IDG, GCU, Line Contactor)	2	1	(M)(O)Except for ER operations beyond 120 minutes, one may be inoperative provided: a) APU generator operates normally and is used throughout the flight, b) All busses can be powered, c) Indications for the remaining AC main generation and AC auxiliary generation operate normally, d) There is no ELEC IDG 1(2) OIL SYS FAULT caution associated with IDG of the operative AC main generation displayed on ECAM E/WD, e) There is no FUEL APU AFT PUMP FAULT caution displayed on ECAM E/WD, f) Automatic switching of essential electrical network power supply from AC BUS 1 to AC BUS 2 is checked operative daily when AC main generation 2 is inoperative, g) APU aft fuel pump shedding in land recovery configuration is checked operative weekly, and h) Operator ensures that APU oil quantity is adequate for the intended flight.

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 16  
DATE: 07/01/2014

PAGE:  
24-2

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			2.	3. NUMBER REQUIRED FOR DISPATCH	
24 ELECTRICAL POWER					
22-02	ELEC IDG 1(2) OIL SYS FAULT Caution on ECAM EWD	C	2	1	(M)One may be displayed provided: a) Associated IDG oil circuit is verified to be operational prior to each departure, and b) Sight glass is verified to show correct oil level on associated IDG.
		B	2	1	(M)(O)One may be displayed provided: a) Associated IDG is disconnected, b) Associated IDG is completely drained in the case of evidence of oil leakage, and c) Associated AC main generation is considered inoperative.
23-01	AC Auxiliary Generation (APU Generator, GCU, Line Contactor)	C	1	0	Except for ER operations beyond 120 minutes, may be inoperative provided the APU is not used.
		C	1	0	(M)Except for ER operations beyond 120 minutes, may be inoperative provided: a) The failure is not mechanically related, and b) The APU GEN Pb Sw is selected OFF.
		C	1	0	(M)Except for ER operations beyond 120 minutes, may be inoperative provided the AC Auxiliary Generation is deactivated or removed.

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 16  
DATE: 07/01/2014

PAGE:  
24-3

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3.	NUMBER REQUIRED FOR DISPATCH	
24	ELECTRICAL POWER				
25-01	AC ESS FEED Control				
	1) Automatic Transfer to AC BUS 2	C	1	0	(O)May be inoperative provided: a) AC ESS FEED pb sw is selected NORM, and b) The three DC tie contactors are operative.
	2) Manual Transfer to AC BUS 2 (ALTN Function)	C	1	0	(O)Except for ER operations, may be inoperative provided: a) AC ESS FEED pb sw is selected NORM, and b) The three DC tie contactors are operative.
26-01	Galley Supply System				
	1) Automatic	C	1	0	May be inoperative provided GALLEY Pb Sw and GALLEY FAULT light in the cockpit operate normally.
	2) Manual	C	1	0	(M)(O)May be inoperative provided commercial load system operates normally.
	3) Automatic and Manual	C	2	0	(M)May be inoperative provided all galley loads are disconnected.
26-02	COMMERCIAL Supply System	C	1	0	

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16  
 DATE: 07/01/2014

PAGE:  
 24-4

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			2.	3. NUMBER REQUIRED FOR DISPATCH	
24 ELECTRICAL POWER					
27-01 AC Generation Monitoring and Indicating System					
1) IDG					
	a) FAULT Lights	C	2	1	One may be inoperative provided associated IDG indications are available on ECAM ELEC AC page.
	b) OFF Light	C	2	0	
2) GEN/APU GEN					
	a) FAULT Light	C	3	1	One GEN and/or APU GEN FAULT light may be inoperative provided associated generator indications are available on ECAM ELEC AC page.
	b) OFF Light	C	3	0	
3) AC ESS FEED					
	a) FAULT Light	C	1	0	May be inoperative provided AC ESS bus indication is available on ECAM ELEC AC page.
	b) ALTN Light	C	1	0	May be inoperative provided AC ESS bus indication is available on ECAM ELEC AC page.
	4) BUS TIE OFF Light	C	1	0	
(Continued)					

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16  
 DATE: 07/01/2014

PAGE:  
 24-5

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3.	NUMBER REQUIRED FOR DISPATCH	
24 ELECTRICAL POWER					
27-01 AC Generation Monitoring and Indicating System (Cont'd)					
5) GALLEY					
a) FAULT Light	C	1	0		(M)May be inoperative provided: a) AC load indication for each generator channel is available on ECAM ELEC AC page, and b) Automatic shedding operates normally.
b) OFF Light	C	1	0		
6) EMER GEN FAULT Light	C	1	0		
7) COMMERCIAL OFF Light	C	1	0		
8) LAND RECOVERY ON Light	C	1	0		
9) Indications on ECAM ELEC AC Page	C	-	-		(M)One or more indications related to one AC main generation may be inoperative provided: a) ELEC GEN 1(2) FAULT caution associated with affected AC main generation operates normally, and b) Automatic shedding operates normally.
a) APU GEN Parameters	C	-	0		Except for ER operations beyond 120 minutes, may be inoperative provided both AC main generations are operative.

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 16  
DATE: 07/01/2014

PAGE:  
24-6

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
24	ELECTRICAL POWER				
27-02	Warning and Caution on ECAM E/WD				
	1) ELEC IDG DISCONNECTED	C	2	1	(O)One may be inoperative (confirmed false indication) as displayed on ECAM E/WD.
		B	2	1	May be displayed on ECAM E/WD provided the associated AC main generation is considered inoperative.
29-01	Electrical Contactor Management Unit (ECMU)				
	1) Indicating Functions	C	2	1	(M)One may be inoperative provided the AC and DC transfer functions are verified to operate normally.
32-01	DC Main Generation (APU TR)	C	1	0	(O)Except for ER operations beyond 120 minutes, may be inoperative.  NOTE: The APU is considered inoperative for in-flight start.  Deleted, Rev 16.
35-01	DC Bus Tie Contactor 1PC2 (DC BUS 2 - DC BATT BUS)	C	1	0	May be inoperative in open position.

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 16  
DATE: 07/01/2014

PAGE:  
24-7

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3.	NUMBER REQUIRED FOR DISPATCH	
24 ELECTRICAL POWER					
37-01 DC Generation Monitoring and Indicating					
1) BAT					
	a) FAULT Lights	C	3	0	May be inoperative provided ELEC DC ECAM indication operates normally.
	b) OFF Lights	C	3	0	
	2) Indications on ECAM ELEC DC Page	C	-	0	
38-01 Battery DC Generation					
	1) Battery	C	3	2	(O)APU battery may be inoperative provided APU starting using AC power is verified to operate normally.
		C	3	2	(O)APU battery may be inoperative provided APU is not used.
	2) Battery Charge Limiter (BCL)	C	3	2	(O)APU battery charge limiter may be inoperative provided APU battery is not used.
	3) Battery Voltage Indication	C	3	0	May be inoperative provided associated voltage indication is available on ECAM <u>ELEC DC</u> Page.

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 16  
DATE: 07/01/2014

PAGE:  
24-8

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
24 ELECTRICAL POWER					
41-01	AC External Power Control				
	1) Ground Power Control Unit (GPCU)	C	1	0	May be inoperative provided external power is not used.
	2) Receptacles	C	2	1	(M)May be inoperative provided affected receptacle is not used.
		C	2	0	(M)May be inoperative provided external power is not used.
41-02	EXT A Pb Sw				
	1) AVAIL Light	C	1	0	(O)May be inoperative provided alternate procedures are established and used.
	2) ON Light	C	1	0	
41-03	EXT B Pb Sw				
	1) AVAIL Light	C	1	0	(O)May be inoperative provided alternate procedures are established and used.
	2) AUTO Light	C	1	0	
41-04	External Power NOT IN USE and AVAIL Panel Lights	C	4	0	(O)May be inoperative provided alternate procedures are established and used.
53-01	Circuit Breaker Management Unit (CBMU)	C	1	0	(M)May be inoperative provided alternate procedures are used to verify that no circuit breaker is tripped in electrical compartment bay (main and emergency power centers).

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 16  
DATE: 07/01/2014

PAGE:  
25-1

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3.	NUMBER REQUIRED FOR DISPATCH	
25 EQUIPMENT/FURNISHINGS					
11-01	Pilot Seat Adjustments				
1)	Electrical Adjustments	C	2	0	(M)May be inoperative provided: a) Horizontal and vertical mechanical adjustments operate normally, and b) Associated electrical control is deactivated.
2)	Vertical Mechanical Adjustment	C	2	0	May be inoperative provided vertical electrical adjustment operates normally.
3)	Lumbar	C	2	0	May be inoperative provided seat contour is satisfactory to individual/crewmember requirements.
4)	Recline Systems	A	2	0	(M)May be inoperative provided: a) Seat is secured in an upright position acceptable to the affected crewmember, and b) Repairs are made within two flight days.
11-03	CAPT and F/O Outboard Armrest Controls				
1)	Height Control	C	2	0	May be inoperative provided setting is acceptable to crewmember(s).
2)	Pitch (Tilt) Control	C	2	0	May be inoperative provided setting is acceptable to crewmember(s).
3)	Armrest Memory Position Display	C	2	0	

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 16  
DATE: 07/01/2014

PAGE:  
25-2

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
25 EQUIPMENT/FURNISHINGS			3. NUMBER REQUIRED FOR DISPATCH		
11-04	CAPT and F/O Inboard Armrest Vertical Adjustment Controls	C	2	0	May be inoperative or missing.
11-05	Pilot Seat Headrest	C	2	0	
11-06	Observer Seat(s)				
	1) Primary Observer Seat (Including associated equipment)	A	1	0	May be inoperative provided: a) A passenger seat in the passenger cabin is made available to an FAA inspector for the performance of official duties, and b) Repairs are made within two flight days.
		A	1	0	May be inoperative provided: a) Second observer's seat is available and acceptable to an FAA inspector for the performance of official duties, and b) Repairs are made within two flight days.
		A	1	0	May be inoperative provided: a) Required minimum safety equipment (safety belt and oxygen) is available, b) Seat is acceptable to an FAA inspector for the performance of official duties, and c) Repairs are made within two flight days.
(Continued)					

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 16  
DATE: 07/01/2014

PAGE:  
25-3

SYSTEM & SEQUENCE NUMBERS	1. ITEM	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
25 EQUIPMENT/FURNISHINGS				
11-06	Observer Seat(s) (Cont'd)  1) Primary Observer Seat (Including associated equipment) (Cont'd)			<p>NOTE 1: These provisos are intended to provide for occupancy of the above seats by an FAA inspector when the minimum safety equipment (oxygen and safety belt) is functional and the inspector determines the conditions to be acceptable.</p> <p>NOTE 2: The pilot-in-command will determine if the minimum safety equipment is functional for other persons authorized to occupy any observer seat(s).</p>
***	2) Additional Observer Seat(s) (Including associated equipment)	D	- 0	<p>NOTE: The Pilot-in-Command will determine if the minimum safety equipment is functional for other persons authorized to occupy any observer seat(s).</p>

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16  
 DATE: 07/01/2014

PAGE:  
 25-4

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
25 EQUIPMENT/FURNISHINGS						
13-01	Captain and First Officer Sliding Tables					
	1) Sliding Tables	D	2	0		(M)May be inoperative in stowed position or removed.
	2) Table Tilt Function	D	2	0		May be inoperative provided associated table can be stowed.
13-02	Captain and First Officer Retractable Foot Rests	C	4	0		(M)May be inoperative in retracted position or removed.
15-01	Crew Foot Warmers	D	2	0		
21-01	Passenger/Super-numerary Seat(s)					
	1) A330-200, A330-300	D	-	-		May be inoperative provided: a) Seat does not block an Emergency Exit, b) Seat does not restrict any passenger from access to the main aircraft aisle, and c) The affected seat(s) are blocked and placarded "DO NOT OCCUPY".  NOTE 1: A seat with an inoperative seat belt is considered inoperative.  NOTE 2: Inoperative seats do not affect the required number of Flight Attendants.  NOTE 3: Affected seat(s) may include the seat(s) behind and/or adjacent outboard seats.
(Continued)						

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16  
 DATE: 07/01/2014

PAGE:  
 25-5

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
25 EQUIPMENT/FURNISHINGS						
21-01 Passenger/Super-numerary Seat(s) (Cont'd)						
2) A330-200F	D	-	-	0	(M)One or more may be inoperative or not used provided the affected seat is secured in its stowed position or removed.	NOTE: A seat position with an inoperative or missing seatbelt or harness is considered inoperative.
3) Recline Mechanism	D	-	-	-	(M)May be inoperative and seat occupied provided seatback is secured in the full upright position.	May be inoperative and seat occupied provided seat back is immovable in full upright position.
4) Underseat Baggage Restraining Bars	C	-	-	-	(O)May be inoperative provided: a) Baggage is not stowed under seat with inoperative restraining bar, b) Associated seat is placarded "DO NOT STOW BAGGAGE UNDER THIS SEAT", and c) Procedures are established to alert Cabin Crew of inoperative restraining bar.	(Continued)

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 16  
DATE: 07/01/2014

PAGE:  
25-6

SYSTEM & SEQUENCE NUMBERS	1. ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
25 EQUIPMENT/FURNISHINGS					
21-01	Passenger/Super-numerary Seat(s) (Cont'd)				
	5) Armrest				
	a) Armrest with Recline Mechanism	D	-	-	(M)May be inoperative or missing and seat occupied provided: a) Armrest does not block an Emergency Exit, b) Armrest does not restrict any passenger from access to the main aircraft aisle, and c) If armrest is missing, seat is secured in the upright position.
	b) Armrest without Recline Mechanism	D	-	-	May be inoperative or missing and seat occupied provided: a) Armrest does not block an Emergency Exit, and b) Armrest does not restrict any passenger from access to the main aircraft aisle.
	6) Takeoff, Taxi, and Landing (TTL) Light (With STC No. ST11686SE-T)	C	-	-	(O)May be inoperative and seat occupied provided alternate procedures are established and used.



AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16  
 DATE: 07/01/2014

PAGE:  
 25-8

1. SYSTEM & SEQUENCE NUMBERS	ITEM	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
25 EQUIPMENT/FURNISHINGS  22-01 Flight Attendant Seat Assembly (Single or Dual Position) (Cont'd)  1) Required Flight Attendant Seats (A330-200, A330-300) (Cont'd)				<p>NOTE 1: An automatic folding seat that will not stow automatically is considered inoperative.</p> <p>NOTE 2: A seat position with an inoperative or missing restraint system is considered inoperative.</p> <p>NOTE 3: Individual operators, when operating with inoperative seats, will consider the locations and combinations of seats to ensure that the proximity to exits and distribution requirements of the applicable 14 CFR are met.</p> <p>NOTE 4: If one side of a dual seat assembly is inoperative and a flight attendant is displaced to the adjacent seat, the adjacent seat must operate normally.</p> <p>(Continued)</p>

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16  
 DATE: 07/01/2014

PAGE:  
 25-9

SYSTEM & SEQUENCE NUMBERS	1. ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
25 EQUIPMENT/FURNISHINGS					
22-01 Flight Attendant Seat Assembly (Single or Dual Position) (Cont'd)					
2) Excess Flight Attendant Seats (A330-200, A330-300)	C	-	-	-	(M)May be inoperative provided: a) Affected seat position or seat assembly is not occupied, and b) Folding type seat stows automatically or is secured in the retracted position.  NOTE 1: An automatic folding seat that will not stow automatically is considered inoperative.  NOTE 2: A seat position with an inoperative or missing restraint system is considered inoperative.

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 16  
DATE: 07/01/2014

PAGE:  
25-10

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
25 EQUIPMENT/FURNISHINGS						
22-03 Non-Essential Equipment & Furnishings (NEF)		-	0		May be inoperative, damaged or missing provided that the item(s) is deferred in accordance with the operator's NEF deferral program. The NEF program, procedures and processes are outlined in the operator's (insert name) Manual. (M) and (O) procedures, if required, must be available to the flight crew and included in the operator's appropriate document.  NOTE: Exterior lavatory door ashtrays are not considered NEF items.	
22-05 Exterior Lavatory Door Ashtrays						
1) Airplanes with more than one exterior lavatory door ashtray installed	A	-	-		Up to and including 50 percent may be missing or inoperative for 10 days.	
	A	-	-		More than 50 percent may be missing or inoperative for 3 calendar days.	
					NOTE: Crew lavatories are included in the total aircraft exterior lavatory door ashtray count.	
2) Airplanes with only one exterior lavatory door ashtray installed	A	1	0		May be missing or inoperative for 10 calendar days.	

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 16  
DATE: 07/01/2014

PAGE:  
25-11

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
25 EQUIPMENT/FURNISHINGS					
22-06	Storage Bins/Cabin, Galley and Lavatory Storage Compartments/ Closets	C	-	-	(M)May be inoperative provided: <ul style="list-style-type: none"> <li>a) Procedures are established to secure the affected bin, compartment or closet in the closed position,</li> <li>b) Affected bin, compartment or closet is prominently placarded DO NOT USE,</li> <li>c) Any emergency equipment located in affected compartment is considered inoperative, and</li> <li>d) Affected bin, compartment or closet is not used for storage of any items except for those permanently affixed.</li> </ul>
Note: For overhead bins, if no partitions are installed, the entire overhead bin is considered inoperative.					
(Continued)					

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 16  
DATE: 07/01/2014

PAGE:  
25-12

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
25 EQUIPMENT/FURNISHINGS						
22-06	Storage Bins/Cabin, Galley and Lavatory Storage Compartments/ Closets (Cont'd)	C	-	-	(M)(O)May be inoperative provided: a) For non-retractable doors, affected door is removed, b) For retractable doors, affected door is removed or secured in the retracted (fully open) position, c) Affected bin, compartment or closet is not used for storage of any items, except those permanently affixed, d) Affected bin, compartment or closet is prominently placarded DO NOT USE, e) Procedures are established and used to alert crew members and passengers of inoperative bins, compartments or closets and f) Passengers are briefed that affected bin, compartment or closet is not used.	
Note 1: For overhead bins, if no partitions are installed, the entire overhead bin is considered inoperative.						
Note 2: Any emergency equipment located in affected bin, compartment or closet (permanently affixed) is available for use.						
***	1) Storage Compartment Key Locks	D	-	0	(M)May be inoperative in the unlocked position provided doors can be secured by other means.	
27-01	Heating Function of Heated Floor Panels (Passenger/Crew Doors, Emergency Exits, and Galley Areas)	D	-	0	(M)May be inoperative provided the heating elements of the affected area heated floor panel are deactivated.	

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16  
 DATE: 07/01/2014

PAGE:  
 25-13

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
25 EQUIPMENT/FURNISHINGS						
45-01	Galley/Cabin Waste Receptacles Access Doors/Covers	C	-	-		(M)(O)May be inoperative provided: a) The container is empty and the access is secured to prevent waste introduction into the compartment, and b) Procedures are established to ensure that sufficient galley/cabin waste receptacles are available to accommodate all waste that may be generated on a flight.
45-02	Lavatory Waste Receptacle Access Doors/ Covers/Flapper Doors	C	-	-		(M)May be inoperative provided: a) Associated waste container is empty, b) Affected receptacle access door/cover/flapper door is secured to prevent waste introduction into the receptacle, c) Lavatory is used only by crewmembers, and d) Lavatory door is locked closed and placarded "INOPERATIVE - DO NOT ENTER".
NOTE: These provisos are not intended to prohibit lavatory use or inspections by crewmembers.						

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16  
 DATE: 07/01/2014

PAGE:  
 25-14

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
25 EQUIPMENT/FURNISHINGS						
50-01 Blow in/out Panels in Cargo Compartments	C	-	-	-	May be damaged or missing provided procedures are established and used to ensure the associated compartment remains empty, or is verified to contain only empty cargo handling equipment, ballast (ballast may be loaded in ULDs), and/or Fly Away Kits.	NOTE: Operator MELs must define which items are approved for inclusion in the Fly Away Kits, and which materials can be used as ballast.
50-02 Lining Panels in Cargo Compartments	C	-	-	-	May be damaged provided procedures are established and used to ensure the associated compartment remains empty, or is verified to contain only empty cargo handling equipment, ballast (ballast may be loaded in ULDs), and/or Fly Away Kits.	NOTE: Operator MELs must define which items are approved for inclusion in the Fly Away Kits, and which materials can be used as ballast.
	C	-	-	-	May be missing provided associated cargo compartment remains empty.	

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16  
 DATE: 07/01/2014

PAGE:  
 25-15

SYSTEM & SEQUENCE NUMBERS	1. ITEM	1.	2.	NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
25 EQUIPMENT/FURNISHINGS						
51-01	Lower Deck Cargo Loading System (CLS)					
	1) Cargo Restraint Components	A	-	-		(M)May be inoperative or missing provided: a) Acceptable cargo loading limits from an approved source, ie. an Approved Cargo Loading Manual. or Weight and Balance Document are observed, and b) Repairs are made prior to the completion of the next heavy maintenance visit.
		C	-	-		May be inoperative, or missing provided cargo compartment remains empty.
	2) Loading Systems	C	-	0		NOTE: Any part of the CLS that operates normally may be used.

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16  
 DATE: 07/01/2014

PAGE:  
 25-16

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
25 EQUIPMENT/FURNISHINGS						
51-02 Main Deck Cargo Loading Systems						
	1) Cargo Restraint Components	A	-	-	(M)May be inoperative or missing provided:	a) Acceptable cargo loading limits from an approved source, i.e. an approved cargo loading manual or weight and balance document, are observed, and b) Repairs are made prior to the completion of the next heavy maintenance visit.
		C	-	-	May be inoperative or missing provided the main deck cargo compartment remains empty.	
	2) Cargo Loading System	C	-	-	NOTE: Any part of the cargo loading system that operates normally may be used.	
	55-01 Main Deck Cargo Compartment Door and Sidewall Lining	C	-	-	May be damaged provided ULDs are utilized to contain all cargo loaded in or passing through the affected loading zone(s).	
		C	-	-	May be missing provided main deck cargo compartment remains empty.	

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16  
 DATE: 07/01/2014

PAGE:  
 25-17

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
25 EQUIPMENT/FURNISHINGS			3. NUMBER REQUIRED FOR DISPATCH		
55-02	Main Deck Cargo Compartment Window Protection Cover	C	4	0	One or more may be damaged or missing provided main deck cargo compartment is empty or does not contain flammable or combustible materials.
55-03	Partition Lining at the Aft Main Deck Cargo Compartment	C	1	0	May be damaged or missing provided main deck cargo compartment remains empty.
60-01	SLIDE Indications on ECAM DOOR/OXY Page				
1	A330-200, A330-300	C	8	0	(O)May be inoperative provided alternate procedures are established and used.
2	A330-200F	C	2	0	(O)May be inoperative provided alternate procedures are established and used.
60-07	"Fasten Seat Belt While Seated" Signs or Placards	C	-	-	One or more signs or placards may be illegible or missing provided a legible sign or placard is visible from each occupied passenger seat.
62-01	Cabin Escape Facilities				Deleted, Rev. 9. (Moved to item 23-73-02 5))

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16  
 DATE: 07/01/2014

PAGE:  
 25-18

SYSTEM & SEQUENCE NUMBERS	1. ITEM	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
25 EQUIPMENT/FURNISHINGS				
65-01 Miscellaneous Emergency Equipment				
	1) Megaphones	D -	-	Any in excess of those required by 14 CFR may be inoperative or missing provided: a) Inoperative megaphone is removed from passenger cabin, b) Associated placard is removed or obscured, and c) Required distribution is maintained.
	D	0		(O)May be missing or inoperative provided: a) No passengers are carried, b) A maximum of 19 persons are carried as authorized by 14 CFR for non-passenger carrying operation, and c) Alternate procedures are established and used.  NOTE: Not required for all-cargo operations.
	2) Flashlight and Holders (Flight Deck or Cabin)	C -	-	May be inoperative or missing provided crewmember assigned to associated seat has a flashlight with equivalent characteristics readily available.
	D	-	0	(O)May be missing or inoperative provided: a) No passengers are carried, b) A maximum of 19 persons are carried as authorized by 14 CFR for non-passenger carrying operation, and c) Alternate procedures are established and used.
(Continued)				

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16  
 DATE: 07/01/2014

PAGE:  
 25-19

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
25 EQUIPMENT/FURNISHINGS						
65-01 Miscellaneous Emergency Equipment (Cont'd)						
*** 3) Emergency Locator Transmitter						
	a) Survival Type ELTs	D	-	-	Any in excess of those required by 14 CFR may be inoperative or missing.	
	b) Fixed ELTs	A	-	0	(M)May be inoperative provided: a) System is deactivated, and b) Repairs are made within 90 days.	
		A	-	0	May be missing provided repairs are made within 90 days.	
		D	-	-	(M)Any in excess of those required by 14 CFR may be inoperative provided system is deactivated.	
		D	-	-	Any in excess of those required by 14 CFR may be missing.	
	4) First Aid Kit (FAK) and/or Associated Equipment	A	-	-	(O)If more than one is required by 14 CFR, only one of the required first aid kits may be incomplete, missing or inoperative provided: a) FAK is resealed in a manner that will identify it as a unit that cannot be mistaken for a fully serviceable unit, and b) Repairs or replacements are made within 1 flight.	
		D	-	-	Any in excess of those required by 14 CFR may be incomplete, missing or inoperative.	
(Continued)						

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 16  
DATE: 07/01/2014

PAGE:  
25-20

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
25 EQUIPMENT/FURNISHINGS			3. NUMBER REQUIRED FOR DISPATCH		
65-01	Miscellaneous Emergency Equipment (Cont'd)				
5)	Emergency Medical Kit (EMK) and/or Associated Equipment	A	-	0	(O)May be incomplete, missing or inoperative provided: a) EMK is resealed in a manner that will identify it as a unit that cannot be mistaken for a fully serviceable unit, and b) Repairs or replacements are made within 1 flight.
		D	-	-	Any in excess of those required by 14 CFR may be incomplete, missing or inoperative.
6)	Automatic External Defibrillator (AED) and/or Associated Equipment	A	-	0	(O)May be incomplete, missing or inoperative provided: a) AED is resealed in a manner that will identify it as a unit that cannot be mistaken for a fully serviceable unit, and b) Repairs or replacements are made within 1 flight.
		D	-	-	Any in excess of those required by 14 CFR may be incomplete, missing or inoperative.
7)	Crash Axe/ Crow Bar	D	-	-	Any in excess of those required by 14 CFR may be inoperative or missing.
8)	Survival Kit	D	-	-	Any in excess of those required by 14 CFR may be incomplete, missing or inoperative.
***	9) Fireproof Gloves	D	-	0	
66-01	Floatation Equipment (Crew and Passenger)	D	-	-	Any in excess of that required by 14 CFR may be inoperative or missing.

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16  
 DATE: 07/01/2014

PAGE:  
 25-21

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
25 EQUIPMENT/FURNISHINGS			3. NUMBER REQUIRED FOR DISPATCH		
74-01	Flight Crew *** Rest Compartment	D	1	0	May be inoperative provided procedures do not require its use and the flight crew rest compartment is placarded inoperative.
	1) Bed Bunks	D	-	0	May be inoperative provided operations or procedures do not require its use.
	2) Door	D	1	0	(M)May be inoperative provided the door is deactivated closed.
74-02	Flight Crew Rest *** Compartment (With STC No. ST02193SE)				
	1) Bed Bunk	D	1	0	May be inoperative provided procedures do not require its use and the flight crew rest compartment is placarded inoperative.
	2) Curtain	D	1	0	(M)May be inoperative provided the curtain is removed or stowed open and the flight crew rest compartment is placarded inoperative.
75-01	Lower Deck Cabin *** Crew Rest Compartment (A330-200, A330-300)	D	1	0	May be inoperative provided procedures do not require its use and the flight crew rest compartment is placarded inoperative.
	1) Bed Bunks	D	-	0	May be inoperative provided operations or procedures do not require its use.
	2) Blow In/Out Panel	D	1	0	May be damaged or missing provided the affected compartment is locked closed and not used.
	3) Door	D	1	0	(M)May be inoperative provided the door is deactivated closed.

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16  
 DATE: 07/01/2014

PAGE:  
 25-22

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
25 EQUIPMENT/FURNISHINGS			3. NUMBER REQUIRED FOR DISPATCH		
75-02	Bulk Crew Rest Compartment (With STC No. ST11686SE-T)	D	1	0	(M)(O)May be inoperative provided: a) The bulk crew rest compartment is locked closed and not used, and b) Procedures do not require its use.
	1) Bed Bunk	D	8	0	(M)(O)May be inoperative provided: a) The bulk crew rest compartment is locked closed and not used, and b) Procedures do not require its use.
		D	8	-	(M)(O)Individual bed bunk(s) may be inoperative provided: a) The associated bed bunk(s)is placarded DO NOT USE, and b) Procedures do not require its use.
	2) Seat	C	2	0	(M)May be inoperative provided the seat is placarded DO NOT USE.
		D	2	0	(M)(O)May be inoperative provided: a) The bulk crew rest compartment is locked closed and not used, and b) Procedures do not require its use.
	3) Bench	C	1	0	(M)May be inoperative provided the seat is placarded DO NOT USE.
		D	2	0	(M)(O)May be inoperative provided: a) The bulk crew rest compartment is locked closed and not used, and b) Procedures do not require its use.
(Continued)					

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16  
 DATE: 07/01/2014

PAGE:  
 25-23

SYSTEM & SEQUENCE NUMBERS	1. ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
25 EQUIPMENT/FURNISHINGS					
75-02	Bulk Crew Rest Compartment (With STC No. ST11686SE-T) (Cont'd)				
	4) Vestibule Door/Lock	D	1	0	(M)(O)May be inoperative provided: a) The bulk crew rest compartment is locked closed and not used, and b) Procedures do not require its use.
	5) Entry Hatch	D	1	0	(M)(O)May be inoperative provided: a) The bulk crew rest compartment is locked closed and not used, and b) Procedures do not require its use.
	6) Escape Hatch	D	1	0	(M)(O)May be inoperative provided: a) The escape hatch is secured closed, b) The bulk crew rest compartment is locked closed and not used, and c) Procedures do not require its use.
76-01	Wheelchair Accessible Lavatory				Deleted Rev 14

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14  
DATE: 05/31/2013

PAGE:  
26-1

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
26 FIRE PROTECTION					
01-04	Passenger Entertainment Overhead Panel				
***	1) BULK AVNCS pb- sw OFF Light	D	1	0	
***	2) BULK AVNCS pb- sw SMOKE Light	D	1	0	
***	3) IFEC pb-sw OFF Light	D	1	0	
***	4) IFEC pb-sw SMOKE Light	D	1	0	
***	5) PAX BBAND pb- sw OFF Light	D	1	0	
***	6) PAX BBAND pb- sw SMOKE Light	D	1	0	
***	7) PAX SYS pb-sw OFF Light	D	1	0	
***	8) PAX SYS pb-sw SMOKE Light	D	1	0	
***	9) VCC SYS pb-sw OFF Light	D	1	0	
***	10) VCC SYS pb-sw SMOKE Light	D	1	0	
12-01	Engine Fire Detection System				
	1) Loops	C	4	2	Except for ER operations beyond 120 minutes, one on each engine may be inoperative provided engine fire test is performed before each departure.
12-02	FIRE Light On ENG MASTER Panel	C	2	0	

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14  
DATE: 05/31/2013

PAGE:  
26-2

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
26 FIRE PROTECTION					
12-03	FIRE Light in ENG FIRE/PUSH Pb Sw				
	1) Bulbs/LEDs	C	16	8	Four bulbs/LEDs in each push button switch may be inoperative.
13-01	APU Fire Detection System				
	1) Loops	C	2	1	Except for ER operations beyond 120 minutes, one may be inoperative provided APU fire test is performed before each APU start.
		C	2	0	May be inoperative provided APU is not used.
13-02	FIRE Light in APU FIRE/PUSH Pb Sw				
	1) Bulbs/LEDs	C	8	4	Four bulbs/LEDs may be inoperative.
		C	8	0	May be inoperative provided APU is not used.
13-03	APU Fire Detection Unit	C	1	0	May be inoperative provided APU is not used.

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 26-3

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
26 FIRE PROTECTION					
16-01	Smoke Detector System in Lower Deck FWD Cargo Compartment	C	1	0	(O)May be inoperative provided procedures are established and used to ensure the associated compartment remains empty, or is verified to contain only empty cargo handling equipment, ballast (ballast may be loaded in ULDs), and/or Fly Away Kits.  NOTE 1: Operator MELs must define which items are approved for inclusion in the Fly Away Kits, and which materials can be used as ballast.  NOTE 2: Failure of a single detector in each cavity is indicated by a MAINTENANCE STATUS message.
16-02	Smoke Detector System in Lower Deck AFT and BULK Cargo Compartments	C	1	0	(O)May be inoperative provided procedures are established and used to ensure the both compartments remain empty, or are verified to contain only empty cargo handling equipment, ballast (ballast may be loaded in ULDs), and/or Fly Away Kits.  NOTE 1: Operator MELs must define which items are approved for inclusion in the Fly Away Kits, and which materials can be used as ballast.  NOTE 2: Failure of a single detector in each cavity is indicated by a MAINTENANCE STATUS message.

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 26-4

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
26 FIRE PROTECTION						
16-03	Smoke Detector System in BULK Cargo Compartment					Deleted, Rev. 9. (Moved to item 26-16-02)
17-01	Lavatory Smoke Detection System					
1) A330-200, A330-300		C	-	-		(M)(O)For each lavatory, the lavatory smoke detection system may be inoperative provided: a) Lavatory waste receptacle is empty, b) Lavatory door is locked closed and placarded "INOPERATIVE - DO NOT ENTER", and c) Lavatory is used only by crewmembers.
2) A330-200F		D	1	0		May be inoperative.  NOTE 1: These provisos are not intended to prohibit lavatory use or inspections by crewmembers.  NOTE 2: Lavatory smoke detection system is not required for all-cargo operations.
18-01 ***	Flight Crew Rest Compartment Smoke Detection System	D	1	0		(O)May be inoperative provided: a) Flight crew rest compartment is locked closed and not used, and b) Procedure is used to periodically check for absence of smoke in flight crew rest compartment.

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14  
DATE: 05/31/2013

PAGE:  
26-5

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
26 FIRE PROTECTION					
18-03 ***	Lower Deck Cabin Crew Rest Compartment Smoke Detection System (A330-200, A330-300)	B	1	0	(M)(O)May be inoperative provided: a) Lower deck cabin crew rest compartment fire extinguishing system is checked operative before each departure, and b) Procedure is used to periodically check for absence of smoke in the lower deck cabin crew rest compartment.
		D	1	0	(O)May be inoperative provided: a) Lower deck cabin crew rest compartment is locked closed and not used, b) Procedure is used to periodically check for absence of smoke in lower deck cabin crew rest compartment, and c) An operative portable fire extinguisher and protective equipment, in excess of those required for the cabin, are carried in the main deck.
18-04 ***	Lower Deck Facilities Smoke Detection System (A330-200, A330-300)	D	1	0	(O)May be inoperative provided: a) Lower deck facility is locked closed and not used, b) Procedure is used to periodically check for absence of smoke in lower deck facility, and c) An operative portable fire extinguisher and protective equipment, in excess of those required for the cabin, are carried in the main deck.

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14  
DATE: 05/31/2013

PAGE:  
26-6

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3.	NUMBER REQUIRED FOR DISPATCH	
26 FIRE PROTECTION					
18-05 ***	Bulk Crew Rest Compartment Smoke Detection System (With STC No. ST11686SE-T)	C	1	0	(M)(O)May be inoperative provided: a) The bulk crew rest compartment is locked closed and not used, and b) Alternate procedures are developed and used.
1)	Bunk Smoke Detectors	C	-	-	(M)(O)May be inoperative provided: a) The associated bed bunk is placarded DO NOT USE, and b) Alternate procedures are developed and used.
2)	Seat Smoke Detectors	C	-	-	(M)(O)May be inoperative provided: a) The associated seat is placarded DO NOT USE, and b) Alternate procedures are developed and used.
3)	Bench Smoke Detectors	C	-	-	May be inoperative.
4)	Vestibule Smoke Detector	C	2	0	May be inoperative.

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14  
DATE: 05/31/2013

PAGE:  
26-7

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
26 FIRE PROTECTION					
18-06 ***	Lower Deck Stowage Smoke Detection System (A330-200, A330-300)	D	1	0	(O)May be inoperative provided lower deck stowage is empty, locked closed and not used.
18-07 ***	Bulk Avionics Compartment Smoke Detection System (A330-200, A330-300)	D	1	0	(M)May be inoperative provided the flight entertainment system is deactivated.
18-08 ***	Video Control Center Smoke Detection System (A330-200, A330-300)	D	-	0	(M)May be inoperative provided the associated Video Control Center is deactivated.
18-09 ***	In Flight Entertainment Center Smoke Detection System (A330-200, A330-300)	D	1	0	(M)May be inoperative provided the In Flight Entertainment Center is deactivated.
18-10	Combined Stowage- Galley Smoke Detection System (A330-200F)	D	1	0	(O)May be inoperative provided: a) The associated stowage is empty, b) The door of associated stowage is locked closed and placarded inoperative, c) The associated stowage is not used for any purpose, and d) A procedure is used to check daily absence of smoke in stowage.
18-11	CAB SMOKE Light (A330-200F)	C	1	0	May be inoperative.

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14  
DATE: 05/31/2013

PAGE:  
26-8

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
26 FIRE PROTECTION					
19-01	Smoke Detector in Main Deck Cargo Compartment (A330-200F)	D	30	0	(O)Both detectors in one or more base plates may be inoperative provided the main deck cargo compartment remains empty or is verified to contain only empty cargo handling equipment, ballast (ballast may be loaded in ULDs), and/or fly away kits.  NOTE 1: Failure of a single detector in each base plate is indicated by a MAINTENANCE message on ECAM STATUS page.  NOTE 2: Operator MELs should define which items are approved for inclusion in the fly away kits and which materials can be used as ballast.
19-02	MD SMOKE Light (A330-200F)	C	1	0	May be inoperative.
21-01	Engine AGENT 1(2) Pb				
	1) DISCH Light	C	4	2	(M)One may be inoperative on each engine provided associated bottle is verified properly charged before first departure of each day.
		A	4	2	(M)Both may be inoperative on one engine provided: a) Associated bottles are verified properly charged before each departure, and b) Repairs are made within one flight day.
	2) SQUIB Light	C	4	0	(M)May be inoperative provided the failure is verified to be in the test circuit only.

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14  
DATE: 05/31/2013

PAGE:  
26-9

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
26 FIRE PROTECTION					
21-02	ENG FIRE TEST	C	1	0	(M)May be inoperative provided verification is made before the first departure of each day that the fault is in test circuit only.
22-01	APU AGENT Pb				
	1) DISCH Light	C	1	0	(M)May be inoperative provided bottle is verified properly charged before first departure of each day.
		C	1	0	May be inoperative provided APU is not used.
	2) SQUIB Light	C	1	0	(M)May be inoperative provided the failure is verified to be in the test circuit only.
		C	1	0	May be inoperative provided APU is not used.
22-02	APU Ground Automatic Fire Extinguisher System	C	1	0	May be inoperative provided APU condition is monitored in the cockpit during all APU ground operations.
22-03	APU FIRE TEST System	C	1	0	(M)May be inoperative provided verification is made before the first departure of each day that the fault is in test circuit only.
		C	1	0	May be inoperative provided APU is not used.
22-04	APU Fire Extinguisher Overpressure Indication (Red Disc)	C	1	0	(M)May be inoperative provided: a) Squib test is used to check squib integrity, and b) Bottle pressure switch is checked operative before the first departure of each day.
		C	1	0	May be inoperative provided APU is not used.

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 26-10

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			2.	3. NUMBER REQUIRED FOR DISPATCH	
26 FIRE PROTECTION					
22-05	APU Fire Bottle Squibs	C	2	1	(M)May be inoperative provided the remaining squib is verified operative before the first flight of each day.
		C	2	0	May be inoperative provided APU is not used.
22-06	APU Fire Extinguisher Bottle	C	1	0	May be inoperative provided APU is not used.
23-01	Lower Deck Cargo Compartment Fire Extinguishing System (FWD/AFT/BULK)				
	1) Bottles	C	2	1	Bottle 2 may be inoperative (and cargo compartments used) provided airplane remains within one hour of a suitable landing airport.
		C	2	0	(O)Bottle 1 or both may be inoperative provided procedures are established and used to ensure all compartments remain empty, or are verified to contain only empty cargo handling equipment, ballast (ballast may be loaded in ULDs), and/or Fly Away Kits.  NOTE: Operator MELs must define which items are approved for inclusion in the Fly Away Kits, and which materials can be used as ballast.
(Continued)					

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 26-11

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
26 FIRE PROTECTION	23-01 Lower Deck Cargo Compartment Fire Extinguishing System (FWD/AFT/BULK) (Cont'd)	C	2	0	(O)Both may be inoperative provided procedures are established and used to ensure the FWD compartment remains empty, or is verified to contain only empty cargo handling equipment, ballast (ballast may be loaded in ULDs), and/or Fly Away Kits.  NOTE 1: Operator MELs must define which items are approved for inclusion in the Fly Away Kits, and which materials can be used as ballast.  NOTE 2: Failure of a single squib in each discharge cartridge is indicated by a MAINTENANCE STATUS message.  (Continued)
2) Squib of FWD	Cargo Bottle 1	C	2	0	

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 26-12

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
26 FIRE PROTECTION					
23-01 Lower Deck Cargo Compartment Fire Extinguishing System (FWD/AFT/BULK) (Cont'd)					
3) Squib of AFT Cargo Bottle 1	C	2	0		<p>(O)Both may be inoperative provided procedures are established and used to ensure the AFT and BULK compartments remain empty, or are verified to contain only empty cargo handling equipment, ballast (ballast may be loaded in ULDs), and/or Fly Away Kits.</p> <p>NOTE 1: Operator MELs must define which items are approved for inclusion in the Fly Away Kits, and which materials can be used as ballast.</p> <p>NOTE 2: Failure of a single squib in each discharge cartridge is indicated by a MAINTENANCE STATUS message.</p>
(Continued)					

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 26-13

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
26 FIRE PROTECTION					
23-01 Lower Deck Cargo Compartment Fire Extinguishing System (FWD/AFT/BULK) (Cont'd)					
4) Squib of FWD Cargo Bottle 2	C	2	0	Both may be inoperative (and FWD cargo compartment used) provided airplane remains within one hour of a suitable landing airport.	
	C	2	0	(O)Both may be inoperative provided procedures are established and used to ensure the FWD compartment remains empty, or is verified to contain only empty cargo handling equipment, ballast (ballast may be loaded in ULDs), and/or Fly Away Kits.	
NOTE 1: Operator MELs must define which items are approved for inclusion in the Fly Away Kits, and which materials can be used as ballast.					
NOTE 2: Failure of a single squib in each discharge cartridge is indicated by a MAINTENANCE STATUS message.					
(Continued)					

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14  
DATE: 05/31/2013

PAGE:  
26-14

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3.	NUMBER REQUIRED FOR DISPATCH	
26 FIRE PROTECTION					
23-01	Lower Deck Cargo Compartment Fire Extinguishing System (FWD/AFT/BULK) (Cont'd)				
	5) Squib of AFT Cargo Bottle 2	C	2	0	Both may be inoperative (and AFT and BULK cargo compartments used) provided airplane remains within one hour of a suitable landing airport.
		C	2	0	(O)Both may be inoperative provided procedures are established and used to ensure the AFT and BULK compartments remain empty, or are verified to contain only empty cargo handling equipment, ballast (ballast may be loaded in ULDs), and/or Fly Away Kits.
					NOTE 1: Operator MELs must define which items are approved for inclusion in the Fly Away Kits, and which materials can be used as ballast.
					NOTE 2: Failure of a single squib in each discharge cartridge is indicated by a MAINTENANCE STATUS message.
23-02	FWD/AFT Cargo BTL 1 DISCH Light	C	1	0	
23-03	FWD/AFT Cargo BTL 2 DISCH Light	C	1	0	
23-05	FWD/AFT Cargo SQUIB Lights	C	2	0	

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 26-15

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
26 FIRE PROTECTION						
23-06	Test on CARGO SMOKE Panel	C	1	0		
24-01	Portable Fire Extinguishers	D	-	-		Any in excess of those required by 14 CFR may be inoperative or missing provided: a) Inoperative fire extinguisher is tagged inoperative, removed from installed location, and placed out of sight so it cannot be mistaken for a functional unit, and b) Required distribution is maintained.
25-01	Lavatory Fire Extinguisher System					
	1) A330-200, A330-300	C	-	-		For each lavatory, the lavatory fire extinguisher system may be inoperative provided lavatory smoke detection system operates normally.
		C	-	-		(M)(O)For each lavatory, the lavatory fire extinguisher system may be inoperative provided: a) Lavatory waste receptacle is empty, b) Lavatory door is locked closed and placarded "INOPERATIVE - DO NOT ENTER", and c) Lavatory is used only by crewmembers.
NOTE 1: These provisos are not intended to prohibit lavatory use or inspections by crewmembers.						
NOTE 2: A lavatory fire extinguisher system is not required for all-cargo operations.						
(Continued)						

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 26-16

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
26 FIRE PROTECTION						
25-01	Lavatory Fire Extinguisher System (Cont'd)					
	2) A330-200F	D	1	0		May be inoperative.
28-01	Lower Deck Cabin Crew Rest Compartment Fire Extinguishing System (A330-200, A330-300)	D	1	0		(O)May be inoperative provided lower deck cabin crew rest compartment smoke detection system operates normally.
		D	1	0		(O)May be inoperative provided lower deck cabin crew rest compartment is locked closed and not used.
28-02	Bulk Crew Rest Compartment Fire Extinguishing System					Deleted, Rev. 9.

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14  
DATE: 05/31/2013

PAGE:  
27-1

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3.	NUMBER REQUIRED FOR DISPATCH	
27 FLIGHT CONTROLS					
14-01	Aileron Servocontrol				
	1) Outboard	C	4	3	(M)One may be inoperative provided it remains mechanically connected and hydraulically supplied (damping function is not affected).
		C	4	2	(M)Both associated with PRIM 3 (left yellow and right green) may be inoperative provided they remain mechanically connected and hydraulically supplied (damping function is not affected).
14-02	Indication on ECAM F/CTL Page				
	1) Aileron Position Indications	C	4	0	(M)May be inoperative provided ability to move affected aileron through each servocontrol is verified visually before each departure.
	2) Aileron Actuator Indications	C	8	0	
21-01	Rudder Pedal Adjustment Systems	C	2	0	(O)CAPT and/or F/O systems may be inoperative provided: a) Rudder pedals can be adjusted to a position which is acceptable to the affected crewmember, and b) Full and unrestricted movement of rudder pedals and brake pedal deflection is possible at both pilot stations.

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14  
DATE: 05/31/2013

PAGE:  
27-2

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			2.	3. NUMBER REQUIRED FOR DISPATCH	
27 FLIGHT CONTROLS					
22-01	Rudder Trim Systems	C	2	1	(M)(O)One may be inoperative provided: a) The other system is verified to operate normally before each departure, and b) Approach minimums do not require its use.
22-02	Manual Trim Reset Function	C	1	0	May be inoperative provided one rudder trim position indication is available.
22-03	Rudder Trim Position Indications	C	2	1	
		B	2	0	(O)May be inoperative provided: a) Rudder trim is verified to operate normally, b) Rudder position is verified at zero before each departure, and c) Rudder pedals are verified in a neutral position.
23-01	Rudder Travel Limiter System (including Rudder and Pedals Travel Limiter Units) (Without Mod. 49144)				
	1) Channels	C	2	1	One may be inoperative provided FCDC 2 and FWC 2 operate normally.

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 27-3

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
27 FLIGHT CONTROLS						
24-01	Indication on ECAM F/CTL Page (With Mod. 49144)		1	0	(M)May be inoperative provided: a) Visual verification of rudder movement is made, and b) The rudder trim position is verified at zero before each departure on either ECAM F/CTL page or the RUD TRIM panel on the pedestal.	
25-01	Indication on ECAM F/CTL Page (Without Mod. 49144)		1	0	(M)May be inoperative provided: a) Visual verification of rudder movement is made, and b) The rudder trim position is verified at zero before each departure on either ECAM F/CTL page or the RUD TRIM panel on the pedestal.	
25-02	Warning and Caution on ECAM E/WD		3	0	(O)May be inoperative provided before each flight, and for each inoperative caution, rudder deflection is checked operative using only the servocontrol associated with each inoperative caution.	

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 27-4

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
27 FLIGHT CONTROLS						
26-01 Yaw Damper System (Without Mod. 49144)	C	2	1	1	(M)Yaw damper system 2 may be inoperative provided: a) The BYDU is verified to operate normally before each departure, and b) Approach minimums do not require its use.	
34-02 Indications on ECAM F/CTL Page						
1) Elevator Position Indications	C	2	0	0	(M)May be inoperative provided a visual verification of affected elevator movement is made before each departure.	
2) Elevator Actuator Indications	C	4	0	0		
40-03 PRIM Pitch Channel						
1) PRIM 1 Pitch Channel	C	1	0	0	(M)May be inoperative provided: a) A verification is performed before each flight to ensure that the EFCS ground report only shows messages of the THS, b) The affected stabilizer actuator electric motor 1 is considered inoperative, and c) PRIM 2 Pitch Channel and PRIM 3 Pitch Channel are operative.	
	C	1	0	0	May be inoperative provided: a) PRIM 1 is considered inoperative, and b) PRIM 2 Pitch Channel and PRIM 3 Pitch Channel are operative.	
(Continued)						

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14  
DATE: 05/31/2013

PAGE:  
27-5

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
27 FLIGHT CONTROLS					
40-03	PRIM Pitch Channel (Cont'd)				
	2) PRIM 2 Pitch Channel	C	1	0	(M)May be inoperative provided: a) A verification is performed before each flight to ensure that the EFCS ground report only shows messages of the THS, b) The affected stabilizer actuator electric motor 2 is considered inoperative, and c) PRIM 1 Pitch Channel and PRIM 3 Pitch Channel are operative.
	3) PRIM 3 Pitch Channel	C	1	0	May be inoperative provided stabilizer actuator electric motor 3 is considered inoperative.
44-01	Stabilizer Actuator Electrical Motors	C	3	2	(M)Except for ER operations, motor 1 may be inoperative provided: a) It is deactivated, and b) Approach minimums do not require its use.
		C	3	2	(M)Motor 2 or 3 may be inoperative provided it is deactivated.
45-01	Indications on ECAM F/CTL Page				
	1) Pitch Trim Position	C	1	0	(O)May be inoperative provided pitch trim handwheel and stabilizer are verified to operate synchronously before each departure.

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14  
DATE: 05/31/2013

PAGE:  
27-6

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
27 FLIGHT CONTROLS					
51-01 Flaps System					
	1) System 1	A	1	0	(M)(O)May be inoperative provided: a) Flaps system 2 operates normally, b) Slats system 2 operates normally, c) Electrical supply to flaps system 1 is inhibited, and d) Repairs are made within nine calendar days.
	2) System 2	A	1	0	(M)May be inoperative provided: a) Electrical supply to flaps system 2 is inhibited, b) Yellow auxiliary hydraulic power (electric pump) operates normally and c) Repairs are made within nine calendar days.
64-01 Spoilers					
		C	12	10	(M)(O)One pair of symmetrical surfaces may be inoperative in retracted position provided AFM performance penalties are applied.
		C	12	8	(M)(O)Two pairs (surfaces 1 and 2) may be inoperative in retracted position provided AFM performance penalties are applied.
64-02 Indications on ECAM F/CTL and WHEEL Pages					
	1) Spoilers/Speedbrake Indications	C	12	0	(M)May be inoperative provided spoilers are verified to move normally before each departure.

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 27-7

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
27 FLIGHT CONTROLS						
81-01 Slats System						
	1) System 2	A	1	0		(M)May be inoperative provided: a) Electrical supply to slats system 2 is inhibited, and b) Repairs are made within nine calendar days.
	92-01 Speedbrake Control System	C	1	0		
	92-02 Ground Spoiler Control System	C	1	0		(O)May be inoperative provided: a) AFM takeoff and landing performance penalties are applied, and b) The AUTO/BRK function is not used.
	92-05 PRIM Side Stick Potentiometers Signals	C	24	-		(M)May be inoperative provided: a) It is verified before each flight that affected PRIM Side Stick Potentiometers Signals are associated with either PRIM 1 or PRIM 3, b) It is verified before each flight that all sidestick priority switch signals associated with the two other PRIM's and both SEC's are verified to operate normally, and c) Associated PRIM is considered inoperative.

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 27-8

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
27 FLIGHT CONTROLS					
92-06 PRIM Side Stick Priority Switch Signals		C	12	-	(M)May be inoperative provided: <ul style="list-style-type: none"> <li>a) It is verified before each flight that affected PRIM Side Stick Priority Switch Signals are associated with either PRIM 1 or PRIM 3,</li> <li>b) It is verified before each flight that all sidestick potentiometer signals associated with the two other PRIM's and both SEC's are verified to operate normally, and</li> <li>c) Associated PRIM is considered inoperative.</li> </ul>

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 27-9

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
27 FLIGHT CONTROLS	93-01 PRIMs	C	1	0	(M)(O)Except for ER operations, may be inoperative provided: a) PRIM 1 pb sw is selected OFF and remains OFF for the entire flight, b) All sidestick transducers associated with both SEC's operate normally, c) All SEC's, SFCC's, LGCIU's, RA's, ADIRS' and PRIM 3 operate normally, d) The sidestick priority function is checked operative on both sides before each departure, e) Stabilizer actuator electrical motors associated with PRIM 2 and PRIM 3 operate normally, f) Elevators controls through operative PRIM's and SEC's are checked operative before each departure, g) The mode valve transducers on the elevators servo-controls are checked operative, h) The second electrical power supply of PRIM 3 is verified to operate normally, i) Performance penalties for one pair of spoilers inoperative are applied and deactivation of affected spoilers is not necessary, and j) Approach minimums do not require its use.
(Continued)					

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 27-10

SYSTEM & SEQUENCE NUMBERS	1. ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
27 FLIGHT CONTROLS	93-01 PRIMs (Cont'd)	2) PRIM 1 (With Mod. 49144)	C 1	0	(M)(O)Except for ER operations, may be inoperative provided: a) PRIM 1 pb sw is selected OFF and remains OFF for the entire flight, b) All sidestick transducers associated with both SEC's operate normally, c) All SEC's, SFCC's, LGCIU's, RA's, ADIRS' and PRIM 3 operate normally, d) The sidestick priority function is checked operative on both sides before each departure, e) Stabilizer actuator electrical motors associated with PRIM 2 and PRIM 3 operate normally, f) Back-up control module and rudder control on SEC 1 are checked operative before each departure, g) All pedals position transducer units associated with PRIM 2, PRIM 3 and SEC 1 are checked operative before each departure, h) Elevators controls through operative PRIM's and SEC's are checked operative before each departure, i) The mode valve transducers on the elevators servo-controls are checked operative, j) Blue and Yellow electric pumps are checked operative, k) The second electrical power supply of PRIM 3 is verified to operate normally,  (Continued)

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 27-11

SYSTEM & SEQUENCE NUMBERS	1. ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
27 FLIGHT CONTROLS					
93-01 PRIMs					
(Cont'd)					
2) PRIM 1 (With					
Mod.49144)					
(Cont'd)					
3) PRIM 1 (With	C	1	1	0	
Mod. 44385/MP					
S13080 and Mod.					
55439/MP S18649					
and Mod.					
55696/MP S18546					
and Without					
Mod. 49144/MP					
S16279)					

(Continued)

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 27-12

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
27 FLIGHT CONTROLS					
93-01 PRIMs					
(Cont'd)					
4) PRIM 1 (With Mod. 49144/MP S16279 and Mod. 53468/MP S18201 and Mod. 55697/MP S18547)	C	1	0	(M)(O)Except for ER operations, may be inoperative provided: a) PRIM 1 pb sw is selected OFF and remains OFF for the entire flight, b) All sidestick transducers associated with both SEC's operate normally, c) All SECs, SFCCs, LGCIUs, RAs, ADIRS and PRIM 3 operate normally, d) The sidestick priority function is checked operative on both sides before each departure, e) Stabilizer actuator electrical motors associated with PRIM 2 and PRIM 3 operate normally, f) Back-up control module and rudder control on SEC 1 are verified operative before each departure, g) All pedals position transducer units associated with PRIM 2, PRIM 3 and SEC 1 are verified operative before each departure, h) Elevators controls through operative PRIMs and SECs are verified operative before each departure, i) Blue and Yellow electric pumps are checked operative, j) The second electrical power supply of PRIM 3 is verified to operate normally, k) Performance penalties for one pair of spoilers inoperative are applied and deactivation of affected spoilers is not necessary, and (Continued)	



U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 27-14

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
27 FLIGHT CONTROLS					
93-01 PRIMS					
(Cont'd)  5) PRIM 1 (With Mod. 49144/MP S16279 and Mod. 200285/MP S19541 and Mod. 55697/MP S18547) (Cont'd)					h) Elevators controls through operative PRIM's and SEC's are verified operative before each departure, i) Blue and Yellow electric pumps are checked operative, j) performance penalties for one pair of spoilers inoperative are applied and deactivation of affected spoilers is not necessary, and k) Approach minimums do not require its use.
6) PRIM 1 (With Mod. 44385/MP S13080 and Mod. 55439/MP S18649 and Mod. 55440/MP S18550 and Mod. 55696/MP S18546 and Mod. 201687/MP S31873 and Mod. 201688/MP S31874)	C	1	0	(M)(O)Except for ER operations, may be inoperative provided: a) PRIM 1 pb sw is selected OFF and remains OFF for the entire flight, and b) All Sidestick transducers associated with both SECs operate normally, and c) All SECs, SFCCs, LGCIUs, RAs, ADIRs and PRIM 3 operate normally, and d) The Sidestick priority function is checked operative on both sides before each departure, and e) Stabilizer actuator electrical motors associated with PRIM 2 and PRIM 3 operate normally, and	
(Continued)					

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 27-15

SYSTEM & SEQUENCE NUMBERS	1. ITEM	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
27 FLIGHT CONTROLS  93-01 PRIMs (Cont'd)  6) PRIM 1 (With Mod. 44385/MP S13080 and Mod. 55439/MP S18649 and Mod. 55440/MP S18550 and Mod. 55696/MP S18546 and Mod. 201687/MP S31873 and Mod. 201688/MP S31874) (Cont'd)				f) Elevators controls through operative PRIMs and SECs are verified operative before each departure, and g) Performance penalties for one pair of spoilers inoperative are applied and deactivation of affected spoilers is not necessary, and h) Approach minimums do not require its use.
7) PRIM 3 (Without Mod. 49144)	C	1	0	(M)(O)May be inoperative provided: a) PRIM 3 pb sw is selected OFF and remains OFF for the entire flight, b) All sidestick transducers associated with both SEC's operate normally, c) All SEC's, SFCC's, LGCIU's,RA's, ADIRS' and PRIM 1 operate normally, d) Stabilizer actuator electrical motors associated with PRIM land PRIM 2 operate normally, and e) Performance penalties for two pairs of spoilers (Surface 1 and 2) inoperative are applied and deactivation of affected spoilers is not necessary.

Continued

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 27-16

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
27 FLIGHT CONTROLS	93-01 PRIMs (Cont'd)	C	1	0	(M)(O)May be inoperative provided: <ul style="list-style-type: none"> <li>a) PRIM 3 pb sw is selected OFF and remains OFF for the entire flight,</li> <li>b) All sidestick transducers associated with both SEC's operate normally,</li> <li>c) All SEC's, SFCC's, LGCIU's, RA's, ADIRS' AND PRIM 1 operate normally,</li> <li>d) Stabilizer actuator electrical motors associated with PRIM 1 and PRIM 2 operate normally,</li> <li>e) Back-up control module and rudder control on SEC 1 are verified to operate normally before each departure,</li> <li>f) All pedals position transducer units associated with PRIM 1, PRIM 2, and SEC 1 are verified to operate normally before each departure,</li> <li>g) Blue electric pump operates normally, and</li> <li>h) Performance penalties for two pairs of spoilers (Surface 1 and 2) inoperative are applied and deactivation of affected spoilers is not necessary.</li> </ul>

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 27-17

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
27 FLIGHT CONTROLS					
93-02 PRIM Pb Sw					
	1) FAULT Lights	C	3	0	(0)May be inoperative provided associated F/CTL PRIM 1(2)(3) FAULT caution on ECAM E/WD and associated PRIM 1(2)(3) indication on ECAM F/CTL page are operative.
	2) OFF Lights	C	3	0	
93-03 Indications on ECAM F/CTL Page					
	1) PRIM	C	3	0	
93-05 Turbulence Damping Function					
		C	1	0	May be inoperative provided TURB DAMP Pb Sw is selected off.
93-06 TURB DAMP Pb Sw					
	1) OFF Light	C	1	0	

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14  
DATE: 05/31/2013

PAGE:  
27-18

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
27 FLIGHT CONTROLS						
94-01 SECs						
1) SEC 1 (Without Mod. 49144)	C	1	1	0	(M)(O)May be inoperative provided: a) SEC 1 pb sw is selected OFF and remains OFF for the entire flight, b) All sidestick transducers associated with SEC 2 operate normally, c) All PRIM's, SFCC's, LGCIU's, RA's, and ADIRS' operate normally, d) FCDC 2 and FWC 2 operate normally, e) Performance penalties for one pair of spoilers inoperative are applied and deactivation of affected spoilers is not necessary, and f) Approach minimums do not require its use.	
2) SEC 1 (With Mod. 49144)	C	1	1	0	(M)(O)May be inoperative provided: a) SEC 1 pb sw is selected OFF and remains OFF for the entire flight, b) All sidestick transducers associated with SEC 2 operate normally, c) All PRIM's, SFCC's, LGCIU's, RA's, and ADIRS' operate normally, d) Performance penalties for one pair of spoilers inoperative are applied and deactivation of affected spoilers is not necessary, and e) Approach minimums do not require its use.	

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 27-19

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
27 FLIGHT CONTROLS						
94-02 SEC Pb Sw						
	1) FAULT Lights	C	2	0		(O)May be inoperative provided associated F/CTL SEC 1(2) FAULT caution on ECAM E/WD and associated SEC 1(2) indication on ECAM F/CTL page are operative.
	2) OFF Lights	C	2	0		
94-03 Indications on ECAM F/CTL Page						
	1) SEC	C	2	0		
95-01 FCDCs						
		C	2	1		(M)FCDC 2 may be inoperative.

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16a  
 DATE: 03/26/2015

PAGE:  
 28-1

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
28 FUEL						
12-01 Overpressure Protectors						
	1) Wing Surge Tanks	C	2	0	(O)May be damaged or missing.	
	2) Trim Surge Tank	C	1	0	May be damaged or missing.	
	3) Center Tank (A330-200, A330-200F, A330-200F with MOD 58623/MP H16147 and MOD 200281/MP H1615, A330-300 with Mod. 204025/MP H166901)	B	1	0	(M)(O)May be damaged or missing provided: a) The crossfeed valve is checked operative on the ECAM <u>FUEL</u> page, b) Both center tank fuel pumps are operative, c) The center and inner tanks fuel quantity indications are operative on the ECAM <u>FUEL</u> page, d) The maximum fuel on board (FOB) is 154,322 lbs (70,000 kg), and e) The fuel distribution is performed in accordance with the maintenance procedure.	
21-01 Inner Tank Pumps						
	1) Main	C	4	3	(O)Except for ER operations beyond 120 minutes, one main pump may be inoperative provided: a) The crossfeed valve operates normally, and b) 2000 kg (4400 lbs) of fuel is considered unusable in the associated tank.	

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16a  
 DATE: 03/26/2015

PAGE:  
 28-2

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
28 FUEL						
23-01 Crossfeed Valve						
1) A330-300, A330-200F with MOD 58623/MP H16147	B	1	1	0	(M)(O)Except for ER operations, may be inoperative in the closed position provided: a) Both outer tanks inlet valves operate normally, b) Both inner tanks inlet valves operate normally, and c) All fuel quantity indications operate normally on the FUEL SD page.	
2) A330-200, A330-200F, A330-200F with MOD 58623/MP H16147 and MOD 200281/MP H16151, A330- 300 with Mod. 204025/MP H16690	B	1	1	0	(M)(O)Except for ER operations, may be inoperative in the closed position provided: a) Both outer tanks inlet valves operate normally, b) Both inner tanks inlet valves operate normally, c) Both center tank transfer pumps operate normally when there is fuel in the center tank, and d) All fuel quantity indications operate normally on the FUEL SD page.	
25-01 LOAD Fuel Preselector	C	-	-	0	(M)May be inoperative provided alternate procedures are developed and used.	

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16a

PAGE:

DATE: 03/26/2015

28-3

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
			-	0		
28 FUEL						
25-02	Fuel Quantity Panel (Refueling)	C	-	0	0	One or more indications may be inoperative provided continuous monitoring of fuel quantity is applied during refueling or defueling.
25-03	High Level Detection System					
	1) Outer Tanks	C	2	0	0	May be inoperative provided continuous monitoring of fuel quantity is applied during refueling.
	2) Inner Tanks					
	a) A330-300, A330-200F with MOD 58623/MP H16147	C	2	0	0	May be inoperative provided: a) Continuous monitoring of fuel quantity is applied during refueling, and b) Inner tank fuel quantity indications are operative in the cockpit.
	b) A330-200, A330-200F, A330-200F with MOD 58623/MP H16147 and MOD 200281/MP H16151, A330-300 with Mod. 204025/MP H16690	C	2	0	0	May be inoperative provided: a) Continuous monitoring of fuel quantity is applied during refueling, b) Inner tank fuel quantity indications are operative in the cockpit, and c) Center tank pumps are selected OFF.
(Continued)						

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16a

PAGE:

DATE: 03/26/2015

28-4

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
28 FUEL						
25-03 High Level Detection System (Cont'd)						
3) Center Tank (A330-200, A330-200F, A330-200F with MOD 58623/MP H16147 and MOD 200281/MP H1615, A330-300 with Mod. 204025/MP H166901)	C	1	0	0	May be inoperative provided continuous monitoring of fuel quantity is applied during refueling.	
4) Trim Tank	C	1	0	0	(O)May be inoperative provided continuous monitoring of fuel quantity is applied during refueling.	

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16a  
 DATE: 03/26/2015

PAGE:  
 28-5

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
28 FUEL						
25-04 Inlet Valves						
	1) Inner Tanks					
	a) A330-300, A330-200F with MOD 58623/MP H16147	C	2	0	(M)(O)May be inoperative in closed position provided: a) There is no fuel in trim tank or fuel in trim tank is considered unusable, part of ZFW, and is taken into account for CG determination, b) Fuel in associated outer tank is considered as unusable for flight planning, and c) Associated outer to inner transfer valve operates normally.	
	b) A330-200, A330-200F with MOD 58623/MP H16147 and MOD 200281/MP H16151, A330-300 with Mod. 204025/MP H16690	C	2	0	(M)(O)May be inoperative in closed position provided: a) There is no fuel in center and trim tanks or fuel in center and trim tanks is considered unusable, part of ZFW, and is taken into account for CG determination, b) Fuel in associated outer tank is considered as unusable for flight planning, and c) Associated outer to inner transfer valve operates normally.	
	2) Center Tank (A330-200, A330-200F, A330-200F with MOD 58623/MP H16147 and MOD 200281/MP H16151, A330-300 with Mod. 204025/MP H16690)	C	1	0	(M)(O)May be inoperative in closed position provided manual forward transfer from trim tank to center tank is carried out as soon as possible after takeoff when pitch angle is less than 3 degrees.	
(Continued)						

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16a

PAGE:

DATE: 03/26/2015

28-6

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
28 FUEL						
25-04 Inlet Valves (Cont'd)						
3) Trim Tank	C	1	0	0	(M)(O)May be inoperative in closed position provided: a) Trim tank isolation valve is selected closed, and b) There is no fuel in trim tank or fuel in trim tank is considered unusable, part of ZFW, and is taken into account for CG determination.	
4) Outer Tanks	C	2	0	0	(M)May be inoperative in closed position provided: a) Associated tank is full, b) Fuel in associated tank is considered as unusable for flight planning, and c) Associated outer to inner transfer valve operates normally.	
a) A330-300	A	2	0	0	(M)(O)May be inoperative in closed position for a maximum of three flights provided: a) MTOW is limited to 440,900 lbs (200,000 kg), b) The MZFW is limited to 361,550 lbs (164,000 kg), and c) The fuel in the associated tank, if any, is considered as not usable for flight planning purposes.	
b) A330-200, A330-200F, A330-300 with Mod. 204025/MP H16690	A	2	0	0	(M)(O)May be inoperative in closed position for a maximum of three flights, provided the fuel in the associated tank is considered as not usable for flight planning purposes.	

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 16a

PAGE:

DATE: 03/26/2015

28-7

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
28 FUEL					
25-05	Refuel Isolation Valves				
	1) Without MOD 40176/MP H12051	C	1	0	(M)May be inoperative in closed position provided gravity overwing refueling into inner tanks is carried out.
		C	1	0	(M)May be inoperative in open position provided the associated refueling coupling check valves operate normally and coupling caps are installed.
	2) With MOD 40176/MP H12051	C	2	1	One may be inoperative in closed position.
		C	2	0	(M)May be inoperative in closed position provided gravity overwing refueling into inner tanks is carried out.
		C	2	0	(M)May be inoperative in open position provided the associated refueling coupling check valves operate normally and coupling caps are installed.
25-06	Other Controls and Indicators (Refuel/Defuel panel)	C	-	0	May be inoperative provided fueling and defueling procedures do not require their use.

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16a

PAGE:

DATE: 03/26/2015

28-8

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
28 FUEL					
25-07 Refueling Coupling Check Valves					
1) Without MOD 40176/MP H12051	C	2	1	(M)One may be inoperative provided: a) The associated refuel isolation valve operates normally, b) Refueling is performed through the operative coupling check valve, c) The defective coupling check valve is sealed, and d) Both coupling caps are installed and no fuel leak is detected.	
2) With MOD 40176/MP H12051	C	4	2	(M)One or both coupling check valves on one refuel coupling may be inoperative provided: a) The associated refuel isolation valve operates normally, b) The defective coupling check valve is sealed, c) The associated refuel coupling is not used, and d) Both coupling caps are installed and no fuel leak is detected.	
26-01 Outer to Inner Transfer Valves	C	2	0	(M)(O)May be inoperative in closed position provided: a) Associated outer tank is full, b) Associated outer and inner tank inlet valves operate normally, and c) Fuel in associated outer tank is considered unusable for flight planning.	
				NOTE: The (M) procedure is applicable only when the valve is not failed in the closed position.	
				(Continued)	

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 16a

PAGE:

DATE: 03/26/2015

28-9

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			2.	3. NUMBER REQUIRED FOR DISPATCH	
28 FUEL					
26-01	Outer to Inner Transfer Valves (Cont'd)				
	1) A330-300	A	2	0	(O)May be inoperative in open position for a maximum of three flights provided: a) MTOW is limited to 440,900 lbs (200,000 kg), and b) The MZFW is limited to 361,550 lbs (164,000 kg).
	2) A330-200, A330-200F	A	2	0	(O)May be inoperative in open position for a maximum of three flights.
26-02	Center Tank Transfer Pumps (A330-200, A330- 200F, A330-200F with MOD 58623/MP H16147 and MOD 200281/MP H16151, A330-300 with Mod. 204025/MP H16690)	C	2	1	(O)May be inoperative provided there is no fuel in the center tank.
		C	2	1	(O)May be inoperative provided flight routes allow a landing at a suitable airport if the remaining center tank transfer pump fails with fuel in the center tank.
		C	2	1	(O)May be inoperative provided 33,080 lbs (15,000 kg) are considered unusable in the center tank.
		C	2	0	(O)May be inoperative provided there is no fuel in the center tank or fuel remaining in center tank up to 33,080 lbs (15,000 kg) is considered unusable, part of ZFW, and is taken into account for CG determination.

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16a

PAGE:

DATE: 03/26/2015

28-10

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3.	NUMBER REQUIRED FOR DISPATCH	
28 FUEL					
27-01	Trim Tank Isolation Valve	C	1	0	(M)(O)May be inoperative in closed position provided: a) Trim tank inlet valve is selected closed, and b) There is no fuel in trim tank or fuel in trim tank is considered unusable, part of ZFW, and is taken into account for CG determination.
27-02	Aft Transfer Valves	C	2	0	(M)(O)May be inoperative in closed position.  NOTE: When both aft transfer valves are inoperative in closed position, jettison (if installed) from wing tanks is inoperative.
27-03	Trim Pipe Isolation Valve				
	1) A330-300, A330-200F with MOD 58623/MP H16147	C	1	0	(M)(O)May be inoperative in closed position provided: a) Auxiliary forward transfer valve operates normally, and b) Manual forward transfer from trim tank to inner tanks is carried out as soon as possible after takeoff when pitch angle is less than 3 degrees.
		C	1	0	(M)(O)May be inoperative in closed position provided there is no fuel in trim tank or fuel in trim tank is considered as unusable, part of ZFW, and is taken into account for CG determination.
(Continued)					

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16a

PAGE:

DATE: 03/26/2015

28-11

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
28 FUEL						
27-03 Trim Pipe Isolation Valve (Cont'd)						
2) A330-200, A330-200F, A330-200F with MOD 58623/MP H16147 and MOD 200281/MP H16151, A330-300 with Mod. 204025/MP H16690	C	1	0	0	(M)(O)May be inoperative in closed position provided manual forward transfer from trim tank to center tank is carried out as soon as possible after takeoff when pitch angle is less than 3 degrees.	
27-04 Auxiliary Forward Transfer Valve						
1) A330-300, A330-200F with MOD 58623/MP H16147	C	1	0	0	(M)(O)May be inoperative in closed position provided manual forward transfer from trim tank to inner tanks is carried out as soon as possible after takeoff when pitch angle is less than 3 degrees.	
2) A330-200, A330-200F, A330-200F with MOD 58623/MP H16147 and MOD 200281/MP H16151, A330-300 with Mod. 204025/MP H16690	C	1	0	0	(M)(O)May be inoperative in closed position provided there is no fuel in trim tank or fuel in trim tank is considered as unusable, part of ZFW, and is taken into account for CG determination.	
27-05 Trim Tank Transfer Pump						
C	1	0	NOTE: FWD transfers are inhibited when positive pitch angle is more than 3 degrees.			

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16a

PAGE:

DATE: 03/26/2015

28-12

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
28 FUEL	27-06 Trim/APU Fuel Line	C	1	0	(M)(O) The trim/APU fuel line may be inoperative provided: <ul style="list-style-type: none"> <li>a) There is no structural leak from the trim tank,</li> <li>b) There is no fuel in the trim/APU fuel lines and in the trim tank,</li> <li>c) The APU isolation valve is deactivated in the closed position,</li> <li>d) The auxiliary forward transfer valve is deactivated in the closed position,</li> <li>e) The trim pipe isolation valve is deactivated in the closed position,</li> <li>f) The trim tank is isolated,</li> <li>g) The APU pb-sw is set to OFF and APU is not used, and</li> <li>h) Absence of fuel leak at the trim/APU drain mast is checked during each crew walk-around.</li> </ul>

(Continued)

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 16a

PAGE:

DATE: 03/26/2015

28-13

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
28 FUEL						
27-06	Trim/APU Fuel Line (Cont'd)					
	2) A330-300	C	1	0	(M)(O) The trim/APU fuel line may be inoperative provided that:	
						<ul style="list-style-type: none"> <li>a) There is no structural leak from the trim tank,</li> <li>b) The fuel leak is confirmed not originated from the center-box,</li> <li>c) There is no fuel in the trim/APU fuel lines and in the trim tank,</li> <li>d) The APU isolation valve is deactivated in the closed position,</li> <li>e) The auxiliary forward transfer valve is deactivated in the closed position,</li> <li>f) The trim pipe isolation valve is deactivated in the closed position,</li> <li>g) The trim tank is isolated,</li> <li>h) The APU pb-sw is set to OFF and APU is not used, and</li> <li>i) Absence of fuel leak at the trim/APU drain mast is checked during each crew walk-around.</li> </ul>
31-01	Jettison Valves *** (A330-200)	D	2	0	(M)May be inoperative provided jettison system is considered inoperative.	
31-02	Jettison System *** (A330-200)	D	1	0	May be inoperative provided FUEL JETTISON NOT CLOSED caution is not displayed on ECAM E/WD.	
40-01	INR TANK Pb Sw					
	1) FAULT Lights	C	6	0	May be inoperative provided associated pump indication operates normally on ECAM FUEL page.	
	2) OFF Lights	C	6	0		

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16a

PAGE:

DATE: 03/26/2015

28-14

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3.	NUMBER REQUIRED FOR DISPATCH	
28 FUEL					
40-02	CTR TANK L(R) Pump Pb Sw (A330-200, A330-200F, A330-200F with MOD 58623/MP H16147 and MOD 200281/MP H16151, A330-300 with Mod. 204025/MP H16690)				
	1) FAULT Lights	C	2	0	May be inoperative provided associated pump indication operates normally on ECAM FUEL page.
	2) OFF Lights	C	2	0	
40-03	T. TANK MODE Pb Sw				
	1) FAULT Light	C	1	0	
	2) FWD Light	C	1	0	
40-04	CTR TANK XFR Pb Sw (A330-200, A330-200F, A330-200F with MOD 58623/MP H16147 and MOD 200281/MP H16151, A330-300 with Mod. 204025/MP H16690)				
	1) FAULT Light	C	1	0	
	2) MAN Light	C	1	0	
40-06	OUTR TK XFR Pb Sw				
	1) FAULT Light	C	1	0	
	2) ON Light	C	1	0	

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 16a

PAGE:

DATE: 03/26/2015

28-15

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3.	NUMBER REQUIRED FOR DISPATCH	
28 FUEL					
40-07	INR TK SPLIT Pb Sw				
	1) SHUT Lights	C	2	0	(M)May be inoperative provided associated emergency inner tank isolation valve closure function is verified to operate normally prior to each departure.
	2) ON Lights	C	2	0	
40-08	JETTISON ARM				
***	Pb Sw (A330-200)				
	1) ON Light	C	1	0	
40-09	JETTISON ACTIVE				
***	Pb Sw (A330-200)				
	1) OPEN Light	C	1	0	May be inoperative provided both jettison indications operate normally on ECAM FUEL page.
	2) ON Light	C	1	0	
40-10	X FEED Pb Sw				
	1) OPEN Light	C	1	0	May be inoperative provided X FEED VALVE indication operates normally on ECAM FUEL page.
	2) ON Light	C	1	0	

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16a

PAGE:

DATE: 03/26/2015

28-16

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS	
28 FUEL	40-15 Indications on ECAM FUEL Page	1) Pumps	a) Wing Tanks	C	6	0	May be inoperative provided APU LP valve is considered inoperative.
			b) Center Tank (A330-200, A330-200F, A330-200F with MOD 58623/MP H16147 and MOD 200281/MP H16151, A330-300 with Mod. 204025/MP H16690)	C	2	0	
		2) APU LP Valve	C	1	0		
		3) Crossfeed	C	1	0		
(Continued)							

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16a  
 DATE: 03/26/2015

PAGE:  
 28-17

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
28 FUEL						
40-15	Indications on ECAM FUEL Page (Cont'd)					
	4) Transfer Indications					
	a) A330-300, A330-200F with MOD 58623/MP H16147		6	0		May be inoperative provided: a) Associated tanks fuel quantity indications (for tanks containing usable fuel) are operative on ECAM FUEL page, and b) Transfer operation is monitored through fuel quantity indications.
	b) A330-200, A330-200F, A330-200F with MOD 58623/MP H16147 and MOD 200281/MP H16147, A330-300 with Mod. 204025/MP H16690)		10	0		May be inoperative provided: a) Associated tanks fuel quantity indications (for tanks containing usable fuel) are operative on ECAM FUEL page, and b) Transfer operation is monitored through fuel quantity indications.
	5) Fuel On Board (FOB)	C	1	0		Except for ER operations beyond 180 minutes, may be inoperative.
***	6) Jettison (A330-200)					
	a) Valve	C	2	0		
	b) JETTISON	C	2	0		
40-16	Indication on ECAM EWD					
	1) Fuel On Board (FOB)	C	1	0		Except for ER operations beyond 180 minutes, may be inoperative.

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 16a

PAGE:

DATE: 03/26/2015

28-18

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
28 FUEL	40-17 Warning and Caution on ECAM EWD	1) FUEL EXCESS AFT CG	1	0	(M)(O)May be inoperative provided there is no fuel in trim tank or fuel in trim tank is considered unusable, part of ZFW, and is taken into account for CG determination.	
42-01 Quantity Indications On ECAM FUEL Page	1) Fuel Quantity Indications (All Tanks)	D	-	-	(O)The last two digits may be displayed dashed (degraded mode) provided the loss of accuracy is accounted for in fuel planning.	
NOTE: Fuel quantity is considered operative.						
(Continued)						

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16a

PAGE:

DATE: 03/26/2015

28-19

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
28 FUEL	42-01 Quantity Indications On ECAM FUEL Page (Cont'd)				
	2) Outer Tanks				
	a) A330-300, A330-200F with MOD 58623/MP H16147	C	2	1	(M)(O)Except for ER operations beyond 180 minutes, one may be inoperative provided: a) Fuel quantity in associated tank is checked after each refueling by manual magnetic indicators, b) Associated fuel used indication operates normally, c) Associated inner tank fuel quantity indication is operative, and d) Manual forward transfer from trim tank to inner tanks is carried out as soon as possible after takeoff when positive pitch angle is less than 3 degrees.
	b) A330-200, A330-200F, A330-200F with MOD 58623/MP H16147 and MOD 200281/MP H16151, A330-300 with Mod. 204025/MP H16690	C	2	1	(M)(O)Except for ER operations beyond 180 minutes, one may be inoperative provided: a) Fuel quantity in associated tank is checked after each refueling by manual magnetic indicators, b) Associated fuel used indication operates normally, c) Associated inner tank fuel quantity indication is operative, and d) Manual forward transfer from trim tank to center tank is carried out as soon as possible after takeoff when positive pitch angle is less than 3 degrees.

(Continued)

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16a

PAGE:

DATE: 03/26/2015

28-20

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
28 FUEL	42-01 Quantity Indications On ECAM FUEL Page (Cont'd)	3)	2	1	(M)(O)Except for ER operations beyond 180 minutes, one may be inoperative provided: <ul style="list-style-type: none"> <li>a) Fuel quantity in associated                          tank is verified after each                          refueling by manual magnetic                          indicators,</li> <li>b) All Fuel Used indications                          operate normally on ECAM FUEL                          Page,</li> <li>c) Both outer to inner transfer                          valves are deactivated in the                          closed position,</li> <li>d) Both outer tanks are full, and                          fuel in these tanks is                          considered unusable, and</li> <li>e) Manual forward transfer from                          trim tank to inner tanks is                          carried out as soon as                          possible after takeoff when                          pitch angle is less than                          3 degrees.</li> </ul>
a) A330-300, A330-200F with MOD 58623/MP H16147	C	C	2	1	(Continued)

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16a  
 DATE: 03/26/2015

PAGE:  
 28-21

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
28 FUEL	42-01 Quantity Indications On ECAM FUEL Page (Cont'd)	C	2	1	(M)(O)Except for ER operations beyond 180 minutes, one may be inoperative provided: <ul style="list-style-type: none"> <li>a) Fuel quantity in associated tank is verified after each refueling by manual magnetic indicators,</li> <li>a) All Fuel Used indications operate normally on ECAM FUEL Page,</li> <li>b) Both outer to inner transfer valves are deactivated in the closed position,</li> <li>c) Both outer tanks are full, and fuel in these tanks is considered unusable, and</li> <li>d) Manual forward transfer from trim tank to center tank is carried out as soon as possible after takeoff when pitch angle is less than 3 degrees.</li> </ul>
2) Inner Tanks (Cont'd)	b) A330-200, A330-200F with MOD 58623MP H16147 and MOD 200281/MP H16151, A330-300 with Mod. 204025/MP H16690	C	2	1	(Continued)

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16a

PAGE:

DATE: 03/26/2015

28-22

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3.	NUMBER REQUIRED FOR DISPATCH	
28 FUEL					
42-01	Quantity Indications On ECAM FUEL Page (Cont'd)				
4)	Center Tank (A330-200, A330-200F with MOD 58623/MP H16147 and MOD 200281/MP H16151, A330-300 with Mod. 204025/MP H16690)	C	1	0	(M)(O)Except for ER operations beyond 180 minutes, may be inoperative provided: a) Fuel quantity in associated tank is checked after each refueling by manual magnetic indicator, b) All wing tanks fuel quantity indications are operative on ECAM FUEL Page, c) All Fuel Used indications operate normally on ECAM FUEL Page, and d) Manual forward transfer from trim tank to center tank is carried out as soon as possible after takeoff when positive pitch angle is less than 3 degrees.
5)	Trim Tank	C	1	0	(M)(O)Except for ER operations beyond 180 minutes, may be inoperative provided there is no fuel in trim tank.
6)	Collector Cells	C	2	0	Except for ER operations beyond 180 minutes, may be inoperative.
43-01	Manual Magnetic Indicators	C	-	0	May be inoperative provided associated fuel quantity indication operates normally on ECAM FUEL page.
43-02	Fuel Quantity Attitude Monitor(s)	D	-	0	(M)May be inoperative provided fueling or defueling procedures are not predicated on their use.

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16a  
 DATE: 03/26/2015

PAGE:  
 28-23

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
28 FUEL	46-02 Low Level Detection System	1) Inner Tank	C	2	1	One may be inoperative provided: a) Inner tank fuel quantity indications are operative, b) Fuel quantity in affected inner tank is monitored during flight, and c) The jettison system is not used.
		b) Without Jettison System	C	2	1	One may be inoperative provided: a) Inner tank fuel quantity indications are operative, and b) Fuel quantity in affected inner tank is monitored during flight.
		2) Center Tank (A330-200, A330-200F, A330-200F with MOD 58623/MP H16147 and MOD 200281/MP H16151, A330-300 with Mod. 204025/MP H16690)	C	1	0	(M)(O)May be inoperative provided: a) Both center tank pumps operate normally, b) Manual transfer from center tank to inner tanks operates normally, and c) Manual transfer from trim tank to center tank operates normally.

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16a

PAGE:

DATE: 03/26/2015

28-24

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
28 FUEL						
46-03	Overflow Sensors in Wing and Trim Tanks	C	3	0	May be inoperative provided fuel level is monitored in flight.	
46-04	Warning and Caution on ECAM E/WD					
1) FUEL L(R) WING TK LO LVL		C	2	1	One may be inoperative in one inner tank provided associated inner tank low level detection system is considered inoperative.	
2) FUEL WING TK OVERFLOW		C	1	0	May be inoperative (confirmed false indication) as displayed on ECAM E/WD provided fuel level is monitored in flight.	

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16a

PAGE:

DATE: 03/26/2015

28-25

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH		4. REMARKS OR EXCEPTIONS
28 FUEL							
49-01	Temperature Indications on ECAM FUEL Page						
	1) Inner Tanks	C	2	1			
	2) Outer Tank	C	1	0			May be inoperative provided ADR 1 and ADR 2 operate normally.
		C	1	0			(O)May be inoperative provided total air temperature is monitored in flight.
	3) Trim Tank	C	1	0			(O)May be inoperative provided left outer tank fuel temperature indication operates normally on ECAM FUEL page.
		C	1	0			May be inoperative provided ADR 1 and ADR 2 operate normally.
		C	1	0			(O)May be inoperative provided total air temperature is monitored in flight.
49-02	Warning and Caution on ECAM E/WD						
	1) FUEL FUEL LO TEMP Caution Associated with Inner Tanks	C	2	1			One may be inoperative provided associated inner tank fuel temperature indication is considered inoperative.
	2) FUEL FUEL LO TEMP Caution Associated with Left Outer Tank	C	1	0			May be inoperative provided left outer tank fuel temperature indication is considered inoperative.
	3) FUEL FUEL LO TEMP Caution Associated with Trim Tank	C	1	0			May be inoperative provided trim tank fuel temperature indication is considered inoperative.

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16a  
 DATE: 03/26/2015

PAGE:  
 28-26

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
28 FUEL						
51-01 FCMC System						
1) FCMC 2	C	1	0	0		(M)May be inoperative provided: a) Associated fuel level sensing portion is powered, b) All Fuel Used indications operate normally on ECAM FUEL page, and c) The trim tank fuel temperature indication is considered inoperative.
2) FCMC Initialization (ZFW, ZFCG)	C	2	1	1		NOTE: When FCMC 2 is inoperative, fuel quantity indication can have dashes on the two last digits.
	C	2	0	0		(M)(O)May be inoperative provided there is no fuel in trim tank or fuel in trim tank is considered unusable, part of ZFW, and is taken into account for CG determination.
a) A330-300, A330-200F with MOD 58623/MP H16147	C	2	0	0		(O)May be inoperative provided manual forward transfer from trim tank to inner tanks is carried as soon as possible after takeoff when pitch angle is less than 3 degrees.
b) A330-200, A330-200F, A330-200F with MOD 58623/MP H16147 and MOD 200281/MP H16151, A330-300 with Mod. 204025/MP H16690	C	2	0	0		(O)May be inoperative provided manual forward transfer from trim tank to center tank is carried as soon as possible after takeoff when pitch angle is less than 3 degrees.

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 15  
 DATE: 04/07/2014

PAGE:  
 29-1

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
29 HYDRAULIC POWER						
10-01	Engine Driven Pumps					
	1) Depressurization Function	C	4	3		
10-02	Hydraulic System Accumulators	C	3	0		(M)May be inoperative provided there is no hydraulic fluid leakage in the accumulator nitrogen charging circuit.
		C	3	0		(M)May be inoperative provided associated accumulator is deactivated.
10-06	LP System Filters	C	3	2		
10-07	Reservoir Filling Filter	C	1	0		(M)May be inoperative provided an equivalent filter is used to fill hydraulic reservoir.
10-08	Case Drain Filters	C	4	3		(M)One may be inoperative provided filter is removed.
19-01	Leak Measurement Valve pb sw OFF Light	D	3	0		(O)May be inoperative provided: a) Associated hydraulic SYS LO PR Alert is not displayed, and b) All flight control surfaces are verified operative on the FL/CTL SD page prior to each flight.
21-01	Green Auxiliary Hydraulic Power (Electric Pump)	C	1	0		May be inoperative provided associated ELEC pb sw is set to OFF.
22-01	Blue Auxiliary Hydraulic Power (Electric Pump)	C	1	0		May be inoperative provided associated ELEC pb sw is set to OFF.

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 15  
 DATE: 04/07/2014

PAGE:  
 29-2

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
29 HYDRAULIC POWER						
23-01 Yellow Auxiliary Hydraulic Power (Electric/Hand Pump)						
1) Electric Pump						
a) A330-200, A330-200F, A330-300 without Servo-control P/N MZ4306000-12 on spoilers 4 and 6	C	1	0	0	(O)May be inoperative provided associated ELEC pb-sw is set to OFF	
b) A330-300 with Servo-control P/N MZ4306000-12 on spoilers 4 and 6	C	1	0	0	(M)(O)May be inoperative provided: a) The ELEC pb-sw is set to OFF, and b) The anti extension function is checked operative.	
2) Hand Pump	C	1	0	0	(M)May be inoperative provided the integrity of the yellow hydraulic system is not affected.	
30-01 Pump						
1) FAULT Lights	C	7	0	0	May be inoperative provided associated ECAM warnings and cautions operate normally.	
2) OFF Lights	C	7	0	0		
3) ON Lights	C	3	0	0	May be inoperative provided ECAM indication for associated electric pump operates normally.	

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 15  
DATE: 04/07/2014

PAGE:  
29-3

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3.	NUMBER REQUIRED FOR DISPATCH	
29	HYDRAULIC POWER				
30-02	ECAM HYD Page Indications				
	1) Reservoir Quantities	C	3	2	(M)One may be inoperative provided: a) Associated reservoir quantity is verified adequate before each departure, and b) Associated RSVR LO LVL caution operates normally.
	2) Fire Valves	C	4	0	
	3) RAT	C	1	0	May be inoperative provided RAT is visually verified to be stowed before each departure.
	4) ELEC Pumps	C	3	0	
	5) Engine Driven Pumps	C	4	0	
	6) System Labels	C	3	0	(O)May be inoperative provided associated ECAM system pressure indication is verified to operate normally before each departure.
	7) System Pressures	C	3	2	(O)One may be inoperative provided associated System Label indication operates normally.
	8) OVHT (ELEC Pump)	C	3	0	(M)(O)May be inoperative provided associated electric pump is deactivated.

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 15  
 DATE: 04/07/2014

PAGE:  
 29-4

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
29 HYDRAULIC POWER					
30-03 ECAM Warnings & Cautions					
1) RSVR LO LVL	C	3	2	(M)(O)The HYD G RSVR LO LVL alert may be inoperative provided: a) The green reservoir quantity indication is checked normal on <u>HYD</u> SD page before each departure, and b) The green reservoir low level indication is deactivated.	
	C	3	2	(O)The HYD B(Y) RSVR LO LVL alert may be inoperative provided associated reservoir quantity indication is checked normal on <u>HYD</u> SD page before each departure.	
2) RSVR LO AIR PRESS	C	3	2	(M)One may be inoperative provided air pressure is verified on the reservoir before each departure.	
3) RSVR OVHT	C	3	2		
4) ELEC PUMP FAULT					
a) G(B) ELEC PUMP FAULT	C	2	0		
b) Y ELEC PUMP FAULT (A330-200, A330-200F, A330-300 without Servo-control P/N MZ4306000-12 on spoilers 4 and 6)	C	1	0		
(Continued)					

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 15  
 DATE: 04/07/2014

PAGE:  
 29-5

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
29 HYDRAULIC POWER						
30-03 ECAM Warnings & Cautions (Cont'd)						
c) Y ELEC PUMP FAULT (A330-300 with Servo-control P/N MZ4306000-12 installed on spoilers 4 and 6)	C	1	0	0	(M)May be inoperative provided the anti extension function is checked operative.	
5) PUMP LO PR	C	5	0	0	(M)(O)May be inoperative provided: a) Associated system pressure indication is operative, and b) If HYD G ENG 1(2)(1+2) PUMP LO PR caution is displayed on ECAM E/WD, associated green pump is verified operative before each departure.	
6) SYS LO PR	C	3	0	0	(O)May be inoperative provided associated ECAM system pressure indication is verified to operate normally before each departure.	
7) RAT Fault	C	1	0	0	(M)May be inoperative provided RAT integrity is not affected.	
8) MONITORING FAULT	C	1	0	0	(M)May be inoperative provided HSMU computer is verified to be properly installed in its rack.	

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 13  
DATE: 06/11/2012

PAGE:  
30-1

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3.	NUMBER REQUIRED FOR DISPATCH	
30 ICE AND RAIN PROTECTION					
11-01	Wing Anti-Ice Control Valves	C	4	2	(M)(O)One may be inoperative in open position on each side provided: a) All engines are started on ground using APU bleed air and manual start procedures, b) Associated ECAM procedure is applied after engines are started, and c) Temperature at departure airport is 19 degrees Celsius or below.
		C	4	0	(M)Except for ER operations beyond 120 minutes, may be inoperative in closed position provided airplane is not operated in known or forecast icing conditions.
11-02	WING Pb Sw				
	1) FAULT Light	C	1	0	(O)May be inoperative provided anti-ice "arrow" symbols on ECAM BLEED page operate normally.
		C	1	0	May be inoperative provided wing anti-ice control valves are considered inoperative in closed position.
	2) ON Light	C	1	0	

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 13

PAGE:

DATE: 06/11/2012

30-2

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
30 ICE AND RAIN PROTECTION						
11-03	Indications on ECAM BLEED Page					
	1) ANTI ICE	C	2	0		
	2) Arrow	C	4	0		
21-01	Engine Anti-Ice Valves					
	1) GE CF6-80E1 Series Engines	C	2	1		(M)Except for ER operations, one may be inoperative in closed position provided airplane is not operated in known or forecast icing conditions.
		C	2	0		(M)(O)May be inoperative in open position provided AFM performance penalties are applied.
(Continued)						

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 13  
 DATE: 06/11/2012

PAGE:  
 30-3

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
30 ICE AND RAIN PROTECTION						
21-01 Engine Anti-Ice Valves (Cont'd)						
2) PW 4000 Series Engines	C	2	1	1	Except for ER operations beyond 120 minutes, one may be inoperative in closed position provided airplane is not operated in known or forecast icing conditions.	
a) Pressure Regulating Section	A	2	0	0	(M)(O)One or both may be inoperative in open position provided: a) The associated shut-off section operates normally, b) Performance penalties are applied if engine anti-ice is required for the intended flight, and c) Repairs are made within 10 calendar days.	
b) Shut-off Section	A	2	0	0	(M)(O)One or both may be inoperative in open position provided: a) The associated pressure regulating section is in unlocked (activated) position, b) The associated A.ICE ENG 1(2) REGUL FAULT caution was not displayed on ECAM during previous flight, c) Flight Manual performance penalties are applied, and d) Repairs are made within 10 calendar days.	
(Continued)						

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 13  
DATE: 06/11/2012

PAGE:  
30-4

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
30 ICE AND RAIN PROTECTION					
21-01 Engine Anti-Ice Valves (Cont'd)					
3) RR TRENT Series Engines	C	2	1	(M)Except for ER operations, one may be inoperative in closed position provided: a) Airplane is not operated in known or forecast icing conditions, and b) Engine has less than 2000 cycles since new.	
	C	2	0	(M)(O)May be inoperative in open position provided AFM performance penalties are applied.	

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 13  
DATE: 06/11/2012

PAGE:  
30-5

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			2.	3. NUMBER REQUIRED FOR DISPATCH	
30 ICE AND RAIN PROTECTION					
21-02 ENG Anti-Ice Pb Sw					
1) FAULT Lights					
	a) GE CF6-80E1 Series Engines	C	2	1	One may be inoperative provided associated valve is considered inoperative in the closed position.
		C	2	0	May be inoperative provided associated valve(s) is considered inoperative in the open position.
	b) PW 4000 Series Engines	C	2	1	One may be inoperative provided the associated engine anti-ice valve is considered inoperative in closed position.
		A	2	0	May be inoperative provided: a) Pressure regulating section of the associated engine anti-ice valve is considered inoperative in the open position, and b) Repairs are made within 10 calendar days.
	c) RR TRENT Series Engines	C	2	1	One may be inoperative provided associated valve is considered inoperative in the closed position.
		C	2	0	May be inoperative provided associated valve(s) is considered inoperative in the open position.
	2) ON Lights	C	2	0	

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 13  
 DATE: 06/11/2012

PAGE:  
 30-6

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
30 ICE AND RAIN PROTECTION					
31-01 Probe Heat Computers	C	3	2	(M)One may be inoperative provided associated probe heating channel operates normally.	
	C	3	2	(M)(O)Except for ER operations beyond 120 minutes, CAPT or F/O computer may be inoperative provided: a) ADR, heaters, and failure warnings associated with the operative units operate normally, and b) Airplane is not operated in visible moisture or known or forecast icing conditions., and c) Ambient temperature at the departure airport is greater than 5 degrees C when runway is contaminated with water or slush.	
	C	3	2	(M)Except for ER operations beyond 120 minutes, STBY computer may be inoperative provided: a) ADR, heaters, and failure warnings associated with the operative units operate normally, b) Airplane is not operated in visible moisture or known or forecast icing conditions, and c) Ambient temperature at the departure airport is greater than 5 degrees C when runway is contaminated with water or slush.	

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 13  
 DATE: 06/11/2012

PAGE:  
 30-7

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
30 ICE AND RAIN PROTECTION					
31-02 Pitot Heaters	B	3	2	(M)(O)Except for ER operations beyond 120 minutes, CAPT or F/O heater may be inoperative provided: a) ADR, heaters, and failure warnings associated with the operative units operate normally, b) Airplane is not operated in visible moisture or known or forecast icing conditions, and c) Ambient temperature at the departure airport is greater than 5 degrees C when runway is contaminated with water or slush.	
	B	3	2		
	C	3	2		CAPT or F/O heater may be inoperative provided the associated ADR is considered inoperative.

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 13  
 DATE: 06/11/2012

PAGE:  
 30-8

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
30 ICE AND RAIN PROTECTION					
31-03 Static Ports Heaters	C	6	5	5	One STBY heater may be inoperative.
	C	6	4	4	(M)(O)One or both CAPT heaters may be inoperative provided ADR, heaters and failure warnings associated with the operative units operate normally.
	C	6	4	4	(M)(O)One or both F/O heaters may be inoperative provided ADR, heaters and failure warnings associated with operative units operate normally.
	C	6	4	4	(M)Except for ER operations beyond 120 minutes, one or both STBY heaters may be inoperative provided: a) ADR, heaters and failure warnings associated with the operative units operate normally, b) Aircraft is not operated in visible moisture or known or forecast icing conditions, and c) Ambient temperature at the departure airport is greater than 5 degrees C when runway is contaminated with water or slush.

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 13  
DATE: 06/11/2012

PAGE:  
30-9

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3.	2.	
			3. NUMBER REQUIRED FOR DISPATCH		
30 ICE AND RAIN PROTECTION					
31-04	Angle of Attack Probe heaters	C	3	2	(M)(O)Except for ER beyond 120 minutes, one may be inoperative provided: a) ADR, heaters and failure warnings associated with the operative units operate normally, and b) Airplane is not operated in known or forecast icing conditions.
		C	3	2	One may be inoperative provided associated ADR is considered inoperative.
31-05	TAT Probe Heaters	C	2	1	
		C	2	0	Except for ER operations beyond 120 minutes, may be inoperative provided airplane is not operated in visible moisture or known or forecast icing conditions.
31-06	PROBES/WINDOW HEAT Pb Sw				
	1) AUTO Control	C	1	0	May be inoperative provided PROBES/WINDOW HEAT system is manually selected.
	2) ON Light	C	1	0	

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 13

PAGE:

DATE: 06/11/2012

30-10

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
30 ICE AND RAIN PROTECTION						
42-01	Window Heat Computers	C	2	1	(M)Except for ER operations beyond 120 minutes, one may be inoperative provided: a) Airplane is not operated in known or forecast icing conditions, b) All heaters and failure warnings on the fixed and sliding windows associated with operative unit operate normally, and c) Approach minimums do not require its use.	
42-02	Fixed Lateral Window and Sliding Window Heating Systems	C	4	0		
42-03	Front Windshield Heating Systems	C	2	1		Except for ER operations beyond 120 minutes, one may be inoperative provided: a) Airplane in not operated in known or forecast icing conditions, and b) Approach minimums do not require its use.

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 13

PAGE:

DATE: 06/11/2012

30-11

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
30 ICE AND RAIN PROTECTION					
45-01	Windshields Wipers	C	2	0	(O)May be inoperative provided: a) Airplane is not operated in precipitation within 5 NM of the airport of takeoff or intended landing, and b) Approach minimums do not require its use.
		B	2	1	One may be inoperative provided associated rain repellent system is installed and operative.
	1) Fast Speed	C	2	0	May be inoperative provided slow speed operates normally and approach minimums do not require its use.
	2) Slow Speed	C	2	0	May be inoperative provided fast speed operates normally.
	3) PARK Function	C	2	0	May be inoperative provided affected wiper can be located in a position that will not obstruct forward vision.
		C	2	0	(M)May be inoperative provided affected wiper is removed and considered inoperative.
45-02	Rain Repellent	D	2	0	
***	Systems				

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 13  
 DATE: 06/11/2012

PAGE:  
 30-12

SYSTEM & SEQUENCE NUMBERS	1. ITEM		2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
30 ICE AND RAIN PROTECTION					
46-01 Escape Slide *** Locking Mechanism Ice Protection					
	1) Main Entry Cabin Doors (1, 2, and 4)	D	6	3	(O)The heating function may be inoperative on fifty percent of the cabin doors provided cabin crews are briefed that if associated door cannot be disarmed, another door may be used (if necessary) to exit the aircraft.  NOTE: Slide deployment is not affected by an inoperative heater and the associated door remains fully operative as an emergency exit with the slide armed.
	2) Emergency Exit Cabin Doors (3)	D	2	0	(O)The heating function may be inoperative on emergency exit cabin doors provided cabin crews are briefed that associated door may not be disarmed.  NOTE: Slide deployment is not affected by an inoperative heater and the associated door remains fully operative as an emergency exit with the slide armed.
71-01	Waste Water Drain Mast Heating System	C	-	0	(M)May be inoperative provided: a) Associated galleys and lavatories are not used, b) Associated lavatory water supplies are closed, and c) Associated lavatory doors are placarded INOPERATIVE and locked closed.

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 13

PAGE:

DATE: 06/11/2012

30-13

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
30 ICE AND RAIN PROTECTION						
81-01	Advisory Ice *** Detection System	C	1	0		
81-02	External Visual *** Ice Indicator Lighting	D	1	0		

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14  
DATE: 05/31/2013

PAGE:  
31-1

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3.	NUMBER REQUIRED FOR DISPATCH	
31	INDICATING/RECORDING SYSTEM				
21-01	Electrical Clock (Controls and Indicators)	C	1	0	(O)May be inoperative provided: a) UTC indication from CMC is available on ECAM SD, and b) Chrono indication is available on one Navigation Display (ND).
30-01	Printer				Deleted, Rev. 5. (See Item 45-41-01)
33-01	Flight Data Recorder (FDR) System	C	-	1	Any in excess of those required by 14 CFR may be inoperative.
		A	-	0	May be inoperative provided: a) Cockpit Voice Recorder (CVR) operates normally, b) Airplane is not dispatched from a designated airport as listed in the operator's MEL unless: (1) The FDR failure occurs after pushback but prior to takeoff, or (2) The FDR repair was attempted but was not successful, c) In those cases where repair is attempted but not successful, the aircraft may be dispatched on a flight or series of flights until the next designated airport where repair must be accomplished prior to dispatch, and d) Repairs are made within three flight days.
(Continued)					

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14  
DATE: 05/31/2013

PAGE:  
31-2

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3.	NUMBER REQUIRED FOR DISPATCH	
31	INDICATING/RECORDING SYSTEM				
33-01	Flight Data Recorder (FDR) System (Cont'd)				
	1) FDR Recording Parameters required by 14 CFR	A	-	-	May be inoperative provided: a) Cockpit Voice Recorder (CVR) operates normally, and b) Repairs are made within 20 calendar days.
	2) FDR Recording Parameters not required by 14 CFR	A	-	-	May be inoperative provided repairs are made prior to the completion of the next heavy maintenance visit.
33-02	Flight Data Interface Unit (FDIU)	A	1	0	May be inoperative provided: a) FDR is considered inoperative, and b) Repairs are made within three flight days.
33-03	RCDR GND CTL Pb Switch	A	1	0	May be inoperative provided repairs are made within three flight days.
33-04	Quick Access *** Recorder (QAR)	D	1	0	May be inoperative provided operations or procedures do not require its use.
36-01	Digital ACMS *** Recorder (DAR)	D	1	0	May be inoperative provided operations or procedures do not require its use.
36-02	Data Management *** Unit (DMU)	D	1	0	May be inoperative provided operations or procedures do not require its use.
53-01	Flight Warning Computers (FWC)	B	2	1	FWC 2 may be inoperative provided approach minimums do not require its use.

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14  
DATE: 05/31/2013

PAGE:  
31-3

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
31 INDICATING/RECORDING SYSTEM						
53-03 Altitude Alerting System	A	-	0	(O)May be inoperative provided: a) Autopilot with altitude hold and altitude capture operates normally, b) Enroute operations, i.e. RVSM, do not require its use, c) Airplane does not depart from a designated airport(as listed in the operator's MEL)where repair or replacement can be made, and d) Repairs are made within 3 flight days.		
	C	-	1			
1) Aural Alert	C	-	0		May be inoperative provided: a) Visual alert operates normally, and b) Auto-pilot with altitude hold and altitude capture operates normally.	
2) Visual Alert	C	-	0			
55-01 System Data Acquisition Concentrator Unit (SDAC)	B	2	1	SDAC 2 may be inoperative.		

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 31-4

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
31 INDICATING/RECORDING SYSTEM						
56-01 ECAM Control Panel						
1) System Page Manual Call Pb	C	13	0			
2) CLR Pb	C	2	1			
3) T.O. CONFIG Pb	B	1	0			(0)May be inoperative provided the aircraft is verified to be in the correct takeoff configuration before each takeoff.
						NOTE: T.O. CONFIG warning must be operative.

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 31-5

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			2.	3. NUMBER REQUIRED FOR DISPATCH	
31	INDICATING/RECORDING SYSTEM				
58-01	Warning/Caution Message Logic				
	1) MASTER WARN				
	a) Light	C	2	1	
	b) Cancel Function	C	2	1	
	2) MASTER CAUT				
	a) Light	C	2	1	
	b) Cancel Function	C	2	1	
62-01	Display Management System				
	1) EFIS Portion (Without Mod. 47524)	C	3	2	One may be inoperative on DMC 2 provided EFIS DMC 3 is selected on F/O side.
	2) ECAM Portion (Without Mod. 47524)	C	3	2	(O)One may be inoperative on DMC 2.
	3) DMC (With Mod. 47524)	C	3	2	DMC 2 may be inoperative provided EFIS DMC 3 is selected on F/O side.
63-01	Display Units (DU)	C	6	5	(O)PFD2, ND2, or SD units may be inoperative provided approach minimums do not require their use.
		C	6	5	(O)Except for ER operations, ND1 unit may be inoperative provided approach minimums do not require its use.

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 31-6

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
31	INDICATING/RECORDING SYSTEM					
66-02	Engine/Warning Display (E/WD) Indications					
	1) MEMO Messages	C	-	0		
67-02	System Display (SD) Indications					
	1) Permanent Data (TAT, SAT, GLOAD, UTC, GW, GWCG) (Without Mod. 47524)	C	6	1		All indications may be inoperative provided TAT indication is available.
	2) Permanent Data (TAT, SAT, ISA, GLOAD, UTC, GW, GWCG) (With Mod. 47524)	C	7	1		All indications may be inoperative provided TAT indication is available.

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14  
DATE: 05/31/2013

PAGE:  
31-7

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3.	NUMBER REQUIRED FOR DISPATCH	
31	INDICATING/RECORDING SYSTEM				
68-01	Electronic Instrument System (EIS) Switching				
	1) ECAM SWITCHING Panel				
	a) DMC Switching Selector	C	1	0	(M)May be inoperative provided: a) Selector is in AUTO position, and b) Automatic switching is verified to operate normally.
	b) ECAM/ND Switching Selector	C	1	0	(O)May be inoperative provided: a) Selector is in NORM position, b) Both ECAM display units operate normally, and c) Automatic switching E/WD to SD operates normally.
	2) EFIS DMC Panel				
	a) EFIS DMC Transfer Selectors	C	2	1	F/O selector may be inoperative provided: a) F/O selector is in NORM position, and b) EFIS displays operate normally.
	b) PFD/ND Pb	C	2	0	(O)May be inoperative provided: a) Associated PFD and ND units operate normally, and b) PFD to ND automatic switching operates normally.

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 13  
DATE: 06/11/2012

PAGE:  
32-1

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
32 LANDING GEAR					
11-01	Main Landing Gear *** Oleo Pressure Indicator (With Mod. 55731 or Mod. 55922)	D	2	0	
31-01	Landing Gear Control and Interface Unit (LGCIU)	C	2	1	(M)LGCIU 2 may be inoperative provided both SFCC's operate normally.
31-02	Safety Valve  1) Channels	C	2	1	(M)One channel may be inoperative provided the other channel is verified to operate normally.
31-03	Landing Gear Retracting System	A	1	0	(M)(O)May be inoperative for a maximum of three flights provided the airplane is operated in accordance with the AFM supplement for gear down flight.
33-01	Landing Gear Gravity Extension System	A	1	0	(M)(O)May be inoperative for a maximum of three flights provided the airplane is operated with landing gear down and in accordance with the AFM supplement for gear down flight.
41-01	Nose Wheel and Main Wheel Tie Bolts (Except for Goodrich-Messier Basic Main P/N 3-1509-2, P/N 3-1509-3)	A	-	-	(M)One tie bolt on one wheel may be broken or missing provided: a) The affected tie bolt is removed, b) The wheel and associated brake are verified for absence of damage, and c) Repairs are made within 5 flights.

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 13  
 DATE: 06/11/2012

PAGE:  
 32-2

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
32 LANDING GEAR						
42-01 Main Wheel Brakes	C	8	6	6	(M)(O)One brake per landing gear may be inoperative provided: a) Affected brake is deactivated or removed, b) Green and blue brake systems associated with operative brakes operate normally, c) Tachometers associated with operative brakes operate normally, and d) AFM performance penalties are applied.	
42-02 Green System Brakes	C	8	6	6		(M)(O)Braking on one wheel per landing gear may be inoperative provided: a) Green hydraulic supply of affected brake is deactivated, b) Tachometers associated with operative brakes operate normally, c) AFM performance penalties are applied, and d) Blue brake system operates normally.
42-03 Braking/Steering Control Unit (BSCU) Systems	C	2	1	1		

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 13  
 DATE: 06/11/2012

PAGE:  
 32-3

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3.	NUMBER REQUIRED FOR DISPATCH	
32	LANDING GEAR				
42-04	AUTO/BRK				
	1) Function	C	1	0	May be inoperative provided approach minimums do not require its use.  NOTE: AUTO BRK line of TO MEMO will remain blue with MAX auto brakes inoperative.
	2) AUTO/BRK Panel Mode Lights (LO, MED, MAX)				
	a) ON	C	3	0	May be inoperative provided Auto Brake indications on ECAM WHEEL page operate normally.
		C	3	0	May be inoperative provided associated autobrake mode is not used.
	b) DECEL	C	3	0	May be inoperative provided Auto Brake indications on ECAM WHEEL page operate normally.
		C	3	0	May be inoperative provided associated autobrake mode is not used.
42-05	Tachometers	C	8	7	(O)May be inoperative provided: a) AFM takeoff and landing penalties are applied, and b) The AUTO/BRK function is not used.
42-06	Nose Wheel Brake Pads	C	2	0	(M)May be inoperative provided brake pads are removed.

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 13  
 DATE: 06/11/2012

PAGE:  
 32-4

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
32	LANDING GEAR					
42-07	Brake Indications on ECAM WHEEL Page					
	1) Release	C	8	0		
	2) ANTISKID	C	1	0		
	3) AUTO BRK, LO, MED, MAX	C	4	0		
	4) NORM BRK	C	1	0		
44-01	Blue System Brakes	C	8	6		(M)Braking on one wheel per landing gear may be inoperative provided: a) Blue hydraulic supply of affected brake is deactivated, b) Green brake system operates normally, and c) All thrust reversers operate normally.
44-02	ACCU PRESS Indicator	C	1	0		(O)May be inoperative provided: a) Both BRAKES pressure indicators operate normally, and b) Blue hydraulic pressure of the brake accumulators is verified before each departure.
44-03	BRAKES Pressure Indicators	C	2	1		(M)One may be inoperative provided: a) Both BSCU systems operate normally, and b) The Alternate braking system is checked operative before the first flight of each day.
45-02	Parking Brake External Light	C	1	0		(O)May be inoperative provided parking brake status is verified before moving aircraft.

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 13  
 DATE: 06/11/2012

PAGE:  
 32-5

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
32 LANDING GEAR						
47-01	Brake Temperature Indications on ECAM WHEEL Page	C	8	4	4	(M)(O)Up to two brake temperature indications per landing gear may be inoperative provided: a) Associated sensor is deactivated if it triggers BRAKES HOT caution on EWD, and b) Ground brake cooling time is applied.
		C	8	4	4	(M)(O)Up to two brake temperature indications per landing gear may be inoperative provided: a) Associated sensor is deactivated if it triggers BRAKES HOT caution on EWD, b) All brake temperatures on the associated landing gear are measured using hand held infra-red thermometer before each departure, and c) The temperature of the affected brake is equal to, or lower than, the highest of the temperatures measured with the infra-red thermometer on the non affected brakes of the same landing gear, before each departure.
48-01	Brake Fan System	D	1	0	0	
	1) BRK FAN Pb Sw					
	a) HOT Light	C	1	0	0	
	b) ON Light	C	1	0	0	
49-01	ECAM Tire Pressure Indications	D	-	0	0	

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 13  
DATE: 06/11/2012

PAGE:  
32-6

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH		4. REMARKS OR EXCEPTIONS
32 LANDING GEAR							
49-02 Tire Pressure Warnings and Cautions on ECAM E/WD							
*** 1) WHEEL TIRE LO PR		D	1	0			(M)May be inoperative on one or more wheels provided: a) Associated pressure monitoring channel is deactivated if the WHEEL TIRE LO PR caution was triggered erroneously, and b) Tire pressure on affected wheel is verified to be within limits before the first dispatch under present MMEL item and every three days.
		D	1	0			(M)May be inoperative on all wheels provided: a) The Tire Pressure Indicating Computer (TPIC) is deactivated if the WHEEL TIRE LO PR caution was triggered erroneously, and b) Tire pressure on each wheel is verified to be within limits before the first dispatch under present MMEL item and every three days.
51-01 Nose Wheel Steering Control System							Deleted, Rev. 9.
51-02 PEDALS DISC pb		C	2	0			(O)May be inoperative in the released position (No disconnection possible and NWS still available by rudder pedals).

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 13  
 DATE: 06/11/2012

PAGE:  
 32-7

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
32 LANDING GEAR						
51-03 Nose Wheel Steering Electrical Deactivation Box (For A/C Towing)	C	1	0	0	(O)May be inoperative. (No towing mode when lever is in TOWING position.)	
	C	1	0	0	(M)(O)May be inoperative provided the NWS electrical deactivation box is deactivated.	
51-04 NW STEER Indication on ECAM WHEEL Page	C	1	0	0		

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 13  
DATE: 06/11/2012

PAGE:  
32-8

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			1.	2.	
			3. NUMBER REQUIRED FOR DISPATCH		
32 LANDING GEAR					
53-01	Nose Landing Gear *** Oversteer System	D	1	0	(M)May be inoperative provided: a) All aircraft towing is performed using a towbar, or using a towbarless vehicle fitted with an operative oversteer detection system, as required by Flight Manual limitations for towbarless operations, and b) Nose wheel steering system is verified for the absence of damage.
1)	NWS TOWING pb-sw FAULT Light	D	1	0	(M)May be inoperative provided: a) All aircraft towing is performed using a towbar, or using a towbarless vehicle fitted with an operative oversteer detection system, as required by Flight Manual limitations for towbarless operations, and b) Nose wheel steering system is verified for the absence of damage.
2)	Oversteer Red Light on the Nose Landing Gear	D	1	0	
61-01	LDG Gear Indicator Panel (UNLK and/or Down & Locked Triangle Indications)	B	1	0	(O)May be inoperative provided: a) Both landing gear position indications (on ECAM WHEEL page) for all three landing gear operate normally, and b) Upper and lower ECAM display units operate normally.

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 13  
 DATE: 06/11/2012

PAGE:  
 32-9

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
32 LANDING GEAR						
61-02 Gear Not Down Indication						
	1) DOWN RED ARROW Light	B	1	0		(M)May be inoperative provided ECAM warning operates normally.
61-03 Landing Gear Indications on ECAM WHEEL Page						
	1) L/G Position	C	6	0		May be inoperative provided gear position indications are available on LDG GEAR indicator panel.
	2) UP LOCK	C	3	0		May be inoperative provided airplane speed does not exceed 250 kt/M 0.55
	3) L/G Doors Position	C	4	0		May be inoperative provided airplane speed does not exceed 250 kt/M 0.55
	4) L/G CTL	C	1	0		

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14  
DATE: 05/31/2013

PAGE:  
33-1

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
33 LIGHTS	12-01 Cockpit/Flight Deck/Flight Compartment and Instrument Lighting System	C	-	-	Individual lights may be inoperative provided:	<ul style="list-style-type: none"> <li>a) Remaining lighting system lights are sufficient to clearly illuminate all required instruments, controls, and other devices for which they are provided,</li> <li>b) Remaining lighting system lights are positioned so that direct rays are shielded from flight crewmembers' eyes,</li> <li>c) Lighting configuration and intensity is acceptable to the flight crew, and</li> <li>d) RH dome light and left section of the center instrument panel flood light operate normally.</li> </ul>
	1) (Without Mod. 47244)				NOTE: Individual button/switch lights and/or annunciations/indications are excluded from this relief.	(Continued)

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14

PAGE:

DATE: 05/31/2013

33-2

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
33 LIGHTS	12-01 Cockpit/Flight Deck/Flight Compartment and Instrument Lighting System (Cont'd)	C	-	-	Individual lights may be inoperative provided: <ul style="list-style-type: none"> <li>a) Remaining lighting system lights are sufficient to clearly illuminate all required instruments, controls, and other devices for which they are provided,</li> <li>b) Remaining lighting system lights are positioned so that direct rays are shielded from flight crewmembers' eyes,</li> <li>c) Lighting configuration and intensity is acceptable to the flight crew, and</li> <li>d) RH dome light operates normally.</li> </ul>
	2) (With Mod. 47244)				NOTE: Individual button/switch lights and/or annunciators/indications are excluded from this relief.

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 33-3

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
33 LIGHTS						
14-01 Annunciator Light Test and Dimming						
	1) TEST Function	A	1	0	May be inoperative provided: a) Both FWC's operate normally, and b) Repairs are made within three flight days.	
	2) DIM Function	C	1	0	May be inoperative for daylight operations provided BRT lighting operates normally.	
	3) BRT Function	C	1	0	May be inoperative for night operations provided both FWC operate normally.	

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14  
DATE: 05/31/2013

PAGE:  
33-4

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
33 LIGHTS						
20-01 Passenger/Super-numerary Lighted Information Signs(No Smoking/Fasten Seat Belt/Return To Seat/ No Portable Electronic Devices (PED))						
1) A330-200, A330-300		C	-	-		(M)May be inoperative provided: a) Associated passenger seat or lavatory is not occupied from which a passenger lighted information (No Smoking/Fasten Seat Belt/Return To Seat/No Portable Electronic Devices) sign is not readily legible, and b) Associated seat or lavatory must be blocked and placarded - DO NOT OCCUPY.
		C	-	-		NOTE: These provisos are not intended to prohibit lavatory use or inspections by crewmembers.  (O)May be inoperative and associated passenger seat or lavatory may be occupied provided: a) PA system operates normally, and b) PA system is used to notify passengers and cabin crew when associated sign(s) are placed on or off.
(Continued)						

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14  
DATE: 05/31/2013

PAGE:  
33-5

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
33 LIGHTS						
20-01	Passenger/Super-numerary Lighted Information Signs(No Smoking/Fasten Seat Belt/Return To Seat/ No Portable Electronic Devices (PED)) (Cont'd)					
2) A330-200F		C	-	-		(M)May be inoperative provided: a) Associated supernumerary seat or lavatory is not occupied from which a supernumerary lighted information (No Smoking/Fasten Seat Belt/Return to Seat/No Portable Electronic Devices) sign is not readily legible, and b) Associated seat or lavatory must be placarded DO NOT OCCUPY.
		C	-	-		NOTE: These provisos are not intended to prohibit lavatory use or inspections by crewmembers.  (O)May be inoperative and associated supernumerary seat or lavatory may be occupied provided: a) PA system operates normally, and b) PA system is used to notify supernumeraries when associated sign(s) are placed on or off.
20-02	LEAVE MCR Sign (Lower Deck Cabin Crew Rest Compartment)					Deleted, Rev. 9. (Moved to item 33-20-04)

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14  
DATE: 05/31/2013

PAGE:  
33-6

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			-	0	
			3. NUMBER REQUIRED FOR DISPATCH		
33 LIGHTS					
20-03 ***	Crew Rest Compartment Signs ("NO SMOKING/FASTEN SEAT BELT") (Flight Crew Rest Compartment, Lower Deck Cabin Crew Rest Compartment, Bulk Crew Rest Compartment)	C	-	0	(O)Individual signs may be inoperative and affected bunk bed or seat(s) may be occupied provided an acceptable procedure is used to notify crewmembers when bed belts or seat belts should be fastened.
		D	-	0	Individual signs may be inoperative provided affected crew rest compartment is locked closed and placarded inoperative.
	1) With STC No. 02193SE	C	-	0	(O)Individual signs may be inoperative and affected bunk bed may be occupied provided an acceptable procedure is used to notify crewmembers when bed belts should be fastened.
		D	-	0	Individual signs may be inoperative provided the flight crew rest compartment is placarded inoperative.
	2) With STC No. ST11686SE-T	C	-	0	(O)Individual signs may be inoperative and affected bunk bed or seat(s) may be occupied provided an acceptable procedure is used to notify crewmembers when bed belts or seat belts should be fastened.
		D	-	0	(M)(O)May be inoperative provided effected cabin crew rest compartment is considered inoperative.

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 33-7

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
33 LIGHTS					
20-04	Leave *** Compartment Signs ("LEAVE MCR/Return To Cabin") (Lower Deck Cabin Crew Rest Compartment) (A330-200, A330-300)	C	-	0	(O)Individual signs may be inoperative and affected bunk bed or seat(s) may be occupied provided an acceptable procedure is used to notify crewmembers when the affected compartment should be evacuated.
		D	-	0	Individual signs may be inoperative provided affected crew rest compartment is locked closed and placarded inoperative.
20-05	Flight Deck AUTO Function of Cabin Signs Switch(es)	C	-	0	(O)May be inoperative provided manual control function operates normally and procedures for its use are established and used.

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 33-8

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
33 LIGHTS						
21-01 Cabin Light Systems						
1) Cabin/Supernumerary Compartment						
a) A330-200, A330-300						
***	i) With Incandescent Escape Path Marking System	C	-	-	-	Individual lights may be inoperative provided remaining lighting is sufficient for cabin attendants to perform their duties.
***	ii) With Photoluminescent Escape Path Marking System	C	-	-	-	(O)Individual lights may be inoperative provided: a) Remaining lighting is sufficient for cabin attendants to perform their duties, and b) Minimum acceptable lighting levels specified in one of the following documents are maintained: 1) FAA engineering approval letter, 2) FAA approved report of the Type Design holder, 3) Limitations and Conditions section of the applicable Supplemental Type Certificate (STC), or 4) An FAA approved report incorporated in the Master Drawing List for the applicable STC.
***	c) A330-200F	C	-	-	-	The lighting may be degraded provided it is sufficient for supernumeraries to perform their duties.
(Continued)						

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14  
DATE: 05/31/2013

PAGE:  
33-9

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
33 LIGHTS						
21-01 Cabin Light Systems (Cont'd)						
***	2) Flight Crew Rest Compartment	C	-	-		Individual lights may be inoperative provided the lighting is sufficient for the crewmembers to access their bunk bed or seat.
		D	-	0		May be inoperative provided the flight crew rest compartment is locked closed and placarded inoperative.
***	3) Flight Crew Rest Compartment (With STC No. ST02193SE)	C	-	-		Individual lights may be inoperative provided the lighting is sufficient for the crewmember to access the bunk bed.
		D	-	0		May be inoperative provided the flight crew rest compartment is placarded inoperative.
***	4) Lower Deck Cabin Crew Rest Compartment (A330-200, A330-300)	C	-	-		Up to 50 percent of the general illumination may be inoperative.
		C	-	1		One or more may be inoperative provided the stairway light operates normally.
		D	-	0		May be inoperative provided the lower deck crew rest compartment is locked closed and placarded inoperative.
(Continued)						

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14

PAGE:

DATE: 05/31/2013

33-10

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
33 LIGHTS						
21-01 Cabin Light Systems (Cont'd)						
5) Bulk Crew Rest Compartment (With STC No. ST11686SE-T	C	-	-	-	Individual lights may be inoperative provided: a) The lighting is sufficient for the crewmember to access the bunk bed, and b) The lighting intensity is acceptable to the flight crew.	
	D	-	0	0	(M)(O)May be inoperative provided the bulk crew rest compartment is locked closed, not used, and considered inoperative.	
30-01 Cargo and Service Compartment Lighting System	C	1	1	0		

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14

PAGE:

DATE: 05/31/2013

33-11

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
33 LIGHTS					
30-02	Leave Compartment Signs (A330-200F with MOD 200261-Access to MDCC during flight)	C	10	9	One may be inoperative.
		C	10	0	All may be inoperative provided that access to the MDCC during flight is not authorized.
41-01	Navigation Lights Systems				
	1) Aircraft Equipped With One Navigation Lights System	C	1	0	May be inoperative for daylight operations.
***	2) Aircraft Equipped With Two Navigation Lights Systems	C	2	1	NAV 1 or NAV 2 system may be inoperative.
		C	2	0	May be inoperative for daylight operations.
42-01	Landing Lights	C	2	0	May be inoperative for daylight operation.
		C	2	1	One may be inoperative provided taxi and take off lights operate normally.
43-01	Runway Turnoff Lights	C	2	0	
46-01	Taxi and Take Off Lights	C	2	0	
47-01	Logo Lights	D	2	0	

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 33-12

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
33 LIGHTS					
48-01	Anti-Collision /Strobe Lighting	C	5	0	(O)May be inoperative for daylight operations.
	1) Beacon Lights	C	2	0	(O)May be inoperative provided: a) Strobe lights operate normally, and b) Alternate procedures are established and used.
	2) Strobe Lights	C	3	0	
49-01	Wing and Engine Scan Lighting	C	4	0	(O)May be inoperative provided ground deicing procedures do not require their use.
50-01	Escape Slide Lighting				
	1) A330-200, A330-300	C	-	-	May be inoperative for daylight operations.
		A	-	-	May be inoperative provided: a) Associated exit is considered inoperative, and b) Repairs are made within one flight day.
	2) A330-200F	C	2	0	One or both may be inoperative for daylight operation.
		C	2	1	One may be inoperative provided associated exit is considered inoperative.
		B	2	0	Both may be inoperative provided associated exits are considered inoperative.

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14  
DATE: 05/31/2013

PAGE:  
33-13

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
33 LIGHTS					
50-03 Flight Crew					
*** Rest Compartment					
1) Overhead Emergency Light	C	1	0	May be inoperative provided emergency wall light operates normally.	
	C	-	0	May be inoperative provided an operative flashlight is available in the flight crew rest compartment.	
	D	1	0	May be inoperative provided the flight crew rest compartment is locked closed and placarded inoperative.	
2) Emergency Wall Light	C	1	0	May be inoperative provided overhead emergency light operates normally.	
	C	-	0	May be inoperative provided an operative flashlight is available in the flight crew rest compartment.	
	D	1	0	May be inoperative provided the flight crew rest compartment is locked closed and placarded inoperative.	
3) Aft Sidewall Wash Light (With STC No. ST02193SE)	D	1	0	May be inoperative provided the flight crew rest compartment is placarded inoperative.	

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 33-14

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
33 LIGHTS						
50-04 Lower Deck *** Cabin Crew Rest Compartment (A330-200, A330-300)						
1) Overhead Emergency Lights		C	-	1		
		C	-	0	May be inoperative provided an operative flashlight is available in the lower deck cabin crew rest compartment.	
		D	-	0	May be inoperative provided the lower deck cabin crew rest compartment is locked closed and placarded inoperative.	
2) EXIT Signs		C	-	-	Up to three non-adjacent bulbs or LEDs per sign may be inoperative.	
		C	-	0	May be inoperative provided stairway emergency light operates normally.	
		C	-	0	May be inoperative provided an operative flashlight is available in the lower deck cabin crew rest compartment.	
		D	-	0	May be inoperative provided the lower deck cabin crew rest compartment is locked closed and placarded inoperative.	
*** 3) EXIT Marker		C	1	0		
50-05 Interior and Exterior Emergency Lighting, Escape Path Markings, Exit Markings, and Flashlights		D	-	0	(O)May be inoperative or missing provided: a) No passengers are carried, b) A maximum of 19 persons are carried as authorized by 14 CFR for non-passenger carrying operations, and c) Alternate procedures are established and used.	

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14  
DATE: 05/31/2013

PAGE:  
33-15

SYSTEM & SEQUENCE NUMBERS	1. ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
33 LIGHTS					
50-06 Bulk Crew Rest *** Compartment (With STC No. ST11686SE-T					
1) Overhead Emergency Lights	C	-	1		May be inoperative.
	C	-	0		(O)May be inoperative provided an operational flashlight is available in the bulk crew rest compartment.
	C	-	0		(M)(O)May be inoperative provided: a) The bulk crew rest compartment is locked closed not used, and b) Alternate procedures are developed and used.
2) EXIT Signs	C	-	-		Up to three non-adjacent bulbs or LEDs per sign may be inoperative.
	C	-	0		May be inoperative provided stairway emergency light operates normally.
	C	-	0		May be inoperative provided an operative flashlight is available in the bulk crew rest compartment.
	C	-	0		(M)(O)May be inoperative provided: a) The bulk crew rest compartment is locked closed not used, and b) Alternate procedures are developed and used.

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14  
DATE: 05/31/2013

PAGE:  
33-16

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
33 LIGHTS					
51-01 Cabin Emergency Lighting					
	1) Overhead Emergency Lighting (A330-200, A330-300)	C	-	-	A maximum of 3 non-adjacent cabin overhead emergency lights may be inoperative.
	2) Dome Emergency LED Light (A330-200F)	C	2	1	One Dome Emergency LED Light may be missing.
	3) Lavatory Auxiliary Light	C	-	0	
	4) EXIT Sign (EXIT Marking, EXIT Location)				
	a) A330-200, A330-300	C	-	-	Up to three non-adjacent bulbs or LEDs may be inoperative in one or more signs.
		A	-	-	One may be inoperative provided: a) Associated exit is considered inoperative, and b) Repairs are made within one flight day.
	b) A330-200F	C	2	-	A maximum of three non-adjacent bulbs or LEDs may be inoperative in one or both signs.
		C	2	1	One may be inoperative provided associated exit is considered inoperative.
		B	2	0	Both may be inoperative provided associated exit is considered inoperative.
(Continued)					

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 33-17

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
33 LIGHTS					
51-01 Cabin Emergency Lighting (Cont'd)					
5) Floor Proximity Emergency Escape Path Marking System (A330-200, A330-300)					
a) Incandescent System	C	1	-	Individual lights may be inoperative provided minimum acceptable lighting levels specified in one of the following documents are maintained: a) FAA engineering approval letter, b) FAA approved report of the Type Design holder, c) Limitations and Conditions section of the applicable Supplemental Type Certificate (STC), or d) An FAA approved report incorporated in the Master Drawing List for the applicable STC.	
b) Photoluminescent System	C	1	-	Components may be inoperative provided minimum acceptable lighting levels specified in one of the following documents are maintained: a) FAA engineering approval letter, b) FAA approved report of the Type Design holder, c) Limitations and Conditions section of the applicable Supplemental Type Certificate (STC), or d) An FAA approved report incorporated in the Master Drawing List for the applicable STC.	

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14  
DATE: 05/31/2013

PAGE:  
34-1

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
34 NAVIGATION					
10-01 ADIRS					
1) IR	C	3	2	(M)(O)One may be inoperative provided:	<ul style="list-style-type: none"> <li>a) Both flight controls Nz accelerometers operate normally,</li> <li>b) Both flight controls Rate Gyros operate normally,</li> <li>c) For ER operations, IR2 only may be inoperative, and</li> <li>d) Approach minimums do not require its use.</li> </ul>
2) ADR	C	3	2	(O)One may be inoperative provided:	<ul style="list-style-type: none"> <li>a) Affected ADR is selected OFF,</li> <li>b) For ER operations, ADR2 only may be inoperative, and</li> <li>c) Approach minimums do not require its use.</li> </ul> <p>NOTE: If ADR 1 is inoperative, the GPWS is inoperative.</p>

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 34-2

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3.	NUMBER REQUIRED FOR DISPATCH	
34 NAVIGATION					
10-02 ADIRS Panel					
	1) IR Mode Sel	C	3	2	May be inoperative provided associated IR is considered inoperative.
	2) ON BAT Light	C	1	0	
	3) IR Pb Sw				(O)May be inoperative provided: a) Associated IR mode selector operates normally, and b) The two ADR's and two IR's associated with the operative IR pushbutton switches are operative.
	a) FAULT Light	C	3	0	
	b) OFF Light	C	3	0	
	c) Pb Sw	C	3	2	
	4) ADR Pb Sw				
	a) FAULT Light	C	3	0	(O)May be inoperative provided: a) Associated IR mode selector operates normally, and b) The two ADR's and two IR's associated with the operative ADR pushbutton switches are operative.
	b) OFF Light	C	3	0	
	c) Pb Sw	C	3	2	
***	5) DATA Sel	C	1	0	
***	6) SYS Sel	C	1	0	
***	7) Display	C	1	0	
***	8) Keyboard	C	1	0	

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 34-3

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3.	NUMBER REQUIRED FOR DISPATCH	
34 NAVIGATION					
10-03 SWITCHING Panel					
	1) ATT HDG Selector	C	1	0	May be inoperative provided: a) Selector is in NORM position, and b) IR 1 and IR 2 operate normally.
	2) AIR DATA Selector	C	1	0	May be inoperative provided: a) Selector is in NORM position, and b) ADR 1 and ADR 2 operate normally.
11-01	Angle of Attack Sensor	C	3	2	May be inoperative provided associated ADR is considered inoperative.

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14  
DATE: 05/31/2013

PAGE:  
34-4

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
34 NAVIGATION						
13-01 Indications on PFD						
	1) Vertical Speed					
	a) Inertial Mode	C	2	0		
	2) Mach Number	C	2	1		
		C	2	0		May be inoperative provided:
						a) Airplane remains at or below FL 300, and
						b) Operations or procedures do not require their use.
	a) With Mod 47244/MP S14786	C	2	0		May be inoperative provided ISIS Mach number indication operates normally.
13-02 Indications on ND						
	1) Ground Speed	C	2	0		
	2) True Airspeed	C	2	0		
	3) Wind	C	2	0		
14-01 Indications on PFD and ND						
	1) ND Heading Display	C	2	1		
	2) MAP Information	C	2	1		May be inoperative on one side provided operations or procedures do not require its use.
	3) Radio Nav aids	C	-	-		May be inoperative provided operations or procedures do not require its use.
	4) Chrono	C	2	0		

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 34-5

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3.	NUMBER REQUIRED FOR DISPATCH	
34 NAVIGATION					
14-02	NORTH REF Pb Sw	C	1	0	May be inoperative provided operations or procedures do not require its use.
15-01	Angle of *** Attack Indicator	D	-	0	
21-01	Standby Airspeed Indicator				
	1) Airspeed Bugs	D	4	0	
21-02	Standby Altimeter				
	1) Altitude Bugs	D	4	0	
22-01	Standby Horizon	B	1	0	May be inoperative provided: a) Operations are conducted in Day VMC only, and b) Operations are not conducted into known or forecast over-the-top conditions.

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14  
DATE: 05/31/2013

PAGE:  
34-6

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
34 NAVIGATION						
22-02 Standby Compass						
1) Indicator	B	1	0	0	(O)May be inoperative provided: a) The three IR's operate normally, and b) ATT HDG, PFD/ND and EFIS DMC switching operates normally.	
	B	1	0	0	May be inoperative provided: a) The three IR's operate normally, and b) DDRMI operates normally.	
	B	1	0	0	(O)May be inoperative provided: a) Any combination of two IR's are operative, and b) Airplane is operated with dual independent navigation capability and under positive radar control by ATC on enroute portion of flight.	
2) Lighting	C	1	0	0		

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14

PAGE:

DATE: 05/31/2013

34-7

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3.	NUMBER REQUIRED FOR DISPATCH	
34 NAVIGATION					
22-03	Integrated Standby Instrument System (ISIS)				
	1) Horizon (Attitude) Function	B	1	0	May be inoperative provided: a) Operations are conducted in Day VMC only, and b) Operations are not conducted into known or forecast over-the-top conditions.
	2) ILS Function	D	1	0	
	3) Mach Number Function	D	1	0	
	4) Bugs Function	D	1	0	
34-01	Paravisual Indicator (PVI)	D	-	0	
36-01	ILS	C	2	-	As required by 14 CFR.
37-01	Microwave Landing Systems (MLS)	D	2	-	As required by 14 CFR.

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14  
DATE: 05/31/2013

PAGE:  
34-8

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
34 NAVIGATION					
40-08	ATSAW Function ***	D	1	0	May be inoperative.
41-01	Weather Radar Systems	D	2	-	Any in excess of those required by 14 CFR may be inoperative.
	1) Map Mode	C	-	0	
	2) Automatic Gain Control (CAL)	C	-	0	May be inoperative provided radar gain can be manually tuned to receive satisfactory radar returns.
	3) Turbulence Detection Mode	C	1	0	
	4) Ground Clutter Suppression	C	1	0	
***	5) Windshear Detection and Avoidance System (Predictive)	B	-	0	(O)May be inoperative provided alternate procedures are established and used.
		C	-	0	(O)May be inoperative provided: a) Alternate procedures are established and used, and b) Windshear Warning and Guidance System (Reactive) operates normally.
					NOTE: Operator's Alternate procedure should include reviewing windshear avoidance and recovery procedures.

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14  
DATE: 05/31/2013

PAGE:  
34-9

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
34 NAVIGATION					
42-01	Radio Altimeter Systems	A	2	1	(M)One may be inoperative provided: a) All ADIRS', SFCC's, LGCIU's operate normally, b) Repairs are made within three flight days, and c) Approach minimums do not require its use.  NOTE: If Radio Altimeter 1 is inoperative, the GPWS is inoperative.
42-02	Automatic Callout	C	1	0	May be inoperative provided approach minimums do not require its use.
42-03	Altitude Alerting System				Deleted, Rev. 1. (See Item 31-53-03.)
43-01	Traffic Alert and Collision Avoidance System (TCAS II)	B	1	0	(M)May be inoperative provided: a) System is deactivated and secured, and b) Enroute or approach procedures do not require its use.
		C	1	0	(M)(O)May be inoperative provided: a) Not required by 14 CFR, b) System is deactivated and secured, and c) Enroute or approach procedures do not require its use.
	1) Combined Traffic Alert (TA) and Resolution Alert (RA) Dual Display System(s)	C	2	1	May be inoperative on the non-flying pilot side provided: a) TA and RA visual display is operative on flying pilot side, and b) TA and RA audio function is operative on flying pilot side.  (Continued)

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 34-10

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
34 NAVIGATION						
43-01	Traffic Alert and Collision Avoidance System (TCAS II) (Cont'd)					
	2) Resolution Advisory (RA) Display System(s)	C	2	1		May be inoperative on non-flying pilot side.
		C	-	0		(O)May be inoperative provided: a) Traffic Alert (TA) visual display and audio functions are operative, b) TA only mode is selected by the crew, and c) Enroute or approach procedures do not require its use.
	3) Traffic Alert Display System(s)	C	-	0		(O)May be inoperative provided: a) RA visual display and audio functions are operative, and b) Enroute or approach procedures do not require its use.
	4) Audio Functions	B	1	0		May be inoperative provided enroute or approach procedures do not require use of TCAS.
***	5) Airspace Selection Functions	C	-	0		

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 34-11

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
34 NAVIGATION					
48-01	Ground Proximity Warning System (GPWS)	A	1	0	(O)May be inoperative provided: a) Alternate procedures are established and used, and b) Repairs are made within two flight days.
	1) Modes 1 - 4	A	4	0	(O)May be inoperative provided: a) Alternate procedures are established and used, and b) Repairs are made within two flight days.
	2) Test Mode	A	1	0	May be inoperative provided: a) GPWS is considered inoperative, and b) Repairs are made within two flight days.
	3) Glideslope Deviation (Mode 5)	C	2	1	
		B	2	0	
***	4) Advisory Callouts	B	-	0	(O)May be inoperative provided alternate procedures are established and used.
		C	-	0	May be inoperative provided: a) Advisory callout not required by 14 CFR, and b) Alternate procedures are established and used.
(Continued)					

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14  
DATE: 05/31/2013

PAGE:  
34-12

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
34 NAVIGATION						
48-01	Ground Proximity Warning System (GPWS) (Cont'd)					
***	5) Terrain System - Forward Looking Terrain Avoidance (FLTA) and Premature Descent Alert (PDA) Functions	B	1	0	(O)May be inoperative provided alternate procedures are established and used.	
	6) Terrain Displays	C	2	1		
		B	2	0		
	7) Runway Awareness & Advisory System (RAAS)	C	1	0		
51-01	Distance Measuring Equipment (DME) Systems	D	2	-	Any in excess of those required by 14 CFR may be inoperative.	

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14  
DATE: 05/31/2013

PAGE:  
34-13

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3.	NUMBER REQUIRED FOR DISPATCH	
34 NAVIGATION					
52-01	ATC Transponders and Automatic Altitude Reporting Systems	B	2	0	May be inoperative provided: a) Operations do not require its use, and b) Prior to flight, approval is obtained from ATC facilities having jurisdiction over the planned route of flight.
		D	2	1	Any in excess of those required by 14 CFR may be inoperative.
***	1) Elementary and Enhanced Downlink Aircraft Reportable Parameters not Required by 14 CFR	A	-	0	May be inoperative provided: a) Operations do not require its use, and b) Repairs are made prior to completion of the next heavy maintenance visit.
***	2) ADS-B Squitter Transmissions	A	-	0	May be inoperative provided: a) Operations do not require its use, and b) Repairs are made prior to completion of the next heavy maintenance visit.
53-01 ***	ADF	D	-	-	Any in excess of those required by 14 CFR may be inoperative.
55-01	VOR Navigation Systems	D	2	-	Any in excess of those required by 14 CFR may be inoperative.
55-02	Marker Beacon	C	-	-	May be inoperative provided approach minimums do not require its use.

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 34-14

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
34 NAVIGATION						
57-01	Radio Magnetic Information Switching and Indicating					
	1) DDRMI (without Mod. 53622 or with Mod. 53622 and Mod. 54662)					
	a) Compass Card	C	1	0		
	b) VOR Pointers	C	-	-		As required by 14 CFR.
	c) DME Counters	C	-	-		As required by 14 CFR.
	d) ADF Pointers	D	-	-		As required by 14 CFR.
57-02	Automatic Dependent Surveillance-Broadcast (ADS-B) System	D	-	0		May be inoperative provided it is not required by 14 CFR.
	1) Cockpit display and Traffic Information (CDTI)	D	-	0		NOTE: If ADS-B is installed in lieu of or as a replacement for 14 CFR required equipment, the repair category in the operator's MEL will be the same as that of the 14 CFR required equipment.
						NOTE: Cockpit Display Traffic Information (CDTI) display of data from other aircraft systems may be used.
(Continued)						

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 34-15

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
34	NAVIGATION					
57-02	Automatic Dependent Surveillance- Broadcast (ADS-B) System (Cont'd)					
	2) CDTI Control Panel	D	-	0		May be inoperative provided: a) Flight ID can be set, and b) Screen display is acceptable to the flight crew.
	3) Data Link Transmitter(s)	D	-	0		NOTE: In some aircraft the Data Link Transmission is an integral part of the transponder and relief is provided in that section.
	4) Data Link Receivers	D	-	0		
	5) ADS-B Applications	D	-	0		
58-01	Satellite *** Navigation					
	1) Global Positioning System (GPS)	C	2	0		(O)May be inoperative provided alternate procedures are established and used.
		D	2	0		May be inoperative provided procedures do not require its use.
61-01	Navigation Database	C	-	-		(O)May be out of currency provided: a) Current Aeronautical Charts are used to verify Navigation Fixes prior to dispatch, b) Procedures are established and used to verify status and suitability of Navigation Facilities used to define route of flight, and c) Approach Navigation Radios are manually tuned and identified.

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 35-1

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
35 OXYGEN						
10-04	Exterior Crew Oxygen Overpressure Indicator Disc (Green Disc)	C	1	0	(O)May be damaged or missing.	
12-01	Crew Oxygen Distribution System					
***	1) Oxygen Cylinders (Dual System)					
	a) A330-200, A330-300	C	2	1	(M)(O)May be inoperative provided: a) Associated manual isolation valve is selected closed, b) Electrical connector associated with the pressure regulator of the inoperative oxygen cylinder is disconnected and stowed, c) No oxygen circuit leakage is detected, and d) A check is made before each flight to ensure that the remaining flight crew oxygen is sufficient for the intended flight.	
	b) A330-200F				Refer to 35-21-03	

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 35-2

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
35 OXYGEN						
13-01	Indications on DOOR/OXY ECAM Page					
	1) OXY High Pressure Indications (A330-200, A330-300)					
	a) Single System	B	1	0		(M)May be inoperative provided oxygen pressure reading is verified before each departure.
***	b) Dual System	C	2	1		May be inoperative provided associated oxygen cylinder is considered inoperative and not used.  Refer to 35-23-04-1
	CKPT&CAB OXY High Pressure Indications (A330-200F)					
		B	2	0		(M)May be inoperative provided oxygen pressure reading is verified before each departure.
	2) REGUL LO PR Indication	C	1	0		(M)(O)May be inoperative provided the oxygen pressure is verified before the first flight of each day.
13-02	CREW SUPPLY Pb Sw					
	1) OFF Light	C	1	0		

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 35-3

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
35 OXYGEN	20-01 Flight Crew *** Compartment					
	1) Individual Oxygen Module					
	a) A330-200, A330-300	C	-	-		May be inoperative provided associated bed bunk or seat is placarded "DO NOT OCCUPY".
		C	-	-		May be inoperative provided airplane remains at or below FL 250.
		C	-	-		May be inoperative and associated bed bunk or seat occupied provided a portable oxygen bottle and mask are available for the associated bed bunk or seat occupant.
	b) A330-200F	C	-	-		May be inoperative provided associated bed bunk or seat is placarded "DO NOT OCCUPY".
		C	-	-		May be inoperative provided airplane remains at or below FL 250.
		C	-	-		One or more may be inoperative and the associated bunk bed or seat may be occupied provided a portable oxygen bottle and mask, in excess of those required, are available for the associated bed bunk or seat occupant.

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14  
DATE: 05/31/2013

PAGE:  
35-4

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
35 OXYGEN					
20-02	Lower Deck Cabin *** Crew Rest Compartment				
	1) Individual Oxygen Module	C	-	-	May be inoperative provided associated bed bunk(s) is placarded "DO NOT OCCUPY".
		C	-	-	May be inoperative provided airplane remains at or below FL 250.
		C	-	-	May be inoperative and associated bed bunk occupied provided a portable oxygen bottle and mask are available for the associated bed bunk occupant.
20-03	Bulk Crew Rest *** Compartment (With STC No. ST11686SE-T)				
	1) Individual Oxygen Module	C	-	-	(M)(O)May be inoperative provided associated bed bunk(s) is placarded "DO NOT OCCUPY".
		C	-	-	(O)May be inoperative provided airplane remains at or below FL 250.
		C	-	-	(M)May be inoperative and associated bed bunk occupied provided a portable oxygen bottle and mask are available for the associated bed bunk occupant.
	2) DON OXY Mask Light	C	1	0	May be inoperative.

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 35-5

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
35 OXYGEN						
21-01 Passenger/Super-numerary Oxygen Storage						
1) Individual Cabin Modules						
	a) A330-200, A330-300	B	-	-	May be inoperative provided associated seats are placarded "DO NOT OCCUPY".	
		B	-	-	Modules may be inoperative provided airplane remains at or below FL 250.	
	b) A330-200F	C	-	-	One or more may be inoperative provided associated seats are considered inoperative.	
		B	-	-	Modules may be inoperative provided airplane remains at or below FL 250.	
2) Galley Modules (A330-200, A330-300)						
		B	-	-	May be inoperative and associated galley occupied provided airplane remains at or below FL 250.	
		B	-	-	May be inoperative and associated galley occupied provided a portable oxygen bottle and mask are available for the associated galley occupant.	
		B	-	-	May be inoperative provided associated galley is not occupied.	

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 35-6

SYSTEM & SEQUENCE NUMBERS	1. ITEM	1.	2.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
35 OXYGEN						
21-02 Lavatory Oxygen Modules						
1) A330-200, A330-300	B	-	-			May be inoperative provided lavatory is placarded "INOPERATIVE DO NOT OCCUPY".
2) A330-200F	C	1	0			May be inoperative provided the lavatory is not used.
	C	1	0			May be inoperative provided a portable oxygen bottle and mask, in excess of those required, is available in the lavatory.

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14  
DATE: 05/31/2013

PAGE:  
35-7

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3.	NUMBER REQUIRED FOR DISPATCH	
35 OXYGEN					
21-03 Gaseous Oxygen *** Cylinders					
	1) A330-200, A330-300	C	-	-	(M)May be inoperative provided: a) The associated manual shut-off valves are selected closed, b) The electrical connector associated with the pressure reducer of the inoperative oxygen cylinder is disconnected and properly stowed (for A330 Enhanced only), c) No oxygen leakage is detected, and d) The oxygen pressure is checked by direct reading on each operative oxygen cylinder before each flight and is sufficient for the intended flight.
	2) A330-200F	C	-	-	(M)Any in excess of one may be inoperative provided: a) The associated manual shut-off valves are selected closed, and b) No oxygen circuit leakage is detected, and c) A check is made before each flight to ensure the oxygen pressure is sufficient for flight crew and supernumeraries for the intended flight by direct reading on the operating bottle pressure gauge.
23-01	Passenger Oxygen Manual Control System	C	1	0	May be inoperative provided airplane remains at or below FL 250.

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14

PAGE:

DATE: 05/31/2013

35-8

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3.	NUMBER REQUIRED FOR DISPATCH	
35 OXYGEN					
23-02	Passenger Oxygen AUTO Control System	C	1	0	May be inoperative provided: a) Airplane remains at or below FL 300, and b) MAN control function is operative
		C	1	0	May be inoperative provided airplane remains at or below FL 250.
23-03	PASSENGER/CAB SYS ON Light	C	1	0	
23-04	Indications on *** DOOR/OXY ECAM Page (Cabin Fixed Oxygen System)				
	1) PAX OXY High Pressure Indication (A330-200, A330-300)	B	1	0	(M)May be inoperative provided the oxygen pressure is checked by direct reading prior to each flight and is sufficient for the intended flight.
	2) CKPT & CAB OXY High Pressure (A330-200F)	B	1	0	(M)May be inoperative provided the oxygen pressure is checked to be sufficient for the intended flight by direct reading on the associated cylinder pressure gauges before each flight.
	3) REGUL LO PR Indication	B	1	0	
23-05	Exterior PAX *** Oxygen Overpressure Indicator Disc (Green Disc)	C	1	0	(O)May be damaged or missing.
23-06	CAB OXY pb-sw OFF Light	C	1	0	May be inoperative.

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 35-9

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
35 OXYGEN						
31-01 Portable Oxygen Units (Bottle and Mask)	D	-	-	-	(M)Any in excess of those required by 14 CFR may be unserviceable or missing provided: a) Required distribution of serviceable bottles is maintained throughout the aircraft, and b) Bottles not properly serviced are replaced, serviced or removed at the next available maintenance facility.	Any in excess of those required by 14 CFR may be inoperative or removed provided location placarding is removed or obscured.
32-01 Protective Breathing Equipment (PBE)	D	-	-	-		

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 13  
 DATE: 06/11/2013

PAGE:  
 36-1

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
36 PNEUMATIC					
11-01	Bleed Air Supply Systems	C	2	1	(O)Except for ER operations beyond 120 minutes, one may be inoperative provided : a) Airplane remains at or below FL 370, b) Speedbrake control system operates normally, c) Associated ENG BLEED pb sw is selected OFF, d) Crossbleed valve is selected OPEN,, and e) APU and APU bleed air supply systems operate normally.
11-02	Bleed Valves	C	2	1	(M)One may be inoperative provided: a) Valve is secured closed, and b) Associated engine bleed air supply system is not used.
11-03	Overpressure Valves	C	2	1	One may be inoperative provided associated engine bleed air supply system is not used.
		C	2	0	May be inoperative provided no AIR ENG 1(2) BLEED FAULT caution, due to overpressure, was triggered on ECAM E/WD during previous flight.
11-04	Fan Air Valves	C	2	1	One may be inoperative provided associated engine bleed air supply system is not used.
11-05	Bleed Air Precoolers	C	2	1	One may be inoperative provided associated engine bleed air supply system is not used.

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 13  
 DATE: 06/11/2013

PAGE:  
 36-2

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			2.	3. NUMBER REQUIRED FOR DISPATCH	
36 PNEUMATIC					
11-06	IP Check Valves	C	2	1	One may be inoperative provided associated engine bleed air supply system is not used.
		C	2	1	(M)(O)One may be inoperative in open position provided: a) Associated HP valve is secured closed, and b) At low power setting, the associated engine bleed air supply system is not used.
11-07	HP Valves	C	2	1	One may be inoperative in closed position provided associated engine bleed air supply system is not used.
		C	2	1	(M)(O)One may be inoperative provided: a) Valve is secured closed, and b) At low power setting, the associated engine bleed air supply system is not used.
11-08	Bleed Monitoring Computers (BMC)				
	1) Without Mod. 52260/MP D44330 or Mod. 55198/MP D46286	C	2	1	BMC 2 may be inoperative.
		C	2	1	(M)BMC 1 may be inoperative provided: a) The APU check valve is removed and replaced by a cover plate, and b) The APU bleed air supply system is not used.
	2) With Mod. 52260/MP D44330 or Mod. 55198/MP D46286	C	2	1	One may be inoperative.

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 13  
DATE: 06/11/2013

PAGE:  
36-3

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
36 PNEUMATIC						
12-01	APU Bleed Air Supply System	C	1	0	Except for ER operations beyond 180 minutes, may be inoperative provided APU BLEED pb sw remains Off.	
12-02	APU Bleed Valve	C	1	0	(M)May be inoperative in secured closed position provided APU bleed air supply system is not used.	
		C	1	0	May be inoperative in open position provided APU is not used.	
12-03	APU Bleed Check Valve	C	1	0	May be inoperative provided APU bleed air supply system is not used.	

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 13  
 DATE: 06/11/2013

PAGE:  
 36-4

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
36 PNEUMATIC					
12-04 Crossbleed Valve					
	1) Automatic Control	C	1	0	(O)May be inoperative provided manual control is verified to operate normally.
20-01 ENG BLEED Pb Sw					
	1) FAULT Light	C	2	0	May be inoperative provided associated BMC operates normally.
	2) OFF Light	C	2	0	
20-02 APU BLEED Pb SW					
	1) FAULT Light	C	1	0	
	2) ON Light	C	1	0	
20-03 Indications on ECAM BLEED Page					
	1) Engine Precooler Inlet Pressure	C	2	0	
	2) Engine Precooler Outlet Temperature	C	2	0	
	3) Engine Bleed Valve	C	2	0	
	4) Engine HP Valve	C	2	0	
	5) APU Bleed Valve	C	1	0	(O)May be inoperative provided alternate procedures are established and used.
	6) Crossbleed Valve	C	1	0	

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 13  
 DATE: 06/11/2013

PAGE:  
 36-5

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
36 PNEUMATIC					
22-01	Pylon Leak Detection Loops				Deleted, Rev. 9. (See item 36-23-01 1) for relief.)
22-02	Wing Leak Detection Loops				Deleted, Rev. 7. (This is a MAINTENANCE STATUS message.)
22-03	APU Leak Detection Loop				
	1) Without Mod. 52260/MP D44330 or Mod.55198/MP D46286	C	1	0	(M)May be inoperative provided: a) The APU check valve is removed and replaced by a cover plate, and b) The APU bleed air supply system is not used.
	2) With Mod. 52260/MP D44330 or Mod.55198/MP D46286	C	2	0	(M)May be inoperative provided: a) The APU check valve is removed and replaced by a cover plate, and b) The APU bleed air supply system is not used.  NOTE: Failure of a single loop is indicated by a MAINTENANCE STATUS message.

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 13  
 DATE: 06/11/2013

PAGE:  
 36-6

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
36 PNEUMATIC						
23-01 Warning and Caution on ECAM EWD						
1) AIR ENG 1(2) BLEED LEAK	C	2	1	1	(M)May be displayed on ECAM EWD provided: a) There is no pylon air leakage, and b) Associated pylon loop is deactivated.	
2) AIR APU BLEED LEAK-APU LEAK FED BY ENG	C	1	0	0	(M)May be displayed on EWD provided: a) There is no air leakage in the APU bleed air duct, b) The APU leak detection system is deactivated, c) The APU check valve is removed and replaced by a cover plate, and d) The APU bleed air supply system is not used.	

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 9  
 DATE: 09/26/2007

PAGE:  
 38-1

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
38 WATER/WASTE	10-01 Potable Water Systems	C	-	-		(M)Individual components may be inoperative provided: a) Associated components are deactivated or isolated, and b) Associated system components are verified not to have leaks.  NOTE: Any portion of the system which operates normally may be used.
		C	-	-		(M)May be inoperative provided: a) System is drained, and b) Procedures are established to ensure that system is not serviced.

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 9  
 DATE: 09/26/2007

PAGE:  
 38-2

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
38 WATER/WASTE						
30-01 Lavatory Waste Systems (Including Wheelchair Accessible Lavatories)	C	-	-	-	(M)Individual components may be inoperative provided: a) Associated components are deactivated or isolated, and b) Associated components are verified not to have leaks.  NOTE: Any portion of the system which operates normally may be used.	
	C	-	-	-	(M)Associated lavatory system(s) may be inoperative provided: a) Associated components are deactivated or isolated to prevent leaks, b) The Pilot-in-Command will determine if flight duration is acceptable with a FWD Deck lavatory unusable, and c) Associated lavatory door(s) is secured closed and placarded, "INOPERATIVE - DO NOT ENTER".  NOTE: These provisions are not intended to prohibit inspections by crewmembers.	
1) Vacuum Generator Systems (Toilet)	C	2	0	0	(M)(O)May be inoperative provided: a) Vacuum generator is deactivated, and b) Procedures are established and used to only allow use of the associated lavatory at or above 16000 FT MSL.	

AIRCRAFT:

A330-200, A330-200F, A330-300

REVISION NO: 13

PAGE:

DATE: 06/11/2012

45-1

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
45	CENTRAL MAINTENANCE COMPUTER				
10-01	CMC 1 Pb Sw (Without Mod. 58416)	C	1	0	
13-01	Central Maintenance Computer(s) (CMC)				
	1) Without Mod. 58416	C	2	1	
		C	2	0	(O)May be inoperative provided alternate procedures are established and used.
	2) With Mod. 58416	C	1	0	(O)May be inoperative provided alternate procedures are established and used.
22-01	Up and Down Data Loading System Acquisition/ Interface				
	1) DATA LOADER Rotary Selector (With Mod. 40783)	C	2	0	
	2) DATA LOADING SELECTOR (DLS) (With Mod. 50021)	C	1	0	
	3) Data Loading Routing Box (DLRB) (With Mod. 50021)	C	1	0	
23-01	Multipurpose Disk Drive Unit (MDDU)	C	1	0	

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 13  
 DATE: 06/11/2012

PAGE:  
 45-2

SYSTEM & SEQUENCE NUMBERS	1.	ITEM	1.	2.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
45 CENTRAL MAINTENANCE COMPUTER							
31-01 Electronic *** Library System (ELS)	C		1	0			
41-01 Printer	C		1	0			

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 12a

PAGE:

DATE: 06/18/2010

46-1

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
46 INFORMATION SYSTEMS					
11-01 Electronic					
*** Flight Bag Systems (EFBs)					
***	1) Class 3 EFBs	C	-	-	(O)May be inoperative provided alternate procedures are established and used.
		D	-	0	NOTE: Any function, program or document which operates normally may be used. May be inoperative provided procedures do not require its use.
***	2) Data Connectivity (Class 2)	C	-	-	(O)May be inoperative provided alternate procedures are established and used.
		D	-	0	May be inoperative provided procedures do not require its use.
***	3) Power Connection (Class 1 & 2)	C	-	-	(O)May be inoperative provided alternate procedures are established and used.
		D	-	0	May be inoperative provided procedures do not require its use.
***	4) Mounting Device (Class 2)	C	-	0	(M)(O)May be inoperative provided: a) Associated EFB and hardware is secured by an alternate means or removed from the aircraft, and b) Alternate procedures are established and used.
		D	-	0	(M)(O)May be inoperative provided: a) Associated EFB and hardware is secured by an alternate means or removed from the aircraft, and b) Procedures do not require its use.

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 12a

PAGE:

DATE: 06/18/2010

46-2

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
46 INFORMATION SYSTEMS					
21-01	Air Traffic *** Service Unit (ATSU)	C	1	0	(O)May be inoperative provided alternate procedures are established and used.
		D	1	0	May be inoperative provided procedures do not require its use.  NOTE: Any ATSU function or mode that operates normally may be used.
21-02	Data-link *** Control Display Units (DCDU)	C	2	1	
		C	2	0	(O)May be inoperative provided alternate procedures are developed and used.
		D	2	0	May be inoperative provided procedures do not require its use.
21-03	ATC MSG pb ***	C	2	1	
		C	2	0	(O)May be inoperative provided alternate procedures are developed and used.
		D	2	0	May be inoperative provided procedures do not require its use.
	1) ATC MSG Lights	D	2	0	

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 12b  
 DATE: 03/07/2011

PAGE:  
 47-1

SYSTEM & SEQUENCE NUMBERS	1. ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
47 INERT GAS SYSTEM					
10-01 FUEL TANK INERTING SYSTEM (With Mod 58723)	A	1	0		May be inoperative provided repairs are made within twenty flight-days.

U.S. DEPARTMENT OF TRANSPORTATION  
FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 13  
DATE: 06/11/2012

PAGE:  
49-1

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3.	NUMBER REQUIRED FOR DISPATCH	
49 AIRBORNE AUXILIARY POWER					
11-01	APU System	C	1	0	(O)Except for ER operations beyond 120 minutes, may be inoperative provided the APU MASTER sw is set to OFF.
		C	1	0	(M)(O)Except for ER operations beyond 120 minutes, may be inoperative provided APU is deactivated or removed.
16-01	APU Air Intake Flap	C	1	0	(M)May be inoperative in open position.
		C	1	0	May be inoperative provided APU is not used.
30-01	APU AFT Fuel Pump	C	1	0	May be inoperative provided: a) The forward APU pump operates normally, and b) APU is not used in flight above FL 255.
		C	1	0	May be inoperative provided APU is not used.
30-02	APU Isol Valve	C	1	0	(M)May be inoperative closed provided APU is not used.
30-03	APU LP Valve	C	1	0	(M)May be inoperative closed provided APU is not used.
60-01	MASTER SW Pb Sw				
	1) FAULT Light	C	1	0	May be inoperative provided N and EGT indications are available on ECAM APU page.
	2) ON/R Light	C	1	0	

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 11/28/2013

PAGE:  
 49-2

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
49 AIRBORNE AUXILIARY POWER					
60-02 START Pb Sw					
	1) AVAIL Light	C	1	0	May be inoperative provided AVAIL or N indications are available on ECAM APU page.
	2) ON Light	C	1	0	
70-01 ECAM APU Page Indications					
	1) APU Indications	C	-	0	May be inoperative provided procedures do not require their use.
	2) APU GEN Parameters	C	-	0	Except for ER operations beyond 120 minutes, may be inoperative provided both AC main generations are operative.
	3) LOW OIL LEVEL message	B	-	0	(M)May be inoperative provided: a) Oil level is verified before each refueling, and b) There is no evidence of abnormal consumption or leakage.

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 52-1

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
52 DOORS	10-01 Main Entry Door/Slides	A	-	-	(M)(O)	One may be inoperative or one slide missing, provided: <ul style="list-style-type: none"> <li>a) All other main entry doors are fully operational,</li> <li>b) Affected door is not used for passenger loading,</li> <li>c) A conspicuous barrier strap or rope and a placard stating that the door is inoperative shall be placed across the inoperative door,</li> <li>d) Emergency exit signs and floor proximity lights associated with the inoperative exit must be covered to obscure the signs and lights,</li> </ul>
(Continued)						

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 52-2

SYSTEM & SEQUENCE NUMBERS	1. ITEM	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
52 DOORS	10-01 Main Entry Door/Slides (Cont'd)	1)	A330-200, A330-300 (Cont'd)	<p>e) Passengers must be briefed not to use the affected door,</p> <p>f) All passenger seats halfway to the next exit in each direction from the inoperative door, across the entire width of the airplane, shall be blocked-off with conspicuous tapes or ropes that contrast with the interior prior to loading passengers. Only the seats in these areas shall be blocked; main passenger aisles, cross aisles, and exit areas must not be blocked. (For an inoperative forward door/slide, the blocked seating area shall extend from the forward cabin end, rearward to a line halfway between the inoperative forward door and the next set of doors aft of the inoperative one. For an inoperative rear door/slide, the blocked seating area shall extend forward from the aft cabin end to a line halfway between the inoperative door and the next set of doors forward of the inoperative one.),</p> <p>(Continued)</p>

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 52-3

SYSTEM & SEQUENCE NUMBERS	1. ITEM	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
52 DOORS	10-01 Main Entry Door/Slides (Cont'd)	2)	A330-200, A330-300 (Cont'd)	<p>g) Conspicuous signs and placards shall be placed in appropriate locations indicating these seats are not to be occupied by passengers,</p> <p>h) Seating capacity must not exceed the rated capacity of the remaining pairs of exits,</p> <p>i) For extended range/overwater operations, occupancy shall not exceed the normal rated capacity of the slide/rafts, or the remaining slide/rafts, or the rated overload capacity of the slide/rafts remaining after loss of one additional slide/raft of greatest capacity, whichever is least,</p> <p>j) Blocked seating layouts and evacuation procedures must be developed and approved by the FAA Certificate Holding District Office for inclusion in the operator's manual, and</p> <p>k) Repairs are made within one flight day.</p> <p>(Continued)</p>

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 52-4

SYSTEM & SEQUENCE NUMBERS	1. ITEM	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
52 DOORS  10-01 Main Entry Door/Slides (Cont'd)  1) A330-200, A330-300 (Cont'd)	C	-	1	(M)(O)May be inoperative or slide missing provided: a) No passengers are carried, b) A maximum of 19 persons are carried as authorized by 14 CFR for non-passenger carrying operations, c) Each person has unobstructed access from their seat to an operative exit, either regular or emergency, d) Inoperative exits are conspicuously identified as inoperative, e) Any emergency exit sign and floor proximity lights associated only with the inoperative exit(s) are covered to obscure the sign and lights, f) Safety briefing includes the location of the inoperative exit(s) and instructions not to use the inoperative exit(s), and g) Alternate procedures are established and used.  (Continued)

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14  
DATE: 05/31/2013

PAGE:  
52-5

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
52 DOORS						
10-01 Main Entry Door/Slides (Cont'd)						
	2) A330-200F	C	2	1	One door/slide may be inoperative or slide missing.	
		B	2	0	(O)Both doors/slides may be inoperative or slides missing provided: a) Only essential crew members including official observer(s) in the observer seat(s) are allowed on the flight, and b) An alternate means of egress is available.	
10-03 Passenger/Supernumerary Compartment Exit Stop Fitting						
		C	-	-	One per exit may be inoperative provided airplane remains unpressurized.	
		A	-	-	(M)One per exit may be inoperative provided: a) There is no visible damage on other stop fittings for affected door, b) Stop fittings at beams 1, 2, 7, and 8 on both No. 1 doors operate normally, and c) Repairs are made within 10 flights.	

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 52-6

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
52 DOORS						
10-04 Door Damper and Emergency Operation						
1) Damper Function						
	a) A330-200, A330-300	C	8	0		
	b) A330-200F	C	2	0		
2) Emergency Opening Function						
	a) A330-200, A330-300	A	8	7		One may be inoperative provided: a) Affected exit is considered inoperative, and b) Repairs are made within one flight day.
	b) A330-200F	C	2	1		One may be inoperative provided the affected exit is considered inoperative.
		B	2	0		(O)Both may be inoperative provided: a) The affected exits are considered inoperative, b) Only essential crew members including official observer(s) in the observer seat(s) are allowed on the flight, and c) An alternative means of egress is available.
10-05 Door Bottle Pressure Indication						
Deleted, Rev. 9. (See item 23-73-02 6) for relief)						

AIRCRAFT:

A330-200, A330-200F, A330-300

REVISION NO: 14

PAGE:

DATE: 05/31/2013

52-7

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
52 DOORS					
10-06	Passenger/Supernumerary Compartment Door Stay Mechanism				
	1) A330-200, A330-300	A	8	7	One may be inoperative provided: a) Affected exit is considered inoperative, and b) Repairs are made within one flight day.
	2) A330-200F	C	2	1	One may be inoperative provided the affected exit is considered inoperative.
		B	2	0	Both may be inoperative provided the affected exits are considered inoperative.
10-07	Passenger/Supernumerary Compartment Door Spring Rod Assembly				
	1) A330-200, A330-300	C	8	0	(M)May be inoperative provided affected spring rod assembly is removed.
	2) A330-200F	C	2	0	(M)May be inoperative provided affected spring rod assembly is removed.
30-01	Cargo Doors	C	-	0	May be inoperative in closed and locked position provided they are indicated locked on ECAM DOOR/OXY page.
30-02	Cargo Door Actuators	C	-	0	(M)May be inoperative provided: a) Integrity of yellow hydraulic system is not affected, and b) Affected door is manually closed and locked.

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14  
DATE: 05/31/2013

PAGE:  
52-8

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
52 DOORS					
30-03	Lower Deck Cargo Door Latching Hooks, Spools and Bolts	C	-	-	(M)One latching hook, spool, or bolt per door may be inoperative provided: a) Remainder are normal, b) All hinge arms and hinge bolts are without damage, and c) Airplane remains unpressurized.
30-04	Lower Deck Cargo Door Hinge Arm or Hinge Bolts	C	-	-	(M)One hinge arm or bolt per door may be inoperative provided: a) Remainder are normal, b) All latching hooks, spools and bolts are without any damage and, c) Airplane remains unpressurized.
30-06	Cargo Door Electrical Control	C	-	0	May be inoperative provided the associated door can be operated using the hand pump.
		C	-	0	May be inoperative provided the associated door is not used.
30-07	Cargo Door Open/Locked Indicator light	D	2	0	(O)May be inoperative provided the affected cargo door is in the fully open position during loading and unloading operations.
30-08	Main Deck Cargo Door Piano Hinge Lugs, Latching Hook, Spool and Bolt (A330-200F)	C	-	-	(M)One latching hook, or spool, or bolt may be inoperative provided that: a) All the other latching hooks, spools, bolts and hinge lugs are without any damage, and b) The flight is not pressurized.
		C	-	-	(M)One of two piano hinge lugs may be inoperative provided that: a) all the other latching hooks, spools bolts and hinge lugs are without any damage, and b) The flight is not pressurized.

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 52-9

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
52 DOORS						
50-01	Flight Deck Door *** Lock Solenoid					Deleted, Rev. 12.
50-02	Cockpit Door Locking System (Automatic System) 14 CFR 25.795 Compliant					
	1) A330-200, A330-300 (With Mod. 50014/MP D44099)	A	1	0	(M)(O)May be inoperative provided:	a) Automatic locking system is deactivated, b) Door dead bolt operates normally and is used to lock the door, c) Alternate procedures are established and used for locking and unlocking the door using the deadbolt, and d) Repairs are made within two flight days.
	a) Cockpit Door Toggle Switch					
	i) UNLOCK Function	B	1	0	(O)May be inoperative provided:	a) LOCK and NORM functions are verified to operate normally, and b) Alternate procedures are established and used.
	ii) LOCK Function	B	1	0	(M)(O)May be inoperative provided:	a) Keypad is deactivated, b) UNLOCK and NORM functions are verified to operate normally, and c) Alternate procedures are established and used.
(Continued)						

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 52-10

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
52 DOORS						
50-02 Cockpit Door Locking System (Automatic System) 14 CFR 25.795 Compliant (Cont'd)						
1) A330-200, A330-300 (With Mod. 50014/MP D44099) (Cont'd)						
b) OPEN Light	B	1	0	0	(O)May be inoperative provided: a) Door buzzer is considered inoperative and b) Alternate procedures are established and used.	
c) FAULT Light	C	1	0	0	(O)May be inoperative provided: a) NORM and LOCK functions are verified to operate normally, b) Control Unit LED's operate normally, and c) Alternate procedures are established and used.	
d) Buzzer	C	1	0	0	(M)(O)May be inoperative provided: a) Keypad is deactivated, and b) Alternate procedures are established and used.	
e) Keypad	C	1	0	0	(M)(O)May be inoperative provided: a) Keypad is deactivated, and b) Alternate procedures are established and used.	
i) Green and Red LEDs	C	2	0	0	(O)May be inoperative provided alternate procedures are established and used.	
(Continued)						

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 52-11

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
52 DOORS						
50-02 Cockpit Door Locking System (Automatic System) 14 CFR 25.795 Compliant (Cont'd)						
1) A330-200, A330-300 (With Mod. 50014/MP D44099) (Cont'd)						
f) Pressure Rate Sensors	C	2	1	1		May be inoperative provided repairs are made within two flight days.
g) Door Release Strikes (Catch Spring, Solenoid, Bolt)	A	2	0	2		(M)One may be inoperative provided associated door release strike is removed.
h) Control Unit LED's	C	5	0	0		NOTE: Application of the maintenance procedure is only necessary when the inoperative door release strike is failed in locked position.
2) A330-200F (With Mod. 58673/MP D57209)	D	1	0	0		(O)May be inoperative provided: a) It is deactivated in the unlocked position, and b) It is not required by operational regulations for the intended flight.

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 52-12

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3.	NUMBER REQUIRED FOR DISPATCH	
52 DOORS					
50-03	Cockpit Door *** Secondary Locking System (Dead Bolt) 14 CFR 25.795 Compliant	C	1	0	
	1) A330-200, A330-300 (With Mod. 52586/MP D47666)	C	1	0	May be inoperative provided primary locking system operates normally.
	2) A330-200F (With Mod. 58673/MP D57209)	D	1	0	
50-04	Cockpit Door *** Secondary Barrier (With STC No. ST11686SE-T)	D	1	0	(M)May be inoperative provided: a) The secondary barrier is stowed open or not used, and b) Procedures do not require its use.
70-01	DOOR Indications on ECAM DOOR/OXY Page	C	-	0	(M)(O)May be inoperative provided visual verification is made before each departure that affected doors are closed and locked.  NOTE: If the PSCU or at least one proximity switch is the cause of a door caution, aircraft will not pressurize.

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 52-13

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
52 DOORS						
71-01 Door and Escape Slide Control System						
1) Proximity Switch Control Unit (PSCU)	C	1	0	0	(M)(O)May be inoperative provided: a) A visual verification is made before each departure that affected doors are closed and locked, and b) Airplane remains unpressurized.	
2) Proximity Switch						
a) Passenger Doors, Lower Deck Forward, Aft, and Bulk Cargo Doors (A330-200, A330-300 Without Mod. 56338/ MP D46296)	C	-	0	0	One or more may be inoperative provided the PSCU is considered inoperative.	
	B	-	-	-	(M)One may be inoperative for pressurized flight provided: a) Associated door locking mechanisms are verified to operate normally, b) The dummy proximity switch is connected to the PSCU in place of the inoperative proximity switch, and c) A visual verification is made before each departure that affected doors are closed and locked.	
Note: If affected door is reopened, the complete maintenance procedure must be repeated.						
(Continued)						



AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 52-15

1. SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
52 DOORS					
71-01 Door and Escape Slide Control System (Cont'd)					
2) Proximity Switch (Cont'd)					
c) Cabin Emergency Passenger Doors (No. 3), (A330-200, A330-300 With Mod. 56338/MP D46296)		C	-	0	One or more may be inoperative provided the PSCU is considered inoperative.
		B	2	1	(M)One may be inoperative for pressurized flight provided: <ul style="list-style-type: none"> <li>a) Associated door locking mechanisms are verified to operate normally,</li> <li>b) The door override procedure is applied before each flight,</li> <li>c) A visual verification is made before each departure that affected doors are closed and locked, and</li> <li>d) All other door proximity switches are operative.</li> </ul> Note: If affected door is reopened, the complete maintenance procedure must be repeated.
					(Continued)

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 52-16

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
52 DOORS						
71-01 Door and Escape Slide Control System (Cont'd)						
2) Proximity Switch (Cont'd)						
d) Entry Doors, Lower Deck Forward, Aft, and Bulk Cargo Doors (A330-200F)	C	-	0	0	One or more may be inoperative provided the PSCU is considered inoperative.	
	B	-	-	-	(O)One may be inoperative for pressurized flight provided: a) Associated door locking mechanisms operate normally, b) The door override procedure is applied before each flight, and c) A visual verification is made before each departure that affected doors are closed and locked.  NOTE: If affected door is reopened, the complete maintenance procedure must be repeated.	
e) Avionics Doors	C	1	0	0	(M)(O)May be inoperative provided prior to each departure: a) A visual verification is made that avionics door is closed and locked, and b) The door is pushed against to ensure it is closed and locked.  Note: If avionics door is reopened, the complete maintenance procedure must be repeated.	
(Continued)						

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 52-17

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
52 DOORS					
71-01 Door and Escape Slide Control System (Cont'd)					
2) Proximity Switch (Cont'd)					
f) Main Deck Cargo Door (A330-200F)	B	8	7		<p>(O)One may be inoperative and the aircraft can be pressurized provided that:</p> <ul style="list-style-type: none"> <li>a) The associated door locking mechanisms are checked to be functional before each flight, and</li> <li>b) The door override procedure is applied before each flight, and</li> <li>c) A visual check is made to confirm that the associated door is closed and locked before each flight.</li> </ul> <p>NOTE: Depending on the affected proximity switch, the automatic opening/closing function of the main deck cargo door may be inoperative. In this case, the main deck cargo door needs to be operated manually.</p>
(Continued)					

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 52-18

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
52 DOORS					
71-01 Door and Escape Slide Control System (Cont'd)					
3) SLIDE ARMED Light					
	a) A330-200, A330-300	C	8	0	(O)May be inoperative provided alternate procedures are developed and used.
	b) A330-200F	C	2	0	(O)May be inoperative provided alternate procedures are developed and used.
4) CABIN PRESSURE Light (Passenger/Entry Doors, Lower Deck Forward, and Aft Cargo Doors)					
	a) A330-200, A330-300	C	10	0	
	b) A330-200F	C	6	0	

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 12  
 DATE: 12/14/2009

PAGE:  
 56-1

SYSTEM & SEQUENCE NUMBERS	1. ITEM	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
56 WINDOWS				
	11-01 Front Windshields			Relief deleted with Revision 12.  NOTE: Refer to Aircraft Maintenance Manual (AMM) or Structural Repair Manual.
	11-02 Fixed Lateral Windows			Relief deleted with Revision 12.  NOTE: Refer to Aircraft Maintenance Manual (AMM) or Structural Repair Manual.
	12-01 Sliding Windows			Relief deleted with Revision 12.  NOTE: Refer to Aircraft Maintenance Manual (AMM) or Structural Repair Manual.
	21-01 Cabin Windows			Relief deleted with Revision 12.  NOTE: Refer to Aircraft Maintenance Manual (AMM) or Structural Repair Manual.

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16a

PAGE:

DATE: 03/26/2015

73-1

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
73 ENGINE FUEL & CONTROL					
20-01	Flex Take Off Mode	C	2	0	May be inoperative provided takeoff is performed in TOGA or derated mode.
20-02	Minimum Idle on Ground	C	2	0	(O)May be inoperative provided AFM performance penalties are applied.
20-03	Derated Takeoff *** Mode	D	2	0	May be inoperative provided takeoff is performed in TOGA or FLX mode.
20-04	Engine Thrust *** Bump (GE Engines)	D	2	0	May be inoperative provided benefit of bump is not taken into account for determination of takeoff performance.
21-01	Items Affecting the Aircraft Fuel Consumption (PW 4000 Engine Series)	C	-	-	One or more items affecting the aircraft fuel consumption (signaled by ENG INCREASED FUEL BURN caution on ECAM E/WD) may be inoperative on one or both engines provided fuel consumption increase of 2 per cent is applied.

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16a  
 DATE: 03/26/2015

PAGE:  
 73-2

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3. NUMBER REQUIRED FOR DISPATCH		
73 ENGINE FUEL & CONTROL					
25-01 FADEC					
1)	Engine Short Time Limited Dispatch Items	A	-	-	Dispatch is allowed with engine short time limited faults present on one engine (signaled by ENG 1(2) MINOR FAULT caution on ECAM EWD) provided repairs are made in a period of time not exceeding 300 flight hours, or 20 consecutive calendar days whichever occurs first.
2)	FADEC Channel A (PW 4000 Series Engines)	A	2	1	Except for ER operations, one may be inoperative provided repairs are made within 10 calendar days.
3)	EPR Control Mode (PW 4000 and RR Trent Series Engines)	C	2	0	(O)Except for ER operations, may be inoperative provided : a) The N1 rated control mode operates normally on both engines (ENG 1(2) N1 DEGRADED MODE caution not displayed on ECAM), and b) Flight Manual performance penalties are applied.
4)	A/C 115VAC Power Supply Channel A (RR Trent Series Engines)	C	2	1	(O)Except for ER operations, one may be inoperative.
5)	A/C 115VAC Power Supply Channel B (RR Trent Series Engines)	C	2	0	

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16a

PAGE:

DATE: 03/26/2015

73-3

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
73 ENGINE FUEL & CONTROL					
25-02 EIU		C	2	1	(M)(O)One may be inoperative provided: <ul style="list-style-type: none"> <li>a) Associated N1 and N2 vibrations are considered inoperative,</li> <li>b) Autothrust function is considered inoperative,</li> <li>c) Minimum idle on ground is considered inoperative,</li> <li>d) Flight crew is provided with the following statement via appropriate means (e.g. dispatch release, MEL (O) procedure, etc.): "For a landing conducted with one unavailable thrust reverser, ensure that both engine thrust levers are retarded to the IDLE detent for the flare and the touchdown. Select both reverse control levers when applying reverse thrust.", and</li> <li>e) Appropriate performance adjustments for an inoperative thrust reverser are applied.</li> </ul>
					NOTE: Associated thrust reverser is not available.

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16a  
 DATE: 03/26/2015

PAGE:  
 73-4

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			2.	3. NUMBER REQUIRED FOR DISPATCH	
73 ENGINE FUEL & CONTROL					
30-01 Indications on ECAM					
	1) Fuel Used Indications (Without Mod. 57115/MP S30194)	C	2	1	One may be inoperative provided associated inner, outer and center (A330-200, A330-300 with Mod. 204025/MP H16690) tank fuel quantity indications for tanks containing usable fuel are operative.
	2) Fuel Used Indications (With Mod. 57115/MP S30194)	C	2	1	One may be inoperative provided associated inner, outer and center (A330-200, A330-300 with Mod. 204025/MP H16690) tank fuel quantity indications for tanks containing usable fuel are operative.
		D	2	1	One may be in degraded mode (Last 3 green digits with amber dashes).  NOTE: Fuel used indication on the ENG SD page in degraded mode is considered operative.
		C	2	0	Both may be in degraded mode (Last 3 green digits with amber dashes).  NOTE: Fuel used indication on the ENG SD page in degraded mode is considered operative.
	2) Fuel Filter Clog Indications	C	2	0	

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16a  
 DATE: 03/26/2015

PAGE:  
 73-5

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
73 ENGINE FUEL & CONTROL						
30-03 Warning and Caution on ECAM EWD						
1) FUEL FILTER CLOG	C	2	1	1	(M)(O)One may be inoperative provided associated filter is replaced once each flight day or every 15 flight hours, whichever occurs first.	
2) ENG THRUST LOSS	C	1	0	0	(O)May be inoperative provided takeoff performance is based on all bleed systems selected on: - Both engine bleed air supply systems, - Both air conditioning packs, - All wing anti-ice control valves, and - Both engine anti-ice valves.	
3) <u>ENG 1(2) FADEC IDENT FAULT</u> (RR TRENT Series Engines)	C	2	0	0	(M)May be inoperative provided there is no disagreement between the associated engine identification contained in the FADEC, and the identification written on the engine plate.	
(Continued)						

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 16a

PAGE:

DATE: 03/26/2015

73-6

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
73 ENGINE FUEL & CONTROL						
30-03 Warning and Caution on ECAM EWD (Cont'd)						
4) <u>ENG 1(2)</u> LP SHAFT PROT LOSS (RR TRENT Series Engines)	B	2	1	1	One may be displayed on ECAM EWD.	
5) <u>ENG 1(2)</u> XWIND PROT FAULT (RR TRENT Series Engines)	A	2	0	0	(0)Dispatch is allowed provided: a) The <u>ENG 1(2)</u> XWIND PROT FAULT - <u>ENG 1(2)</u> SLOW RESPONSE caution was not displayed during previous airborne phase, and b) Repairs are made within a period of time not exceeding 300 flight hours, or 20 consecutive calendar days, whichever occurs first.	

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 13

PAGE:

DATE: 06/11/2013

74-1

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
74 IGNITION						
11-01	Ignition Emergency Power Supply Systems (RR TRENT Series Engines)	C	2	1	(O)Except for ER operations, one may be inoperative.	
31-01	Ignition Systems					
	1) System A					
	a) PW 4000 Series Engines (With Mod. 45686)	C	2	0	(O)May be inoperative provided: a) Associated system B operates normally, and b) Associated IGN SUPPLY selector is selected ALTN before engine start.	
	b) RR TRENT Series Engines	C	2	0	(O)May be inoperative provided associated system B operates normally.	
	2) System B	C	2	0	(O)May be inoperative.	

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 13  
DATE: 06/11/2013

PAGE:  
74-2

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
74 IGNITION						
31-02	Indications on ECAM ENGINE Page					
	1) Selected Igniter					
	a) GE CF6- 80E1, C and PW 4000 Series Engines		4	0		(M)May be inoperative provided associated ENG 1(2) IGN A(B)(A+B) FAULT caution operates normally on ECAM EWD.
	b) RR TRENT Series Engines		4	0		(M)May be inoperative provided associated ignition system is verified to operate normally.
31-03	Warning and Caution on ECAM EWD					
	1) ENG 1(2) IGN A(B) (A+B) FAULT		6	3		(M)Three may be inoperative provided associated ignition system is verified to operate normally.

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 13  
 DATE: 06/11/2012

PAGE:  
 75-1

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			2.	3. NUMBER REQUIRED FOR DISPATCH	
75 BLEED AIR					
24-01	HPTCC Valve (PW 4000 Series Engines)	C	2	0	(M)(O)May be inoperative in closed position.
24-02	LPTCC Valve (PW 4000 Series Engines)	C	2	0	(M)(O)May be inoperative in closed position.
25-01	Core Compartment Cooling Valve (GE CF6-80E1 Series Engines)	C	2	0	(M)May be inoperative in locked open position.
26-01	IDG Air Shutoff Valve (GE CF6-80E1 Series Engines)	C	2	0	(M)(O)May be inoperative in locked open position.
26-02	Nacelle Core Compartment Cooling Valve (PW 4000 Series Engines)	A	2	0	(M)May be inoperative provided: a) The associated valve is deactivated in the closed position, b) The associated ENG 1(2) CTL VALVE FAULT - NAC COOL VALVE OPEN caution is no longer displayed on ECAM EWD after maintenance action, c) The associated ENG 1(2) COOL VALVE FAULT caution is displayed on ECAM EWD after maintenance action, and d) Repairs are made within a period of time not exceeding 20 consecutive calendar days or 300 flight hours, whichever occurs first.  Note: Associated engine must be running for ENG 1(2) COOL VALVE FAULT caution to be displayed.

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 13  
DATE: 06/11/2012

PAGE:  
75-2

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
75 BLEED AIR	26-03 Warning and Caution on ECAM EWD	A	2	0	May be displayed on the ECAM EWD provided: <ul style="list-style-type: none"> <li>a) The associated ENG 1(2) COOL VALVE FAULT - IDG VALVE CLOSED caution is not displayed on ECAM EWD, and</li> <li>b) Repairs are made within a period of time not exceeding 20 consecutive calendar days or 300 flight hours, whichever occurs first.</li> </ul>
1) ENG 1(2) COOL VALVE FAULT (PW 4000 Series Engines)	A	A	2	1	May be displayed on the ECAM E/WD provided: <ul style="list-style-type: none"> <li>a) The opposite IDG operates normally, and</li> <li>b) Repairs are made within a period of time not exceeding 20 consecutive calendar days or 300 flight hours, whichever occurs first.</li> </ul>

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 13  
 DATE: 06/11/2012

PAGE:  
 77-1

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3.	NUMBER REQUIRED FOR DISPATCH	
77 ENGINE INDICATING					
00-01 ECAM Indications (EWD)					
	1) EPR Indication (PW 4000, and RR TRENT Series Engines)	C	2	0	May be inoperative provided EPR control mode is considered inoperative on both engines.
	2) Fuel Flow Indication (Without Mod. 57115/MP S30194)	A	2	1	One may be inoperative provided repairs are made within three flight days.
	3) Fuel Flow Indication (With Mod. 57115/MP S30194)	D	2	1	One may be in degraded mode (Last 3 green digits with amber dashes).
		C	2	0	NOTE: Fuel flow indication on the EWD in degraded mode is considered operative.
		C	2	0	Both may be in degraded mode (Last 3 green digits with amber dashes). NOTE: Fuel flow indication on the EWD in degraded mode is considered operative.
00-02 ECAM Indications (ENGINE Page)					
	1) Nacelle Temperature	C	2	0	
	2) N1 Vibration	C	2	1	
	3) N2 Vibration	C	2	1	
	4) N3 Vibration (RR TRENT Series Engines)	C	2	1	

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 13  
 DATE: 06/11/2012

PAGE:  
 78-1

1. SYSTEM & SEQUENCE NUMBERS	1. ITEM	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
78 ENGINE EXHAUST  30-01 Thrust Reverser Systems	1) GE CF6 80E1 and RR TRENT Engines	2	1	(M)(O)One may be inoperative provided: a) Inoperative thrust reverser is deactivated and stowed in forward thrust position, b) ENG 1 (2) REV INHIBITED caution is displayed on ECAM EWD after deactivation, c) Flight crew is provided with the following statement via appropriate means (e.g. dispatch release, MEL (O) procedure, etc.): "For a landing conducted with one deactivated thrust reverser, ensure that both engine thrust levers are retarded to the IDLE detent for the flare and the touchdown. Select both reverse control levers when applying reverse thrust.", and d) Appropriate performance adjustments are applied.  (Continued)

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 13  
 DATE: 06/11/2012

PAGE:  
 78-2

1. SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
78 ENGINE EXHAUST  30-01 Thrust Reverser Systems (Cont'd)  2) PW 4000 series Engines  a) Control	C	2	1			(M)One may be inoperative provided: a) Inoperative thrust reverser is deactivated and stowed in forward thrust position, b) ENG 1 (2) REV INHIBITED caution is displayed on ECAM EWD after deactivation, c) Flight crew is provided with the following statement via appropriate means (e.g. dispatch release, MEL (O) procedure, etc.): "For a landing conducted with one deactivated thrust reverser, ensure that both engine thrust levers are retarded to the IDLE detent for the flare and the touchdown. Select both reverse control levers when applying reverse thrust.", and d) Appropriate performance adjustments are applied.  (Continued)

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 13  
 DATE: 06/11/2012

PAGE:  
 78-3

1. SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
78 ENGINE EXHAUST  30-01 Thrust Reverser Systems (Cont'd)  2) PW 4000 series Engines (Cont'd)  b) Actuation	C	2	1		(M)One may be inoperative provided: a) Inoperative thrust reverser is deactivated and secured in the stowed position, b) ENG 1 (2) REV INHIBITED caution is displayed on ECAM EWD after deactivation, c) Flight crew is provided with the following statement via appropriate means (e.g. dispatch release, MEL (O) procedure, etc.): "For a landing conducted with one deactivated thrust reverser, ensure that both engine thrust levers are retarded to the IDLE detent for the flare and the touchdown. Select both reverse control levers when applying reverse thrust.", and d) Appropriate performance adjustments are applied.

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 13  
 DATE: 06/11/2012

PAGE:  
 78-4

1. SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
78 ENGINE EXHAUST						
30-04 Thrust Reverser Transcowl Lock (PW 4000 Series Engines)	A	4	0			(M)May be inoperative provided: a) Associated lock is secured in open position, b) Associated ENG 1(2) REV LOCKED caution is no longer displayed on ECAM EWD after maintenance action, c) ENG 1(2) REV MINOR FAULT caution is displayed on ECAM EWD after maintenance action, d) Associated thrust reverser operates normally, and e) Repairs are made within a period of time not exceeding 20 consecutive calendar days or 300 flight hours, whichever occurs first.
	C	4	2			One or both may be inoperative on one engine provided associated thrust reverser is considered inoperative.
30-05 Thrust Reverser Short Time Limited Dispatch (PW 4000 Series Engines only)	A	-	-			Dispatch is allowed with thrust reverser short time limited faults present on one or both engines (signaled by ENG 1(2) REV MINOR FAULT caution on ECAM EWD) provided repairs are made in a period of time not exceeding 300 flight hours, or 20 consecutive calendar days whichever occurs first.

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 13  
 DATE: 06/11/2012

PAGE:  
 78-5

1. SYSTEM & SEQUENCE NUMBERS ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
78 ENGINE EXHAUST				
30-06 Indications On ECAM EWD				
1) REV	C	2	1	One may be inoperative provided associated thrust reverser is considered inoperative.
30-07 Warning and Caution on ECAM EWD				
1) ENG 1(2) REV PRESSURIZED (PW 4000 Series Engines)	C	2	0	(M)(O)One or both may be displayed on the ECAM EWD provided that before each flight: a) The caution is confirmed to be false, b) The isolation valve associated with the thrust reverser having the false caution is verified to operate normally, and c) There is no ENG 1(2) REV MINOR FAULT caution associated with the thrust reverser having a false ENG 1(2) REV PRESSURIZED caution displayed on the ECAM EWD.

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14  
DATE: 05/31/2013

PAGE:  
79-1

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			2.	3. NUMBER REQUIRED FOR DISPATCH	
79	ENGINE OIL				
11-01	Engine Oil Tank Flapper Valves (PW 4000 Series Engines)	A	2	0	May be inoperative provided: a) Associated oil tank filler cap is securely latched after each servicing, and b) Repairs are made within 5 flights.
21-01	Air/Oil Heat Exchanger Valve (RR TRENT Series Engines)	C	2	1	(M)Except for ER operations, one may be inoperative in open position.
31-01	Oil Quantity Indication On ECAM				
	1) GE CF6-80E1 and PW 4000 Series Engines	B	2	1	(M)One may be inoperative provided: a) It is verified before each departure that the oil tank is filled to the recommended maximum capacity, and b) There is no evidence of abnormal consumption or leakage.
	2) RR TRENT Series Engines	B	2	1	(M)One may be inoperative provided: a) It is verified before each departure that the oil tank is filled to the recommended maximum capacity, b) There is no evidence of abnormal consumption or leakage, and c) There is no OIL LO PR SW/EEC failure message in EIVMU ground report.

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 79-2

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			3.	NUMBER REQUIRED FOR DISPATCH	
79	ENGINE OIL				
34-01	Warning and Caution on ECAM EWD				
	1) OIL LO PR (RR TRENT Series Engines)	C	2	0	
35-01	Indications on ECAM ENGINE Page				
	1) CLOG	C	2	0	

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 79-3

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED	3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
79	ENGINE OIL				
35-02	Warning and Caution on ECAM EWD				
	1) OIL FILTER CLOG				
	a) GE CF6-80E1 Series Engines	C	2	1	(M)One may be inoperative provided associated filter is changed once each flight day or every 15 flight hours whichever occurs first.
	b) RR TRENT Series Engines without MOD 56713/MP30133	A	2	1	(O)One may be displayed on the EWD for 15 flight hours provided the alert is false.
		C	2	1	(M)(O)One may be inoperative provided: a) Associated filter is changed before the first flight and then every flight day or every 15 flight hours whichever occurs first, and b) Associated master chip detector is inspected before each flight and does not reveal presence of chips from engine bearings.
(Continued)					

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 14  
 DATE: 05/31/2013

PAGE:  
 79-4

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
79 ENGINE OIL						
35-02 Warning and Caution on ECAM EWD (Cont'd)						
1) OIL FILTER CLOG (Cont'd)						
c) RR TRENT series Engines with MOD 56713/MP30133	A	2	1	1	(O)One may be displayed on the EWD for 15 flight hours provided the alert is false.	
	C	2	1	1	(M)(O)One may be inoperative provided: a) The associated ENG 1(2) OIL CHIP DETECTED alert was not displayed on the EWD during the previous landing phase, and b) Associated filter is changed before the first flight and then every flight day or every 15 flight hours whichever occurs first, and c) The associated Electronic Master Chip Detector (EMCD) is checked operative when the filter is replaced.	
d) PW 4000 Series Engines	C	2	1	1	(M)(O)One may be inoperative provided: a) Associated filter is changed once each flight day or every 15 flight hours whichever occurs first, and b) Associated master chip detector is inspected before each flight and does not reveal presence of chips from engine bearings.	
(Continued)						

AIRCRAFT:  
A330-200, A330-200F, A330-300

REVISION NO: 14

PAGE:

DATE: 05/31/2013

79-5

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		3. NUMBER REQUIRED FOR DISPATCH	4. REMARKS OR EXCEPTIONS
79 ENGINE OIL						
35-02 Warning and Caution on ECAM EWD (Cont'd)						
2) OIL CHIP DETECTED (RR TRENT Series Engines with MOD 56713/MP30133)		A	2	1	One may be displayed on the EWD for 40 flight hours or three consecutive calendar days, whichever occurs first.	
		A	2	1	One may be inoperative on the EWD for 300 flight hours or twenty consecutive calendar days, whichever occurs first, provided the alert is false.	

U.S. DEPARTMENT OF TRANSPORTATION  
 FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

AIRCRAFT:  
 A330-200, A330-200F, A330-300

REVISION NO: 9  
 DATE: 09/26/2007

PAGE:  
 80-1

SYSTEM & SEQUENCE NUMBERS	ITEM	1.	2. NUMBER INSTALLED		4. REMARKS OR EXCEPTIONS
			2.	3. NUMBER REQUIRED FOR DISPATCH	
80 STARTING					
11-01	Start Valve	C	2	1	(M)(O)One may be inoperative provided valve is manually closed after engine start.
11-02	ENG MAN START Control	C	2	0	
11-03	FAULT Light on ENG MASTER PANEL	C	2	0	
11-04	Indications on ECAM ENGINE Page				
	1) Start Valve Position Indication	C	2	0	(M)(O)May be inoperative provided associated start valve is verified closed after engine start.