

Revision: 5a
Date: 04/20/2009

DEPARTMENT OF TRANSPORTATION
FEDERAL AVIATION ADMINISTRATION
WASHINGTON, D.C.

MASTER MINIMUM EQUIPMENT LIST

HAWKER BEECHCRAFT

BE-1900D

John Vetter
Chairman, Flight Operations Evaluation Board
(FOEB)

Federal Aviation Administration
Aircraft Evaluation Group
DOT Building, Room 332
901 Locust Street
Kansas City, MO 64106-2641

Telephone: (816)-329-3233
FAX: (816)-329-3241

TABLE OF CONTENTS

SYSTEM NO.	SYSTEM	PAGE NO.
--	Table of Contents	I
--	Log of Revisions	II, III, IV
--	Control Page	V, VI
--	Highlights of Change	VII
--	Definitions	VIII
--	Preamble	IX
--	Guidelines for (O) & (M) Procedures	X THRU XVI
21	Air Conditioning	21-1, 2, 3, 4, 5
22	Auto Flight	22-1
23	Communications	23-1, 2, 3, 4
24	Electrical Power	24-1, 2
25	Equipment/Furnishings	25-1, 2, 3, 4, 5
25	Equipment/Furnishings	25-6
26	Fire Protection	26-1, 2
27	Flight Controls	27-1, 2
28	Fuel	28-1, 2, 3, 4, 5
30	Ice and Rain Protection	30-1, 2, 3, 4
31	Indicating/Recording Systems	31-1, 2, 3, 4
32	Landing Gear	32-1, 2
33	Lights	33-1, 2, 3
34	Navigation	34-1, 2, 3, 4, 5
34	Navigation	34-6 THRU 10
35	Oxygen	35-1
37	Vacuum/Pressure	37-1, 2
38	Water/Waste	38-1
52	Doors	52-1
56	Windows	56-1
61	Propellers	61-1
73	Engine Fuel & Control	73-1
74	Ignition	74-1
77	Engine Indicating	77-1

DEPARTMENT OF TRANSPORTATION

MASTER MINIMUM EQUIPMENT LIST

FEDERAL AVIATION ADMINISTRATION

AIRCRAFT: HAWKER BEECHCRAFT
BE-1900DREVISION: 5
DATE: 02/07/2006PAGE NO:
II

Log of Revisions

Rev No.	Date	Page Numbers	Initials
0a	02/14/1992	HIGHLIGHTS OF REV.	
0a	02/14/1992	23-2	
0b	04/30/1992	HIGHLIGHTS OF REV.,GUIDELINES	
0b	04/30/1992	28-2	
0c	07/23/1993	HIGHLIGHTS OF REV.,DEFINITIONS	
0c	07/23/1993	GUIDELINES	
0c	07/23/1993	21-1,21-2,21-3,22-1,23-1	
0c	07/23/1993	23-2,24-1,24-2,25-1,25-2	
0c	07/23/1993	26-1,27-1,27-2,28-1,28-2	
0c	07/23/1993	30-1,30-2,30-3,30-4,31-1	
0c	07/23/1993	32-1,33-1,33-2,33-3,34-1	
0c	07/23/1993	34-2,34-3,34-4,35-1,37-1	
0c	07/23/1993	52-1,61-1	
0d	12/15/1993	HIGHLIGHTS OF REV.,GUIDELINES	
0d	12/15/1993	21-1,21-2,21-3,23-1,23-2	
0d	12/15/1993	24-1,28-1,31-1,33-1,33-2	
0d	12/15/1993	33-3,34-4,52-1	
0e	05/24/1994	HIGHLIGHTS OF REV.,GUIDELINES	
0f	10/28/1994	HIGHLIGHTS OF REV.,GUIDELINES	
0f	10/28/1994	30-1,30-2,30-3,30-4	
0g	12/08/1995	HIGHLIGHTS OF REV.,DEFINITIONS	
0g	12/08/1995	GUIDELINES	
0g	12/08/1995	34-3,34-4,52-1	
0h	02/15/1996	HIGHLIGHTS OF REV.,DEFINITIONS	
0h	02/15/1996	GUIDELINES	
0h	02/15/1996	23-2,23-3,30-1,30-2,30-3	
0h	02/15/1996	30-4,77-1	
0i	03/18/1997	HIGHLIGHTS OF REV.,DEFINITIONS	
0i	03/18/1997	25-1,25-2,26-1,32-2,33-1	
0i	03/18/1997	34-1,34-2,34-3,34-4	
0j	06/09/1997	HIGHLIGHTS OF REV.,DEFINITIONS	
0j	06/09/1997	23-1,28-2,33-2,33-3,34-2	
1	11/03/1998	HIGHLIGHTS OF REV.,DEFINITIONS	
1	11/03/1998	GUIDELINES	
1	11/03/1998	21-1,21-2,21-3,22-1,23-1	
1	11/03/1998	23-2,23-3,24-1,24-2,25-1	
1	11/03/1998	25-2,25-3,26-1,27-1,27-2	
1	11/03/1998	28-1,28-2,28-3,28-4,30-1	
1	11/03/1998	30-2,30-3,31-1,31-2,32-1	
1	11/03/1998	32-2,33-1,33-2,33-3,34-1	
1	11/03/1998	34-2,34-3,34-4,34-5,35-1	
1	11/03/1998	37-1,52-1,56-1,61-1,74-1	
1	11/03/1998	77-1	

DEPARTMENT OF TRANSPORTATION

MASTER MINIMUM EQUIPMENT LIST

FEDERAL AVIATION ADMINISTRATION

AIRCRAFT: HAWKER BEECHCRAFT
BE-1900DREVISION: 5
DATE: 02/07/2006PAGE NO:
III

Log of Revisions

Rev No.	Date	Page Numbers	Initials
2	10/25/1999	HIGHLIGHTS OF REV.,DEFINITIONS	
2	10/25/1999	GUIDELINES	
2	10/25/1999	21-1,21-2,21-3,22-1,25-1	
2	10/25/1999	25-2,25-3,25-4,27-1,28-3	
2	10/25/1999	31-1,31-2,33-1,33-2,33-3	
2	10/25/1999	34-1,34-2,34-3,34-4,34-5	
2	10/25/1999	34-6,56-1,61-1,74-1	
3	04/11/2000	HIGHLIGHTS OF REV.,DEFINITIONS	
3	04/11/2000	PREAMBLE,GUIDELINES	
3	04/11/2000	22-1,56-1	
3a	09/18/2001	HIGHLIGHTS OF REV.,DEFINITIONS	
3a	09/18/2001	GUIDELINES	
3a	09/18/2001	21-1,21-2,21-3,21-4,21-5	
3b	02/15/2002	HIGHLIGHTS OF REV.,DEFINITIONS	
3b	02/15/2002	GUIDELINES	
3b	02/15/2002	21-1,21-2,21-3,21-4,21-5	
3b	02/15/2002	34-1,34-2,34-3,34-4,34-5	
3b	02/15/2002	34-6,34-7	
4	07/30/2002	HIGHLIGHTS OF REV.,DEFINITIONS	
4	07/30/2002	GUIDELINES	
4	07/30/2002	21-1,21-2,21-3,21-4,21-5	
4	07/30/2002	22-1,23-1,23-2,23-3,23-4	
4	07/30/2002	24-1,24-2,25-1,25-2,25-3	
4	07/30/2002	25-4,25-5,25-6,26-1,26-2	
4	07/30/2002	27-1,27-2,28-1,28-2,28-3	
4	07/30/2002	28-4,28-5,30-1,30-2,30-3	
4	07/30/2002	30-4,31-1,31-2,31-3,31-4	
4	07/30/2002	32-1,32-2,33-1,33-2,33-3	
4	07/30/2002	34-1,34-2,34-3,34-4,34-5	
4	07/30/2002	34-6,34-7,34-8,34-9,34-10	
4	07/30/2002	35-1,37-1,37-2,38-1,52-1	
4	07/30/2002	56-1,61-1,73-1,74-1,77-1	
4a	10/04/2004	HIGHLIGHTS OF REV.,DEFINITIONS	
4a	10/04/2004	GUIDELINES	
4a	10/04/2004	22-1,25-1,25-2,25-3,25-4	
4a	10/04/2004	25-5,25-6,26-1,26-2,27-1	
4a	10/04/2004	27-2,28-1,28-2,28-3,28-4	
4a	10/04/2004	28-5,30-1,30-2,30-3,30-4	
4a	10/04/2004	31-1,31-2,31-3,31-4,33-1	
4a	10/04/2004	33-2,33-3,34-1,34-2,34-3	
4a	10/04/2004	34-4,34-5,34-6,34-7,34-8	
4a	10/04/2004	34-9,34-10,37-1,37-2,38-1	
4a	10/04/2004	52-1,56-1,73-1,74-1	

Log of Revisions

Rev No.	Date	Page Numbers	Initials
4b	12/14/2004	HIGHLIGHTS OF REV.,DEFINITIONS	
4b	12/14/2004	27-2	
5	02/07/2006	Log of Revisions	
5	02/07/2006	Control Page	
5	02/07/2006	Highlights of Change	
5	07/05/2005	Definitions	
5	02/07/2006	Guidelines for (O) & (M) Procedures	
5	02/07/2006	21-1, 21-2, 21-3, 21-4, 21-5, 22-1, 23-1, 23-2, 23-3, 23-4, 24-1, 24-2, 25-1, 25-2, 25-3, 25-4, 25-5, 25-6, 26-1, 26-2, 27-1, 27-2, 28-1, 28-2, 28-3, 28-4, 28-5, 30-1, 30-2, 30-3, 30-4, 31-1, 31-2, 31-3, 31-4, 32-1, 32-2, 33-1, 33-2, 33-3, 34-1, 34-2, 34-3, 34-4, 34-5, 34-6, 34-7, 34-8, 34-9, 34-10, 34-11, 34-12, 35-1, 37-1, 37-2, 38-1, 52-1, 59-1, 61-1, 73-1, 74-1, 77-1.	
5a	04/20/2009	Log of Revisions, Control Page, Highlights of Change, Definitions, Preamble, Guidelines for (O)&(M) Procedures, 28-1, 35-1	

DEPARTMENT OF TRANSPORTATION

MASTER MINIMUM EQUIPMENT LIST

FEDERAL AVIATION ADMINISTRATION

AIRCRAFT: HAWKER BEECHCRAFT
BE-1900DREVISION: 5a
DATE: 04/20/2009PAGE NO:
V

Control Page

System	Page No.	Rev. No.	Current Date
Cover Page	-	5a	04/20/2009
Table of Contents	I	5a	04/20/2009
Log of Revisions	II	5	02/07/2006
	III	5	02/07/2006
	IV	5a	04/20/2009
Control Page	V	5a	04/20/2009
	VI	5a	04/20/2009
Highlights of Change	VII	5a	04/20/2009
Definitions	VIII	5a	04/20/2009
Preamble	IX	5a	04/20/2009
Guidelines for (O) & (M) Procedures	X	5a	04/20/2009
	XI	5	02/07/2006
	XII	5	02/07/2006
	XIII	5a	04/20/2009
	XIV	5	02/07/2006
	XV	5a	04/20/2009
	XVI	5	02/07/2006
21	21-1	5	02/07/2006
	21-2	5	02/07/2006
	21-3	5	02/07/2006
	21-4	5	02/07/2006
	21-5	5	02/07/2006
22	22-1	5	02/07/2006
23	23-1	5	02/07/2006
	23-2	5	02/07/2006
	23-3	5	02/07/2006
	23-4	5	02/07/2006
24	24-1	5	02/07/2006
	24-2	5	02/07/2006
25	25-1	5	02/07/2006
	25-2	5	02/07/2006
	25-3	5	02/07/2006
	25-4	5	02/07/2006
	25-5	5	02/07/2006
	25-6	5	02/07/2006
26	26-1	5	02/07/2006
	26-2	5	02/07/2006

DEPARTMENT OF TRANSPORTATION

MASTER MINIMUM EQUIPMENT LIST

FEDERAL AVIATION ADMINISTRATION

AIRCRAFT: HAWKER BEECHCRAFT
BE-1900DREVISION: 5a
DATE: 04/20/2009PAGE NO:
VI

Control Page

System	Page No.	Rev. No.	Current Date
27	27-1	5	02/07/2006
	27-2	5	02/07/2006
28	28-1	5a	04/20/2009
	28-2	5	02/07/2006
	28-3	5	02/07/2006
	28-4	5	02/07/2006
	28-5	5	02/07/2006
30	30-1	5	02/07/2006
	30-2	5	02/07/2006
	30-3	5	02/07/2006
	30-4	5	02/07/2006
31	31-1	5	02/07/2006
	31-2	5	02/07/2006
	31-3	5	02/07/2006
	31-4	5	02/07/2006
32	32-1	5	02/07/2006
	32-2	5	02/07/2006
33	33-1	5	02/07/2006
	33-2	5	02/07/2006
	33-3	5	02/07/2006
34	34-1	5	02/07/2006
	34-2	5	02/07/2006
	34-3	5	02/07/2006
	34-4	5	02/07/2006
	34-5	5	02/07/2006
	34-6	5	02/07/2006
	34-7	5	02/07/2006
	34-8	5	02/07/2006
	34-9	5	02/07/2006
	34-10	5	02/07/2006
	34-11	5	02/07/2006
	34-12	5	02/07/2006
35	35-1	5a	04/20/2009
37	37-1	5	02/07/2006
38	38-1	5	02/07/2006
52	52-1	5	02/07/2006
56	56-1	5	02/07/2006
61	61-1	5	02/07/2006
73	73-1	5	02/07/2006
74	74-1	5	02/07/2006
77	77-1	5	02/07/2006
	37-2	5	02/07/2006

HIGHLIGHTS OF CHANGE

Definitions	Change format of DEFINITIONS section to accommodate new FSIMS MMEL distribution format.
Preamble	Change format of PREAMBLE section to accommodate new FSIMS MMEL distribution format.
Guidelines (O)&(M)	Update introduction to Guidelines for (O) & (M) Procedures.
28-1	Change Remarks to require operative Standby Electric Boost Pump. Add (O) procedure to configure and check Standby Electric Boost Pump. Revise Guidelines for (O) & (M) procedure for Engine Driven Low Pressure Fuel Boost Pump failure.
35-1	Change Oxygen System description to Passenger Oxygen System and add NOTE to specify requirement for Cockpit Crew Oxygen.
35-2	Change External Oxygen Gauge Remarks to remove inappropriate identification of personnel and add (M).
35-4	Add relief for PBE IAW PL-43.

DEPARTMENT OF TRANSPORTATION		MASTER MINIMUM EQUIPMENT LIST
FEDERAL AVIATION ADMINISTRATION		
AIRCRAFT: HAWKER BEECHCRAFT BE-1900D	REVISION: 5a DATE: 04/20/2009	PAGE: VIII
DEFINITIONS		

The Definitions must be inserted here in each Minimum Equipment List (MEL) from current FAA MMEL Policy Letter PL-25, MMEL DEFINITIONS in accordance with current FAA MMEL Policy Letter PL-70, DEFINITIONS REQUIRED IN MELs.

DEPARTMENT OF TRANSPORTATION		MASTER MINIMUM EQUIPMENT LIST
FEDERAL AVIATION ADMINISTRATION		
AIRCRAFT: HAWKER BEECHCRAFT BE-1900D	REVISION: 5a DATE: 04/20/2009	PAGE NO: IX
PREAMBLE		

The applicable Preamble must be inserted here in each Minimum Equipment List (MEL) from current FAA MMEL Policy Letter PL-34, MMEL AND MEL PREAMBLE or PL-36, FAR PART 91MEL APPROVAL AND PREAMBLE

DEPARTMENT OF TRANSPORTATION		MASTER MINIMUM EQUIPMENT LIST
FEDERAL AVIATION ADMINISTRATION		
AIRCRAFT: HAWKER BEECHCRAFT BE-1900D	REVISION: 5a DATE: 04/20/2009	PAGE NO: X
Guidelines for (O) & (M) Procedures		

The FOEB has identified a need for certain procedures to provide an adequate level of safety while providing relief for some items. These procedures must be established by the operator and may be based on the aircraft manufacturer's recommended procedures, Supplemental Type Certificate modifier's recommended procedures, or equivalent operator procedures. When recommended procedures are published the operator should comply with these procedures. If recommended procedures are not published, the following guidelines delineate the aspects to be considered by the operator in the development of required procedures.

21-3-1	(O) Procedure to verify environmental and instrument air valves are closed prior to each flight.
21-3-2	(O) Procedure to verify environmental and instrument air valves are closed prior to each flight and to either extinguish or mask illuminated annunciator.
21-4	(O) Procedure to verify appropriate environmental bleed air valve is closed prior to every flight and either extinguish or mask illuminated annunciator, if applicable.
21-5	(O) Procedure to extinguish or mask illuminated annunciator, if applicable.
21-8	(M) Procedure for removing or securing outflow/safety valve in the open position.
21-9	(M) Procedure for removing or securing outflow/safety valve in the open position.
21-9-1	(O) Procedure to ensure each crew (and dispatcher if applicable) is aware of pressurization capability and/or limitations.
21-9-2	(O) Procedure to ensure each crew (and dispatcher if applicable) is aware of pressurization capability and/or limitations.
21-9-3	(O) Procedure to ensure each crew (and dispatcher if applicable) is aware of pressurization capability and/or limitations.
21-9-4	(O) Procedure to ensure first flight is planned assuming aircraft will not pressurize. If aircraft pressurizes normally, appropriate adjustments can be made to the flight plan. Coordination with dispatch, if applicable, should be accomplished. Procedure to ensure each crew (and dispatcher if applicable) is aware of pressurization capability and/or limitations.
21-14	(O) Procedure to verify affected environmental bleed air valve(s) is/are closed prior to each flight.

Guidelines for (O) & (M) Procedures

21-17	(O) Procedure to extinguish or mask illuminated annunciator, if applicable.
22-1	(M) Procedure to disable the autopilot and determine that the servos do not cause binding of the control cables.
22-2	(O) Procedure to disable Rudder Boost function. (M) Procedure to disable the yaw damper and determine that the rudder servo does not cause binding of the control cables. Acceptable procedure: Move rudder pedals through full travel to ensure no restrictions and pull and band "servo" circuit breaker.
22-2-1	(O) Procedure to disable the rudder boost function.
22-2-2	(M) Procedure to disable the yaw damper and determine that the rudder servo does not cause binding of the control cables. Acceptable procedure: Same as 22-2 above.
22-2-3	(M) Procedure to disable the yaw damper and determine that the rudder servo does not cause binding of the control cables. Acceptable procedure: Same as 22-2 above.
22-2-4	(M) Procedure to disable the yaw damper and determine that the rudder servo does not cause binding of the control cables. Acceptable procedure: Same as 22-2 above.
23-1	(O) Procedure to specify how passengers are to be briefed and to operate within the MMEL restrictions.
23-12	(O) Procedure to ensure remaining Long Range Communications System(s) operate normally.
24-3	(O) Procedure to ensure that the electrical load is less than 50% on the operative side generator prior to take-off and at all times during flight and that loads are not added if the generator on the operative side fails.
24-6	(M) Procedure to ensure ground power relay is open.
24-7	(O) Procedure to ensure connection and disconnection of power cart is verified.
24-9	(O) Procedure to verify generator bus tie relay is closed.
25-1-2	(O) Procedure to ensure crew awareness of inoperative restraining bar.

Guidelines for (O) & (M) Procedures

- | | |
|-------|---|
| 25-2 | (M)Procedure to secure the ELT to preclude false operation. |
| 25-10 | (M)Procedure to ensure seat is locked in the appropriate position. |
| 25-13 | (O)Procedure to ensure crew awareness of specific airspeed information. |
| 25-14 | (M)Procedure to lock the rudder pedals in a position that allows full rudder pedal movement. |
| 25-17 | (O)Procedure to ensure sufficient waste receptacles are available for the intended flight.
(M)Procedure to secure access to the affected waste receptacle. |
| 25-20 | (M)Procedure to secure the compartment/closet in closed position. |
| 25-21 | (M)Procedure to ensure that cargo is not secured by an inoperative cargo restraint system. |
| 26-3 | (O)Procedure to ensure waste receptacle is empty and lavatory is used by crewmembers only.
(M)Procedure to lock and placard Lavatory Door. |
| 26-4 | (O)Procedure to ensure waste receptacle is empty and Lavatory is used by crewmembers only.
(M)Procedure to lock and placard Lavatory Door. |
| 27-2 | (O)Procedure to verify the flaps are secure and in the UP position, the circuit breaker is pulled and a placard is installed which states the following: "DO NOT SILENCE THE LANDING GEAR WARNING HORN". The placard should be installed near the landing gear warning horn silence button. |
| 27-4 | (O)Procedure to ensure there is no binding of the trim cables prior to each flight.
Acceptable procedure: Manually operate trim full travel and visually observe to verify full travel. |

Guidelines for (O) & (M) Procedures

- | | |
|--------|--|
| 28-1 | <p>(O) Operations procedure to ensure Standby Electric Boost Pump is operative and Fuel Low Pressure light is operative and extinguished</p> <p>(M) Procedure to determine there is no fuel leak, the Low Pressure Pump has disconnected (shaft has sheared), pump failure did not introduce debris into the fuel system, and the Fuel Pressure Low annunciator is extinguished by use of the Standby Electric Fuel Pump with the engine operating at takeoff power.</p> |
| 28-5-1 | <p>(O) Procedure to deactivate the pump and ensure no electrical power is supplied to it.</p> <p>Procedure to ensure auxiliary fuel is balanced prior to each flight and is considered unusable for flight planning purposes.</p> |
| 28-7 | <p>(O) Procedure to ensure fuel balance is maintained within AFM limits.</p> <p>Acceptable procedure: Fill fuel tanks and calculate fuel burn from full tanks.</p> |
| 28-7-1 | <p>(O) Procedure to ensure fuel balance is maintained within AFM limits.</p> <p>Acceptable procedure: Fill fuel tanks and calculate fuel burn from full tanks.</p> |
| 28-7-2 | <p>(O) Procedure to ensure fuel balance is maintained within AFM limits.</p> |
| 30-2 | <p>(O) Procedure to determine inoperative motor does not affect other actuator motor.</p> <p>(O) Procedure to ensure ice vanes are in the extended position.</p> <p>(M) Procedure to secure vanes in the extended position.</p> |
| 30-4-1 | <p>(O) Procedure for flight crewmember to verify operation of Inertial Ice Vane prior to each departure.</p> <p>(M) Procedure to secure vanes in the extended position.</p> |
| 30-4-2 | <p>(M) Procedure to secure vanes in the extended position</p> |
| 30-6 | <p>(M) Procedure to ensure affected windshield has an effective hydrophobic coating each flight day of operation without operative Windshield Wipers.</p> |
| 30-12 | <p>(M) Procedure to secure shutoff valves in the closed position and secure circuit breaker.</p> |

Guidelines for (O) & (M) Procedures

- | | |
|---------|---|
| 31-2 | (O)Procedure for recording aircraft time for maintenance purposes. |
| 31-5 | (O)Procedure to check operation of individual circuits. |
| 31-11 | (M)Procedure to pull and collar CB in the open position.
(O)Procedure to ensure that aircraft time entries are made in the aircraft flight log. |
| 32-1 | (O)Procedure to ensure crew and dispatcher awareness for compliance with MMEL restrictions and AFM procedures.
(M)Procedure to ensure nose wheel is in the free caster mode and secure circuit breaker. |
| 32-1-1 | (O)Procedure to ensure crew and dispatcher awareness for compliance with MMEL restrictions and AFM procedures |
| 32-1-2 | (O)Procedure to ensure crew awareness that nose steering is in the free caster mode and for compliance with MMEL restrictions and AFM procedures
(M)Procedure to ensure nose wheel is in the free caster mode and secure circuit breaker. |
| 32-4 | (O)Procedure to ensure crew awareness of change in nose wheel steering and for compliance with MMEL restrictions.
(M)Procedure to disconnect and secure actuator. |
| 32-5 | (M)Maintenance procedure to check hydraulic fluid level at the time of discovery and prior to the first flight of the day.
(O)Procedure to check for leaks prior to and after each flight. |
| 32-7 | (O)Procedures to secure aircraft during ground emergencies and prior to releasing toe brakes during normal operations. |
| 32-8 | (O)Procedure to ensure crew awareness of the requirement to manually move the down lock latch. |
| 33-2-3 | (O)Procedure to verify switch function is operative. |
| 34-3 | (O)Procedure to ensure crew awareness of the need to regularly check/reset directional gyro.
NOTE: Do NOT select the Heading input (with the HD Reversionary Switch) of the affected Flightdeck Heading Indicator to a single, common gyro heading source. This is NOT permitted because it reduces the heading source redundancy. |
| 34-12-1 | (O)Procedure to ensure crew awareness of inoperative G0-AROUND mode. |

Guidelines for (O) & (M) Procedures

- | | |
|-------------------|---|
| 34-13 | (O)Operations procedure to ensure autopilot hold is operative and enroute operations do not require its use. |
| 34-15 | (M)Procedure to deactivate and secure the system.
(O)Procedure to operate without TCAS I system. |
| 34-16 | (M)Procedure to deactivate and secure the system.
(O)Procedure to operate without TCAS II system. |
| 34-16-2 | (O)Procedure to ensure non-flying pilot monitors pilot display.
(O)Procedure to ensure TA ONLY mode is selected and all TA functions/elements are operative. |
| 34-16-3 | (O)Procedure to ensure all RA display/functions are operative. |
| 34-19-1 | (O)Procedure to ensure crew awareness of inoperative GPWS and alternate methods for ground proximity awareness. |
| 34-19-1-a | (O)Procedure for crew awareness of inoperative mode(s) and alternate methods of operating without the inoperative mode(s). |
| 34-19-1-d | (O)Procedure to establish alternate methods of operating without advisory callouts. |
| 34-19-1-e | (O)Procedure to establish alternate method of operating without the windshear mode. |
| 34-19-2 | (O)Procedure for crew awareness of inoperative FLTA / PDA and alternate method for terrain awareness. |
| 34-19
C | (O)Procedure to verify Test Mode is functional with crew awareness of which modes are operative / inoperative. Establish alternate methods to operate without affected modes.(e.g., TAWS, GPWS modes, Windshear, FLTA/PDA, as applicable) |
| 34-21 | (O)Procedure to establish alternate method of operating without the Multifunction Display (MFD). |
| 34-24-1&2 | (O)Procedure to operate with expired Navigation Databases. |
| 35-2 | (M) Procedure to use the oxygen pressure gauge in the cockpit during servicing. |
| 35-3 | (M)Procedure to prohibit oxygen flow from affected outlet. |

Guidelines for (O) & (M) Procedures

- 37-1 (O) Procedure to insure Left and Right Instrument Air Sources are operative prior to each departure.
- 37-2 (O) Procedure to verify inoperative valve is in the closed position.
- 37-3 (O) Procedure to ensure L&R Instrument Air Sources are operative and all provisos are complies with prior to each flight.
- (O) Procedure to ensure L&R Instrument Air Sources are operative and all provisos are complies with prior to each flight.
- 38-1 (M) Procedure to deactivate the affected components and ensure there are no leaks.
- (M) Procedure to drain and ensure the system is not serviced.
- 38-2 (M) Procedure to deactivate the affected components and ensure there are no leaks.
- (M) Procedure to deactivate the associated components to prevent leaks and to placard the Lavatory Door.
- 52-4 (O) Procedure to manually lower the Main Cabin Door in such a manner as to prevent personal injury and aircraft damage.
- 52-6 (M) Procedure to remove Cargo Door Snubber and Placard Cargo Door near the handle to warn ground personnel that the CDS is inoperative.
- 56-1 (O) Procedure to ensure that AFM Limitations are complied with.
- 56-2 (O) Procedure to ensure that AFM Limitations are complied with.
- 73-1 (O) Procedure to determine inoperative condition is not caused by a leak or broken fuel line.

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY				4. REMARKS AND EXCEPTIONS
	2. NUMBER INSTALLED			3. NUMBER REQUIRED FOR DISPATCH	
21 AIR CONDITIONING					
1. Air Cycle Air Conditioning System	C	1	0		May be inoperative for unpressurized flight provided the Environmental Bleed Air Valves are closed.
2. Vapor Cycle Air Conditioning System	C	1	0		
3. L or R BL AIR FAIL Annunciator System					
1) Annunciator fails to illuminate	B	2	1		(O) One may be inoperative provided: a) Environmental and Instrument Bleed Air Valves on inoperative side are verified closed before each flight, and b) Aircraft is not operated in known or forecast icing conditions.
2) Annunciator remains illuminated	B	2	1		(O) One may be illuminated provided: a) Environmental and Instrument Bleed Air Valves on inoperative side are verified closed before each flight, and b) Aircraft is not operated in known or forecast icing conditions.
4. L or R ENVIR FAIL Annunciator Systems	C	2	1		(O) One may be inoperative provided Environmental Bleed Air Valve on inoperative side is closed.

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY			
	2. NUMBER INSTALLED			
	3. NUMBER REQUIRED FOR DISPATCH			
	4. REMARKS AND EXCEPTIONS			
21 AIR CONDITIONING				
5. CABIN ALT HI Annunciator System	C	1	0	(O) May be inoperative for pressurized flight: a) At or below 10,000 feet MSL, and b) Above 10,000 feet MSL up to and including 12,000 feet MSL for not more than 30 minutes.
	C	1	0	May be inoperative for unpressurized flight in accordance with FAR.
6. Cabin Rate of Climb Indicator	C	1	0	May be inoperative for pressurized flight provided Differential Pressure/Cabin Altitude Indicator is operative.
	C	1	0	May be inoperative for unpressurized flight provided the dump valve is in the open position.
7. Differential Pressure/Cabin Altitude Indicator	C	1	0	May be inoperative for unpressurized flight provided the dump valve is in the open position.
8. Outflow/Safety Valves	C	2	0	(M) May be inoperative for unpressurized flight provided one valve is removed or secured in the open position.

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY				4. REMARKS AND EXCEPTIONS
	2. NUMBER INSTALLED			3. NUMBER REQUIRED FOR DISPATCH	
21 AIR CONDITIONING					
9. Pressurization System	C	1	0	(M) May be inoperative provided one Outflow/Safety valve is removed or secured in the open position.	
1) Maximum Pressure Differential Function	C	1	0	(O) May be inoperative, resulting in failure to achieve maximum pressure differential, provided: a) Available stabilized maximum differential must be known and considered for dispatch flight planning, and b) Cabin Altitude does not exceed 9,500 feet.	
	C	1	0	May be inoperative provided flight remains at or below 10,000 feet MSL. NOTE: Any available pressurization capability may be used provided system limits are not exceeded.	
2) Cabin Pressure Control Function	C	1	0	(O) May be inoperative, resulting in failure to pressurize at selected altitude, provided system can maintain cabin altitude at or below 9,500 feet. NOTE: Any available pressurization capability may be used provided system limits are not exceeded.	
3) Cabin Rate Control Function	C	1	0	(O) May be inoperative, resulting in disagreement between selected rate and actual rate, provided system can maintain cabin altitude at or below 9,500 feet. NOTE: Any available pressurization capability may be used provided system limits are not exceeded.	
(Continued)					

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY			
	2. NUMBER INSTALLED			
	3. NUMBER REQUIRED FOR DISPATCH			
	4. REMARKS AND EXCEPTIONS			
21 AIR CONDITIONING				
9. Pressurization System (Continued)				
3) Cabin Rate Control Function	C	1	0	(O) May be inoperative, resulting in fluctuations of rate indicator, provided: a) System can maintain cabin altitude at or below 9,500 feet, and b) Fluctuation cannot cause cabin pressure to exceed maximum differential. NOTE: Any available pressurization capability may be used provided system limits are not exceeded.
4) Cabin Pressure TEST Function	C	1	0	(O) May be inoperative provided system can maintain cabin altitude at or below 9,500 feet. NOTE: Any available pressurization capability may be used provided system limits are not exceeded.
10. Environmental Temperature Control	C	1	0	May be inoperative for unpressurized flight provided the Environmental Bleed Air Valves are closed.
1) Automatic Function	C	1	0	May be inoperative provided the Manual Function is operative.
2) Manual Function	C	1	0	May be inoperative provided the Automatic Function is operative.

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY				4. REMARKS AND EXCEPTIONS
	2. NUMBER INSTALLED			3. NUMBER REQUIRED FOR DISPATCH	
21 AIR CONDITIONING					
11. Manual Temperature Control					DELETED Combined with Item 21-10
12. Vent Blowers	C	2	0		
13. Cabin Temperature Gauge	C	1	0		
14. Environmental Bleed Air Systems	C	2	1		(O) One may be inoperative provided: a) Environmental Bleed Air Valve on inoperative side is closed, and b) ENVIR FAIL Annunciator is operative on operative Environmental Bleed Air System.
	C	2	0		(O) May be inoperative for unpressurized flight provided all Environmental Bleed Air Valves are closed.
15. Precooler and Bypass Valve Systems					DELETED Revision 1. Combined with Item 21-14.
16. L or R ENVIR OFF Annunciator Systems	C	2	1		One may be inoperative.
17. CAB DIFF HI Annunciator System	C	1	0		(O)

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY				4. REMARKS AND EXCEPTIONS
	2. NUMBER INSTALLED			3. NUMBER REQUIRED FOR DISPATCH	
22 AUTO FLIGHT					
1. Autopilot System ***	C	-	0		(M) May be inoperative provided operations do not require its use.
1) Autopilot Disconnect	C	2	0		May be inoperative provided the autopilot is no utilized at less than initial approach altitude.
2. Yaw Damper/Rudder Boost System	C	1	0		(O)(M)
1) Rudder Boost Function Only	C	1	0		(O)
2) Yaw Damper Function Only	C	1	0		(M)
3) LEFT/RIGHT YAW DAMP Computers	C	2	1		One may be inoperative provided the operative computer is selected.
	C	2	0		(M)
4) Single YAW DAMP *** Computer	C	1	0		(M)
3. Rudder Boost					DELETED Revision 1. Combined with Yaw Damper System.

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY			
	2. NUMBER INSTALLED			
	3. NUMBER REQUIRED FOR DISPATCH			
	4. REMARKS AND EXCEPTIONS			
23 COMMUNICATIONS				
1. Passenger Address *** System				
1) Passenger Carrying Operations	C	1	-	(O) May be inoperative provided: a) PA not required by FAR, and b) Alternate, normal and emergency procedures, and/or operating restrictions are established and used. NOTE: Any station that operates normally may be used.
2) Other Operations	D	1	0	May be inoperative unless procedures require its use.
2. Recorded Passenger *** Briefing Unit	D	-	0	
3. Static Discharge Wicks	C	-	17	Any combination of wicks may be missing or broken except: a) 4 on each wing (includes aileron and winglet), b) 3 on each side of horizontal stabilizer (includes taillet), c) 1 on horizontal stabilizer aft bullet, and d) 1 on each ventral fin.
4. Communications Equipment (VHF, UHF)	D	-	-	Any in excess of those required by FAR may be inoperative provided it is not powered by an Emergency Power Supply and is not required for Emergency Procedures.

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY				4. REMARKS AND EXCEPTIONS
	2. NUMBER INSTALLED			3. NUMBER REQUIRED FOR DISPATCH	
23 COMMUNICATIONS					
5. Flight Deck Speakers	C	2	1	0	One may be inoperative.
	C	2	0	0	May be inoperative provided an operative headset is used by each flight crewmember.
6. Cockpit Voice Recorder *** (CVR)					
1) With Flight Data Recorder (FDR) Installed	A	1	0	0	May be inoperative provided: a) Flight Data Recorder (FDR) operates normally, and b) Repairs are made within three flight days.
2) Without Flight Data Recorder (FDR) Installed	A	1	0	0	May be inoperative provided repairs are made within three flight days.
3) Installed for an operator other than a holder of an Air Carrier or Commercial Operator certificate	A	1	0	0	May be inoperative provided repairs are made in accordance with applicable FARs.
7. GND COMM PWR *** System	D	1	0	0	
8. Crew Intercom System	B	1	0	0	May be inoperative for operations not using or requiring a second-in-command.
9. SELCAL/CALSEL *** Systems	C	1	0	0	

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY			
	2. NUMBER INSTALLED			
	3. NUMBER REQUIRED FOR DISPATCH			
	4. REMARKS AND EXCEPTIONS			
23 COMMUNICATIONS				
10. Push to Talk Switch (Radio)				
1) Aircraft equipped with separate hand held microphone plug-in (Second-in-command required)	C	2	1	One may be inoperative provided hand microphone on affected side is operative.
2) Aircraft equipped with separate hand held microphone plug-in (Second-in-command not required)	C	2	1	Right side may be inoperative.
3) Aircraft without separate hand held microphone plug-in (Second in command not required.)	C	2	1	Right side may be inoperative.
11. Observers Headset Audio *** Jack	C	-	0	May be inoperative provided an alternate audio source is available.

AIRCRAFT: HAWKER BEECHCRAFT
BE-1900D

REVISION NO: 5
DATE: 02/07/2006

PAGE NO:
23-4

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY			
	2. NUMBER INSTALLED			
	3. NUMBER REQUIRED FOR DISPATCH			
	4. REMARKS AND EXCEPTIONS			
23 COMMUNICATIONS				
12. High Frequency (HF) *** Communication System	D	-	-	Any in excess of those required by FAR may be inoperative.
	C	-	1	(O) May be inoperative while conducting operations that require two LRCS provided: a) SATCOM Voice or Data Link system operates normally, b) Alternate procedures are established and used c) SATCOM coverage is available over the intended route of flight, and d) Prior coordination with the appropriate ATC facility is required when Inmarsat codes for SATCOM Voice are not available. NOTE: SATCOM is to be used only as a backup to normal HF communications unless otherwise authorized by the appropriate ATC facilities.

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY			
	2. NUMBER INSTALLED			
	3. NUMBER REQUIRED FOR DISPATCH			
	4. REMARKS AND EXCEPTIONS			
24 ELECTRICAL POWER				
1. AC VOLT/FREQ. Meter				DELETED Revision 1.
2. L or R DC GEN Annunciator System	B	2	1	One may be inoperative provided: a) Both DC LOAD meters are operative, b) Both Generator Bus Ties are operative, and c) Both L and R GEN TIE OPEN Annunciator Systems are operative.
3. DC LOAD Meters	B	2	1	(O) One may be inoperative provided: a) Electrical load is maintained within the capacity of one generator at all times. b) Both L and R DC GEN Annunciator Systems are operative and c) Aircraft is not operated in known or forecast icing conditions.
4. Inverters	B	2	1	One may be inoperative for day VFR provided: a) No passengers are carried, and b) Both L and R AC Bus Annunciator Systems are operative.
5. L or R AC BUS Annunciator System	B	2	0	May be inoperative provided: a) Both Inverters are operative, and b) AC VOLT/FREQ Meter is operative.

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY			
	2. NUMBER INSTALLED			
	3. NUMBER REQUIRED FOR DISPATCH			
	4. REMARKS AND EXCEPTIONS			
24 ELECTRICAL POWER				
6. External Power System	C	1	0	(M)
7. EXTERNAL POWER Annunciator System	C	1	0	(O)
8. Generator Bus Tie	B	2	1	One may be inoperative for day VMC provided both DC GEN Annunciators are operative.
9. L or R GEN TIE OPEN Annunciator Systems	B	2	0	(O) May be inoperative provided: a) Affected Generator Bus Tie Relay is verified closed prior to each departure, and b) Both DC Gen Annunciators are operative.
10. AC VOLT/FREQ Meter Frequency select button	C	1	0	May be missing or broken provided frequency information can be obtained from the Meter.

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY				4. REMARKS AND EXCEPTIONS
	2. NUMBER INSTALLED			3. NUMBER REQUIRED FOR DISPATCH	
25 EQUIPMENT/ FURNISHING					
1. Passenger Seat(s)	C	-	0		<p>May be inoperative provided:</p> <ul style="list-style-type: none"> a) Seat does not block an Emergency Exit, b) Seat does not restrict any passenger from access to the main aircraft aisle, and c) Affected seat(s) is blocked and placarded "DO NOT OCCUPY". <p>NOTE: A seat with an inoperative seat belt is considered to be inoperative.</p> <p>NOTE: Affected seat(s) may include the seat(s) behind and/or adjacent to the outboard seats.</p>
1) Recline Mechanism	C	-	-		<p>May be inoperative and seat occupied provided seat is secure in the upright position.</p>
2) Underseat Baggage Restraining Bars	C	-	-		<p>(O) May be inoperative provided:</p> <ul style="list-style-type: none"> a) Baggage is not stowed under seat with inoperative restraining bar, b) Associated seat is placarded "DO NOT STOW BAGGAGE UNDER THIS SEAT", and c) Procedures are established to alert crew of inoperative restraining bar.
(Continued)					

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY			
	2. NUMBER INSTALLED			
	3. NUMBER REQUIRED FOR DISPATCH			
	4. REMARKS AND EXCEPTIONS			
25 EQUIPMENT/ FURNISHINGS				
1. Passenger Seat(s) (Continued)				
3) Armrest	C	-	-	May be inoperative or missing and seat occupied provided: a) Armrest does not block an Emergency Exit, b) Armrest does not restrict any passenger from access to the main aircraft aisle, and c) For an armrest with a recline mechanism, seat is secure in the upright position.
4) Forward Observer Seat	C	-	0	May be inoperative provided: a) Another forward passenger seat is made available to the Administrator for the performance of official duties, and b) An audio source is available.
2. Emergency Locator *** Transmitter (ELT) System	C	1	0	(M)As required by FAR.
	C	1	0	(M)May be inoperative for published scheduled flights in scheduled air carrier service.
3. ELT Remote Switch				DELETED Combined with ELT System, Revision 5
4. Passenger Convenience *** Items (Expires December 31, 2007)		-	-	Passenger convenience items, as expressed in this MMEL, are those related to passenger convenience, comfort or entertainment such as, but not limited to, galley equipment, movie equipment, ashtrays, stereo equipment, overhead reading lamps, etc. Items addressed elsewhere in this document shall not be included. (M) and (O) procedures may be required and included in the air carrier's appropriate document.
(Continued)				

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY			
	2. NUMBER INSTALLED			4. REMARKS AND EXCEPTIONS
	3. NUMBER REQUIRED FOR DISPATCH			
25 EQUIPMENT/ FURNISHINGS				
4. Passenger Convenience Items (Continued)				NOTE: Exterior lavatory door ash trays are not considered convenience items
4. Non-Essential Equipment *** & Furnishings (NEF) (Before or after December 31, 2007)		-	-	May be inoperative, damaged or missing provided that the item(s) is deferred in accordance with the operator's NEF deferral program. The NEF program, procedures and processes are outlined in the operators (insert name) Manual. (M) and (O) procedures, if required, must be available to the flight crew and included in the operator's appropriate document. NOTE: Exterior lavatory door ash trays are not considered NEF items.
5. Emergency Medical Equipment	D	-	-	Any in excess of those required by FAR may be incomplete or missing provided required distribution is maintained.
6. Flotation Devices	D	-	-	Any in excess of those required by FAR may be inoperative or missing provided required distribution is maintained.
7. Flashlight/Flashlight *** Assembly	D	-	-	Any in excess of those required by FAR may be inoperative or missing.
8. Cockpit Overhead Crew Assist Straps	D	-	-	May be inoperative or missing.
9. Cockpit Sun Visors	C	2	0	May be inoperative or missing provided there are no visual restrictions to the flight crew.
10. Crew Seat Adjustment	A	-	0	(M) May be inoperative provided: a) Seat(s) are locked in a position that permits normal pilot visibility, b) Full flight control movement is available, c) Position of seat is acceptable to the flight crew, d) Crew Rudder Pedal Adjustment is operative, and e) Repairs are made within one flight day.

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY				4. REMARKS AND EXCEPTIONS
	2. NUMBER INSTALLED			3. NUMBER REQUIRED FOR DISPATCH	
25 EQUIPMENT/ FURNISHINGS					
11. Crew Arm Rests	C	-	0		May be inoperative provided arm rest is secured in the upright position.
12. Flightdeck Doors / Security Barrier	C	-	0		May be inoperative provided door is secured open or does not block nor impede egress to exit.
1) Flightdeck Security *** Barrier Lock System	D	-	0		May be inoperative provided: a) Door opens and closes normally, and b) Door remains in selected position.
13. Externally Mounted Airspeed Indicator Bugs	C	-	0		(O) May be inoperative, missing or broken.
14. Crew Rudder Pedal Adjustment	A	-	0		(M) May be inoperative provided; a) Associated rudder pedal is locked in a position that allows full rudder pedal movement, b) Position of the rudder pedal is acceptable to the flight crew, c) Associated Crew Seat Adjustment must be operative, and d) Repairs are made within one flight day.
15. Crew Compartment Adjustable Air Vent Valves (Wemacs)	C	-	0		
16. Operator Initiated *** Placards.	D	-	-		

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY			
	2. NUMBER INSTALLED			
	3. NUMBER REQUIRED FOR DISPATCH			
	4. REMARKS AND EXCEPTIONS			
25 EQUIPMENT/ FURNISHINGS				
17. Waste Receptacles *** Access Doors/Covers	C	-	-	(O)(M) May be inoperative provided; a) The container is empty and the access is secured to prevent waste introduction into the compartment, and b) Procedures are established to ensure that sufficient waste receptacles are available to accommodate all waste that may be generated on a flight.
18. "Fasten Seat Belt While *** Seated" Sign or Placarded	C	-	-	One or more signs or placards may be illegible or missing provided a legible sign or placarded is visible from each occupied seat.
19. Flightcrew Hat Hooks ***	D	-	0	

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY				4. REMARKS AND EXCEPTIONS	
	2. NUMBER INSTALLED			3. NUMBER REQUIRED FOR DISPATCH		
25 EQUIPMENT/ FURNISHINGS						
20. Cabin and Galley Storage *** Compartments/Closets	C	-	-		(M) May be inoperative provided; a) Procedures are established to secure compartment CLOSED, b) Compartment is not used for storage of Emergency Equipment, and c) Affected compartment is not used for storage of any item(s) except those permanently affixed.	
21. Cargo Restraint Systems ***	C	-	-		(M) May be inoperative, or missing provided acceptable cargo loading limits from an approved source, i.e., an Approved Cargo Loading Manual, Cargo Handling Manual, or Weight and Balance Document are observed.	
	C	-	-		May be inoperative, or missing provided cargo compartment remains empty.	
22. Cargo Door Assist Lanyard	D	-	0		May be inoperative or missing.	

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY			
	2. NUMBER INSTALLED			4. REMARKS AND EXCEPTIONS
	3. NUMBER REQUIRED FOR DISPATCH			
26 FIRE PROTECTION				
1. Portable Fire Extinguisher	D	-	-	Any in excess of those required by FAR may be inoperative or missing provided; a) The inoperative fire extinguisher is tagged inoperative, removed from the installed location and placed out of sight so it can be mistaken for a functional unit, and b) Required distribution is maintained.
2. Fire Extinguisher "Push to Extinguish" Guard	A	2	0	May be broken, missing or lacking safety wire provided: a) Broken guard shall not interfere with the proper indication or activation of the extinguisher, and b) Repairs are made within one flight day.
3. Lavatory Fire *** Extinguisher System	C	-	-	May be inoperative provided Lavatory Smoke Detector system operates normally.
	C	-	-	(M)(O) May be inoperative provided; a) Lavatory waste receptacle is empty, b) Lavatory Door is locked closed and placarded "INOPERATIVE-DO NOT ENTER", and c) Lavatory is used only by crewmembers.
(Continued)				NOTE 1: These provisos are not intended to prohibit lavatory use or inspections by crewmembers.

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY			
	2. NUMBER INSTALLED			
	3. NUMBER REQUIRED FOR DISPATCH			
	4. REMARKS AND EXCEPTIONS			
26 FIRE PROTECTION				
3. Lavatory Fire *** Extinguisher System (Continued)				NOTE 2: A Lavatory Fire Extinguisher system is not required for all-cargo operations.
4. Lavatory Smoke *** Detection System	C	-	-	(O)(M) May be inoperative provided: a) Lavatory Waste Receptacle is empty, b) Lavatory Door is locked closed and placarded, "INOPERATIVE-DO NOT ENTER", and c) Lavatory is used only by crewmembers. NOTE 1: These provisos are not intended to prohibit lavatory use or inspections by crewmembers. NOTE 2: Lavatory Smoke Detection System is not required for all-cargo operations.
5. Cargo Compartment Fire *** Detection System	C	-	0	May be inoperative provided cargo compartment remains empty. NOTE: Does not preclude the carriage or empty cargo containers, pallets, ballast, etc.

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY			
	2. NUMBER INSTALLED			
	3. NUMBER REQUIRED FOR DISPATCH			
	4. REMARKS AND EXCEPTIONS			
27 FLIGHT CONTROLS				
1. Flap Position Indicator				DELETED Combined with Item 27-2, Revision 5.
2. Flap System	B	1	0	(O) May be inoperative provided; a) Flaps are in full up position, and b) Appropriate performance data for no flap takeoff and landings is used. CAUTION: DO NOT SILENCE THE LANDING GEAR WARNING HORN.
1) Flap Position Indicator	B	1	0	May be inoperative provided: a) Flaps are visually checked for full travel and flap operation is not affected, and b) Flaps are checked at each preselected setting prior to each departure.
3. Trim Tab Indicators (Aileron, Rudder)	C	2	0	May be inoperative provided: a) Tab is visually checked for full range of operation, b) Tab operation is not impaired, and c) Tab is positioned to neutral prior to each departure and neutral position is verified by visual inspection.

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY				4. REMARKS AND EXCEPTIONS
	2. NUMBER INSTALLED			3. NUMBER REQUIRED FOR DISPATCH	
27 FLIGHT CONTROL					
4. Electric Elevator Trim *** System					
1) With Autopilot	C	1	0	(O) May be inoperative provided: a) Manual trim is operative and unaffected, and b) Autopilot is not used.	
2) Without Autopilot	C	1	0	(O) May be inoperative provided manual trim is operative and unaffected.	
3) Trim Switches	C	-	0	NOTE: Any operative trim switch may be used.	
4) PITCH TRIM OFF Annunciator System	C	1	0		
5. PITCH TRIM Off Annunciator System					DELETED Combined with Item 27-4

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY			
	2. NUMBER INSTALLED			4. REMARKS AND EXCEPTIONS
	3. NUMBER REQUIRED FOR DISPATCH			
28 FUEL				
1. Engine Driven Low Pressure Fuel Boost Pump	C	2	1	(O)(M) One may be inoperative provided: a) Standby Electric Boost Pump is ON and operative, b) Aviation gasoline is not used, and c) JP4 or Jet B is not used above 8,000 feet MSL.
2. L or R FUEL QTY Annunciator Systems	C	2	1	One may be inoperative provided fuel quantity on board is adequate for the intended flight.
3. FUEL TRANSFER Annunciator System	C	1	0	May be inoperative provide both Fuel Quantity Indicating Systems are operative.
4. Fuel Flow Indicators				DELETED Revision 4. Moved to ATA Section 73.

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY			
	2. NUMBER INSTALLED			
	3. NUMBER REQUIRED FOR DISPATCH			
	4. REMARKS AND EXCEPTIONS			
28 FUEL				
5. Auxiliary Fuel Transfer Pump System				
1) Auxiliary Fuel Transfer Pump	C	2	0	(O) May be inoperative provided: a) Fuel quantity in main tanks is adequate for the intended flight, b) Auxiliary fuel quantity is balanced and is not used for the flight, and c) Fuel Quantity Indicating System on affected side is operative.
2) AUTO mode	C	2	0	May be inoperative provided: a) AUX PUMP ON mode is operative, and b) Fuel Quantity Indicating System on affected side is operative.
6. L or R COL TANK LOW Annunciator System	C	2	1	One may be inoperative provided: a) Fuel quantity on board is adequate for the intended flight, and b) FUEL QTY annunciator on failed side is operative.

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY			
	2. NUMBER INSTALLED			
	3. NUMBER REQUIRED FOR DISPATCH			
	4. REMARKS AND EXCEPTIONS			
28 FUEL				
7. Fuel Quantity Indicating Systems	C	2	1	(O) One may be inoperative provided; a) A reliable means is established to determine that fuel quantity on board meets the regulatory requirements for the intended flight, b) Both Fuel Flow Indicators are operative, c) L and R FUEL QTY annunciators systems are operative, d) Procedures are established to ensure fuel balance remains within AFM limits, and e) FUEL TRANSFER Annunciator System is operative.
1) MAIN Fuel Tank Indications	C	2	1	(O) One may be inoperative provided: a) A reliable means is established to determine that fuel quantity on board meets the regulatory requirements for the intended flight, b) Both Fuel Flow indicators are operative, c) L and R FUEL QTY Annunciator Systems are operative, d) Procedures are established to ensure that fuel balance remains within AFM limitations, and e) FUEL TRANSFER Annunciator System is operative.
(Continued)				

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY			
	2. NUMBER INSTALLED			
	3. NUMBER REQUIRED FOR DISPATCH			
	4. REMARKS AND EXCEPTIONS			
28 FUEL				
7. Fuel Quantity Indicating System (Continued)				
1) Main Fuel Tank Indications	A	2	0	(O) Both may be inoperative provided: a) Both main fuel tanks are visually inspected by a flight crewmember and determined to be fueled to their maximum capacity, b) The required fuel for the flight (to the destination, all required alternates, and required reserves) does not exceed 50% of the rated capacity of the main tanks, c) Repairs are made before the third flight (following discovery), d) The aircraft may not depart any maintenance base authorized to make repairs, e) Both Fuel Flow Indicators are operative, f) Both L and R FUEL QTY Annunciator Systems are operative, g) FUEL TRANSFER Annunciator System is operative, and h) Procedures are established to ensure fuel balance remains within AFM limits.
(Continued)				

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY			
	2. NUMBER INSTALLED			
	3. NUMBER REQUIRED FOR DISPATCH			
	4. REMARKS AND EXCEPTIONS			
28 FUEL				
7. Fuel Quantity Indicating System (Continued)				
2) AUX Fuel Tank Indications	C	2	0	(O) May be inoperative provided: a) A reliable means is established to determine that fuel quantity on board meets the regulatory requirements for the intended flight, b) FUEL TRANSFER Annunciator System is operative, and c) Procedures are established to ensure fuel balance remains within AFM limits.

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY				4. REMARKS AND EXCEPTIONS	
	2. NUMBER INSTALLED			3. NUMBER REQUIRED FOR DISPATCH		
30 ICE AND RAIN PROTECTION						
1. Surface De-Ice System	C	1	0		May be inoperative provided aircraft is not operated in known or forecast icing conditions.	
1) OUTBD WG DEICE Annunciator	C	1	0		May be inoperative provided boot operation is normal and is visually monitored.	
2) INBD WG DEICE Annunciator	C	1	0		May be inoperative for two pilot day operations provided boot operation is normal and visually monitored.	
2. Engine Inertial Ice Vane Actuator Motors	C	4	2		(O) One actuator motor of each intake system may be inoperative provided aircraft is not operated in visible moisture at or below +5 degrees Celsius.	
	C	4	2		(O) One actuator motor of each intake system may be inoperative provided; a) Inertial ice vans are in the extended position, and b) Appropriate ENGINE ANTI-ICE ON performance data is used.	
	C	4	0		(M) Both actuator motors of each intake system may be inoperative on one or both engines provided: a) Inertial ice vanes are secured in the extended position, and b) Appropriate ENGINE ANTI-ICE ON performance data is used.	
3. Alternate Static Air Source Heater	C	1	0		May be inoperative provided aircraft is not operated in known or forecast icing conditions.	

DEPARTMENT OF TRANSPORTATION		MASTER MINIMUM EQUIPMENT LIST			
FEDERAL AVIATION ADMINISTRATION					
AIRCRAFT: HAWKER BEECHCRAFT BE-1900D		REVISION NO: 5 DATE: 02/07/2006		PAGE NO: 30-2	
SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY				
	2. NUMBER INSTALLED				
	3. NUMBER REQUIRED FOR DISPATCH				
	4. REMARKS AND EXCEPTIONS				
30 ICE AND RAIN PROTECTION					
4. Engine Ice Annunciators					
1) L and R ENG ANTI-ICE Annunciators	C	2	1	(O) May be inoperative on one side provided ENG ICE FAIL annunciator is operative on the affected side.	
	C	2	0	(M) May be inoperative on one or both sides provided: a) Affected Inertial Ice Vane(s) is/are secured in the extended position, and b) Appropriated ENGINE ANTI-ICE ON performance data is used.	
2) L and R ENG ICE FAIL Annunciators	C	2	0	(M) May be inoperative on one or both sides provided: a) Affected Inertial Ice Vane(s) is/are secured in the extended position, and b) Appropriate ENGINE ANTI-ICE ON performance data is used.	
5. Stall Warning Vane and Mount Plate Heater System	C	1	0	May be inoperative provided aircraft is not operated in known or forecast icing conditions.	

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY				4. REMARKS AND EXCEPTIONS	
	2. NUMBER INSTALLED			3. NUMBER REQUIRED FOR DISPATCH		
30 ICE AND RAIN PROTECTION						
6. Windshield Wipers	C	2	0		May be inoperative provided aircraft is not operated in precipitation within 5 nautical miles of the airport of takeoff or intended landing.	
	C	2	0		(M) May be inoperative provided the affected windshield has an effective Hydrophobic coating.	
1) PARK Mode	C	1	0		May be inoperative provided wiper arms and blades can be positioned to not obstruct the pilots view.	
2) SLOW mode	C	1	0		May be inoperative provided the FAST mode is operative.	
7. Windshield Heaters	C	2	0		May be inoperative provided aircraft is not operated in known or forecast icing conditions.	
8. Propeller Deicer Ammeter	C	1	0		May be inoperative provided aircraft is not operated in known or forecast icing conditions.	
9. Propeller Deice System	C	1	0		May be inoperative provided aircraft is not operated in known or forecast icing conditions.	
1) Automatic Function	C	1	0		May be inoperative provided the Manual Function is operative.	
2) Manual Function	C	1	0		May be inoperative provided the Automatic Function is operative.	
10. Propeller Deice Systems (Manual)					DELETED Combined with Item 30-9	

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY				4. REMARKS AND EXCEPTIONS
	2. NUMBER INSTALLED			3. NUMBER REQUIRED FOR DISPATCH	
30 ICE AND RAIN PROTECTION					
11. Fuel Vent Heaters	C	2	0		May be inoperative provided aircraft is not operated in known or forecast icing conditions.
12. Brake Deice System ***	C	1	0		(M) May be inoperative provided shutoff valves are in OFF position.
13. Pitot Heater	B	2	1		One may be inoperative provided; a) IFR passenger carrying operations are not conducted and b) Aircraft is not operated in known or forecast icing conditions.
14. STALL HEAT Annunciator	C	1	0		May be inoperative provided aircraft is not operated in known or forecast icing conditions.
15. L and R PITOT HEAT Annunciators					
1) FAR 121 Operations	B	2	0		May be inoperative provided: a) Both pitot heaters are operative, and b) The aircraft is not operated in known or forecast icing conditions.
2) Other operations	C	2	0		May be inoperative provided a) Both pitot heaters are operative, and b) The aircraft is not operated in known or forecast icing conditions.

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY				4. REMARKS AND EXCEPTIONS	
	2. NUMBER INSTALLED			3. NUMBER REQUIRED FOR DISPATCH		
31 INDICATING/ RECORDING SYSTEMS						
1. Clock with presentation of seconds	D	-	0		As required by FAR.	
2. Flight Hour Recorder ***	D	1	0		(O)	
3. Flight Data Recorder *** (FDR)	C	-	-		Any in excess of those required by FAR may be inoperative.	
	A	-	0		May be inoperative provided; <ul style="list-style-type: none"> a) Cockpit Voice Recorder (CVR) operates normally, b) Airplane is not dispatched from a designated airport as listed in the operators MEL unless: <ul style="list-style-type: none"> 1. The FDR failure occurs after pushback but prior to takeoff, or 2. The FDR repair was attempted but was not successful. c) In those cases where repair is attempted but not successful, the aircraft may be dispatched on a flight or series of flights until the next designed airport where repair(s) must be accomplished prior to dispatch, and d) Repairs are made within three flight days. 	
(Continued)						

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY			
	2. NUMBER INSTALLED			
	3. NUMBER REQUIRED FOR DISPATCH			
	4. REMARKS AND EXCEPTIONS			
31 INDICATING/ RECORDING SYSTEMS				
3. Flight Data Recorder (FDR) (Continued)				
1) FDR Recording Parameters required by FAR	A	-	-	May be inoperative provided: a) Cockpit Voice Recorder (CVR) operates normally, and b) Repairs are made within 20 calendar days.
2) FDR Recording Parameters not required by FAR	A	-	-	May be inoperative provided repairs are made prior to the completion of the next heavy maintenance visit.
*** Flight Data Recorder (FDR) (For operator other than a holder of an Air Carrier or Commercial Operator certificate)	C	-	1	Any in excess of those required by FAR may be inoperative.
	A	-	0	May be inoperative provided repairs are made in accordance with applicable FARs.
4. RDR PWR ON Annunciator System				DELETED Revision 2. Combined with Radar Equipment in ATA 34.

DEPARTMENT OF TRANSPORTATION		MASTER MINIMUM EQUIPMENT LIST			
FEDERAL AVIATION ADMINISTRATION					
AIRCRAFT: HAWKER BEECHCRAFT BE-1900D		REVISION NO: 5 DATE: 02/07/2006		PAGE NO: 31-3	
SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY				
	2. NUMBER INSTALLED				4. REMARKS AND EXCEPTIONS
	3. NUMBER REQUIRED FOR DISPATCH				
31 INDICATING/ RECORDING SYSTEMS					
5. Annunciator Power Source Annunciator	C	1	0	(O) May be illuminated provided: a) Preflight procedures are conducted to check operation of individual annunciation circuits in accordance with Beech Minimum Equipment Procedures (P/N 98- 30472 as amended), b) MEL relief is approved and applicable procedures and restrictions observed for all annunciator circuits found to be inoperative, and c) Flight is limited to at or below 10,000 feet MSL or d) Flight above 10,000 feet MSL up to and including 12,000 feet MSL is limited to not more than 30 minutes.	
6. Unassigned (----) Annunciators	D	-	0		
7. Master Caution Annunciator	C	2	1	One may be inoperative provided left side is operative for single pilot operations.	
8. Master Warning Annunciator	A	2	1	One may be inoperative provided: a) Left side is operative for single pilot operations, and b) Repairs are made within one flight day.	
9. EFIS Display Timer	D	2	0		

AIRCRAFT: HAWKER BEECHCRAFT
BE-1900D

REVISION NO: 5
DATE: 02/07/2006

PAGE NO:
31-4

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY			
	2. NUMBER INSTALLED			
	3. NUMBER REQUIRED FOR DISPATCH			
	4. REMARKS AND EXCEPTIONS			
31 INDICATING/ RECORDING SYSTEMS				
10. Aircraft Data Acquisition *** System (Installed per STC SA00095BO)	D	-	0	
11. Electronic Aircraft *** Tracking System	D	1	0	(M)(O)

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY				4. REMARKS AND EXCEPTIONS
	2. NUMBER INSTALLED			3. NUMBER REQUIRED FOR DISPATCH	
32 LANDING GEAR					
1. Power Steering System ***	B	1	0	(O)(M) May be inoperative provided: a) AFM procedures are observed, and b) Landing is limited to 22 knots crosswind and braking action Poor or better,	
1) PWR STEER FAIL *** Annunciator System	B	1	0	(O)May be inoperative provided: a) Power steering remains off, and b) Landing is limited to 22 knots crosswind and braking action Poor or better,	
2) MAN STEER FAIL *** Annunciator System	B	1	0	(O)(M) May be inoperative provided; a) Power steering is disabled, b) Nose gear must be in free caster mode. (See item 1.), and c) Landing is limited to 22 knots crosswind and braking action Poor or better,	
2. PWR STEER FAIL Annunciator System				DELETED Combined as subset of Power Steering System, Revision 5	
3. MAN STEER FAIL Annunciator System				DELETED Combined as subset of Power Steering System, Revision 5	
4. Manual Steering *** Disconnect Actuator	B	1	0	(O)(M) May be inoperative provided Landing is limited to 22 knots crosswind and braking action Poor or better.	
5. HYD FLUID LOW Annunciator System	B	1	0	(O)(M)	
6. Anti-skid System ***	C	1	0	May be inoperative provided: a) The OFF-ON switch remains in the Off position, and b) AFM performance charts for operation without anti-skid are used.	

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY			
	2. NUMBER INSTALLED			
	3. NUMBER REQUIRED FOR DISPATCH			
	4. REMARKS AND EXCEPTIONS			
32 LANDING GEAR				
7. Parking Brake	C	1	0	(O)
8. Landing Gear Handle Solenoid	C	1	0	(O) May be inoperative provided down lock latch is operative.
9. Auxiliary Landing Gear *** Position Indicator System (STC SA00873CH)	D	1	0	May be inoperative provided Landing Gear Position Indicator System is operative.
10. Landing Gear Handle "Intransit" (Red) Lamps	B	2	1	
11. Landing Gear Position Indicator System	C	1	0	May be inoperative provided: a) Auxiliary Landing Gear Position Indicator System STC SA00873CH is installed and operative, and b) All Auxiliary Landing Gear Position Indicators are operative including the "EL" (electroluminescent) panel.
1) Landing Gear Position Indicator Lamps.	A	-	-	One lamp in each indicator may be inoperative provided: a) One lamp in each indicator is operative and provides sufficient illumination for positive down and lock indication, and b) Repairs are made within one flight day.

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY			
	2. NUMBER INSTALLED			4. REMARKS AND EXCEPTIONS
	3. NUMBER REQUIRED FOR DISPATCH			
33 LIGHTS				
1. Cabin Light System (Including Reading Lights)	C	-	-	Individual lights may be inoperative provided lighting configuration is acceptable to the flight crew. Any operative lights may be used.
2. Cockpit/Flight Deck/Flight Compartment and Instruments Lighting System	C	-	-	Individual lights may be inoperative provided remaining lights are: <ul style="list-style-type: none"> a) Sufficient to clearly illuminate all required instruments, controls and other devices for which it is provided, b) Positioned so that direct rays are shielded from flight crewmembers eyes, and c) Lighting configuration and intensity is acceptable to the flight crew.
1) Standby Attitude Indicator Internal Illumination	C	1	0	May be inoperative for day operations.
2) Pressurization Controller Internal Illumination System	D	1	0	May be inoperative for day operations.
	D	1	0	May be inoperative for night operations provided adjacent post light is operative.
3) Emergency Light Switch Position (Red/Green) Indication	B	1	0	(O) Red/Green switch position indication may be inoperative (stuck in either red or green indication) provided switch function is verified operative before each flight at night.
4) Compass Control Unit Internal Illumination (Slaving Meter)	D	2	1	One may be inoperative provided both Gyroscopic Directional Compass Systems operate normally and Comparator Warning is operative.

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY			
	2. NUMBER INSTALLED			
	3. NUMBER REQUIRED FOR DISPATCH			
	4. REMARKS AND EXCEPTIONS			
33 LIGHTS				
3. Landing Lights	C	2	0	May be inoperative for day operations.
	C	2	1	One may be inoperative for night operations provided taxi light is operative.
4. Standby Attitude Indicator Internal Illumination System				DELETED Revision 1. Combined with Cockpit Instrument Lighting System Item 33-2.
5. Navigation Position Lights	C	6	0	May be inoperative for day operations.
	C	6	3	One may be inoperative at each location for night operations.
6. Anti-Collision Beacon Light System	B	1	0	May be inoperative for day operations.
	B	1	0	May be inoperative for night operations provided Anti-Collision Strobe Light System is operative.
7. Anti-Collision Strobe *** Light System	D	1	0	May be inoperative for day operations. Any operative lights may be used.
	D	1	0	May be inoperative for night operations provided Anti-Collision Beacon Light System is operative. Any operative lights may be used.
8. Taxi Light	C	1	0	May be inoperative for day operations.
	C	1	0	May be inoperative for night operations provided both landing lights are operative.

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY				4. REMARKS AND EXCEPTIONS	
	2. NUMBER INSTALLED			3. NUMBER REQUIRED FOR DISPATCH		
33 LIGHTS						
9. TAXI LIGHT Annunciator System	C	1	0			
10. Recognition Lights ***	D	2	0			
11. Tail Flood Lights ***	D	2	0			
12. Wing Ice Lights	C	2	0		May be inoperative except for night operation in known or forecast icing conditions.	
13. Master Caution Lights					DELETED Revision 1. Moved to ATA Section 31.	
14. Cargo Compartment Lighting System	D	1	0		Any operative light may be used.	
15. Boarding Lighting System (including lights within the Airstair and in the entryway foyer)	C	1	0		Any operative light may be used.	

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY			
	2. NUMBER INSTALLED			4. REMARKS AND EXCEPTIONS
	3. NUMBER REQUIRED FOR DISPATCH			
34 NAVIGATION				
1. Vertical Speed Indicators	B	2	1	As required by FAR. NOTE: Left side must be operative for single pilot IFR operations.
2. Weather Radar/ *** Thunderstorm Detection Equipment	C	-	-	As required by FAR.
	D	-	-	Any in excess of those required by FAR may be inoperative.
1) Radar Antenna Gyro Stabilization Function	D	1	0	May be inoperative provided; a) Antenna sweep function is parallel to aircraft pitch axis, and b) Antenna tilt function operates normally.
2) RDR PWR ON *** Annunciator	C	1	0	
3) Windshear Detection and *** Avoidance System (Predictive Windshear)	B	-	0	May be inoperative provided alternate procedures are established and used. NOTE: Operator's alternate procedure should include reviewing windshear avoidance and recovery procedures.
	C	-	0	May be inoperative provided: a) Alternate procedures are established and used, and b) Windshear Warning and Guidance System (reactive) operates normally.

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY			
	2. NUMBER INSTALLED			
	3. NUMBER REQUIRED FOR DISPATCH			
	4. REMARKS AND EXCEPTIONS			
34 NAVIGATION				
3. Gyroscopic Directional Compass	B	2	1	(O) One may be inoperative in slaved mode provided: a) DG mode is operative, and b) Non-Stabilized Magnetic Compass is operative.
4. Non-Stabilized Magnetic Compass	B	1	0	May be inoperative provided any combination of three gyro or INS (IRU) stabilized compass systems are operative.
	B	1	0	May be inoperative provided: a) Any combination of two stabilized gyro or INS stabilized compass systems are operative, and b) Aircraft is operated with dual independent navigation capability and under positive radar control by ATC on the enroute portion of the flight.
	B	1	0	May be inoperative for flights that are entirely within areas of magnetic unreliability provided at least two stabilized directional gyro systems are installed, operative, and used in conjunction with approved free gyro navigation techniques.
5. Navigation Equipment (VOR/ILS, Loran, RNAV, INS, GPS Omega/VLF, Doppler, FMS, MLS, TACAN)	D	-	-	Any in excess of those required by FAR may be inoperative.

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY			
	2. NUMBER INSTALLED			
	3. NUMBER REQUIRED FOR DISPATCH			
	4. REMARKS AND EXCEPTIONS			
34 NAVIGATION				
6. ATC Transponders and Automatic Altitude Reporting Systems	B	-	0	May be inoperative provided: a) Enroute operations do not require its use, and b) Prior to flight, approval is obtained from ATC facilities having jurisdiction over the planned route of flight.
	D	-	1	Any in excess of those required by FAR may be inoperative.
1) Elementary and Enhanced Downlink Aircraft Reportable Parameters not required by FAR	A	-	0	May be inoperative provided: a) Enroute operations do not require its use, and b) Repairs are made prior to completion of the next heavy maintenance visit.
7. Marker Beacon	D	-	-	Any in excess of those required by FAR may be inoperative.
8. Altitude Encoder				DELETED Combined with Item 34-6.
9. Distance Measuring Equipment (DME) Systems	D	-	-	Any in excess of those required by FAR may be inoperative.
10. Automatic Direction Finding Equipment (ADF)	D	-	-	Any in excess of those required by FAR may be inoperative.

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY			
	2. NUMBER INSTALLED			
	3. NUMBER REQUIRED FOR DISPATCH			
	4. REMARKS AND EXCEPTIONS			
34 NAVIGATION				
11. Radar Altimeter				
1) Necessary for GPWS operation when GPWS is required by FAR.	A	-	0	May be inoperative provided: a) GPWS is considered inoperative, b) Alternate procedures are established and used, c) Repairs are made within two flight days, and d) Landing minimums are not based on its use.
2) Necessary for GPWS operation when GPWS is not required by FAR	C	-	0	May be inoperative provided landing minimums are not based on its use.
3) Not necessary for GPWS	D	-	0	Any in excess of those required by FAR may be inoperative.
12. Flight Director System	C	-	0	May be inoperative provided landing minimums are not based on its use. NOTE: Any operative mode may be used.
1) Go Around Function	C	-	0	(O)
13. Altitude Alerting System ***	A	-	0	(O) May be inoperative provided: a) Autopilot with altitude hold is operative, b) Enroute operations do not require its use, and c) Repairs are made within three flight days.
	C	-	0	May be inoperative provided it is not required by FAR.

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY				4. REMARKS AND EXCEPTIONS	
	2. NUMBER INSTALLED			3. NUMBER REQUIRED FOR DISPATCH		
34 NAVIGATION						
14. RMI	C	-	0			
15. Traffic Alert and Collision *** Avoidance System (TCAS I)	B	-	0		(M)(O) May be inoperative provided: a) System is deactivated and secured, and b) Enroute or approach procedures do not require its use.	
	C	-	0		(M)(O) May be inoperative provided: a) Not required by FAR, b) System is deactivated and secured, and c) Enroute or approach procedures do not require its use.	
16. Traffic Alert and Collision Avoidance System (TCAS II)	B	-	0		(M) May be inoperative provided: a) System is deactivated and secured, and b) Enroute or approach procedures do not require its use.	
	C	-	0		(M)(O) May be inoperative provided: a) Not required by FAR, b) System is deactivated and secured, and c) Enroute or approach procedures not require its use.	
1) Combined Traffic Alert (TA) and Resolution Advisory (RA) Dual Display System(s)	C	2	1		May be inoperative on the nonflying pilot side provided; a) TA and RA visual display is operative on the flying pilot side, and b) TA and RA audio function is operative on the flying pilot side.	
(Continued)						

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY				4. REMARKS AND EXCEPTIONS
	2. NUMBER INSTALLED			3. NUMBER REQUIRED FOR DISPATCH	
34 NAVIGATION					
16. TCAS II (Continued)					
2) Resolution Advisory (RA) Display System(s)	C	2	1		May be inoperative on non-flying pilot side.
	C	-	0		(O) May be inoperative provided: a) Traffic Alert (TA) visual display and audio functions are operative, b) TA only mode is selected by the crew, and c) Enroute or approach procedures do not require its use.
3) Traffic Alert Display System(s)	C	-	0		(O) May be inoperative provided: a) RA visual display and audio functions are operative, and b) Enroute or approach procedures do not require its use.
17. Standby Attitude Indicator	C	-	0		May be inoperative provided not required by FAR.
	B	-	0		May be inoperative provided: a) Operations are conducted in Day VMC only, and b) Operations are not conducted into known or forecast VFR-on-Top conditions.
1) Sonalert Standby Power Aural Warning	B	1	0		May be inoperative provided the Standby Power Annunciator is operative.
2) Standby Power Annunciator	B	1	0		May be inoperative provided the Sonalert Standby Power Aural Warning is operative.
18. Flight Profile Advisory *** System	C	1	0		

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY			
	2. NUMBER INSTALLED			
	3. NUMBER REQUIRED FOR DISPATCH			
	4. REMARKS AND EXCEPTIONS			

34 NAVIGATION				
19. Terrain Awareness and *** Warning System(TAWS)				
A Class A TAWS Equipment Required				
1) GPWS	A	-	0	(O) May be inoperative provided: a) Alternate Procedures are established and used, and b) Repairs are made within two flight days.
a) Modes 1-4	A	4	0	(O) May be inoperative provided: a) Alternate procedures are established and used, and b) Repairs are made within two flight days.
b) Test mode	A	1	0	May be inoperative provided: a) The GPWS is considered inoperative, and b) Repairs are made within two flight days.
c) Glideslope Deviation (Mode 5)	C	-	1	
	B	-	0	
d) Advisory Callouts	B	-	0	(O) May be inoperative provided alternate procedures are established and used.
	C	-	0	(O) May be inoperative provided: a) Advisory callout not required by FAR, and b) Alternate Procedures are established and used.
(Continued)				

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY				4. REMARKS AND EXCEPTIONS	
	2. NUMBER INSTALLED			3. NUMBER REQUIRED FOR DISPATCH		
34 NAVIGATION						
19. Class A TAWS						
A Equipment Required						
1) GPWS (Continued)						
e) Windshear Mode	B	1	0		(O) May be inoperative provided alternate procedures are established and used.	
*** (Reactive)					NOTE: Operator's alternate procedure should include reviewing windshear avoidance and recovery procedures.	
	C	1	0		(O) May be inoperative provided: a) Alternate procedures are established and used, and b) Windshear Detection and Avoidance System (Predictive) operates normally.	
2) Terrain System – Forward Looking Terrain Avoidance (FLTA) and Premature Descent Alert (PDA) Functions	B	1	0		(O) May be inoperative provided alternate procedures are established and used.	
3) Terrain Displays	C	-	1			
	B	-	0			
4) Runway Awareness & *** Advisory System (RAAS)	C	1	0			

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY			
	2. NUMBER INSTALLED			
	3. NUMBER REQUIRED FOR DISPATCH			
	4. REMARKS AND EXCEPTIONS			
34 NAVIGATION 19. Class B TAWS B Equipment Required 1) GPWS	A	-	0	(O) May be inoperative provided: c) Alternate Procedures are established and used, and d) Repairs are made within two flight days.
a) Modes 1 & 3	A	2	0	(O) May be inoperative provided: c) Alternate procedures are established and used, and d) Repairs are made within two flight days.
b) Test mode	A	1	0	May be inoperative provided: c) The GPWS is considered inoperative, and d) Repairs are made within two flight days.
c) Modes 2, 4 & 5 ***	C	3	0	
d) Advisory Callouts	B	-	0	(O) May be inoperative provided alternate procedures are established and used.
	C	-	0	(O) May be inoperative provided: c) Advisory callout not required by FAR, and d) Alternate Procedures are established and used.
(Continued)				

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY			
	2. NUMBER INSTALLED			
	3. NUMBER REQUIRED FOR DISPATCH			
	4. REMARKS AND EXCEPTIONS			
34 NAVIGATION				
19. Class B TAWS				
B Equipment Required				
1) GPWS (Continued)				
e) Windshear Mode	C	1	0	(O) May be inoperative provided alternate procedures are established and used.
*** (Reactive)				
				NOTE: Operator's alternate procedure should include reviewing windshear avoidance and recovery procedures.
2) Terrain System – Forward Looking Terrain Avoidance (FLTA) and Premature Descent Alert (PDA) Functions	B	1	0	(O) May be inoperative provided alternate procedures are established and used.
3) Terrain Displays	C	-	0	
4) Runway Awareness & Advisory System (RAAS)	C	1	0	

19. TAWS / GPWS not C required by FAR. (Class C TAWS)	C	1	0	(O) May be inoperative provided alternate procedures are established and used.
				NOTE: Any mode that operates normally may be used.

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY			
	2. NUMBER INSTALLED			
	3. NUMBER REQUIRED FOR DISPATCH			
	4. REMARKS AND EXCEPTIONS			
34 NAVIGATION				
20. Weather Storm Scope				Deleted Rev. 4.
21. Multifunction Display ***	C	-	0	(O) May be inoperative provided alternate procedures are established and used.
22. Windshear Warning and *** Flight Guidance System				DELETED Combined with TAWS / GPWS Revision 5
23. Windshear Detection and *** Avoidance System				DELETED Combined with Weather Radar, Revision 5
24. Navigation Databases ***				
1) Flight Management System	C	-	-	(O) May be out of currency provided: a) Current Aeronautical Charts are used to verify navigation fixes prior to dispatch, b) Procedures are established and used to verify status and suitability of Navigation Facilities used to define route of flight, and c) Approach Navigation Radios are manually tuned and identified.
2) Navigation Management System	C	-	-	(O) May be out of currency provided: a) Current Aeronautical Charts are used to verify navigation fixes prior to dispatch, b) Procedures are established and used to verify status and suitability of Navigation Facilities used to define route of flight, and c) Approach Navigation Radios are manually tuned and identified.

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY				4. REMARKS AND EXCEPTIONS	
	2. NUMBER INSTALLED			3. NUMBER REQUIRED FOR DISPATCH		
34 NAVIGATION						
25. Automatic Dependent *** Surveillance-Broadcast (ADS-B)	D	-	0		May be inoperative provided it is not required by FAR. NOTE: If ADS-B is installed in lieu of or as a replacement for FAR required equipment, the repair category in the operator's MEL will be the same as that of the FAR required equipment.	
1) Link and Display Processor Unit (LDPU)	D	-	0		NOTE: Cockpit Display Traffic Information (CDTI) display of data from other aircraft systems may be used.	
2) Cockpit Display and Traffic Information (CDTI)	D	-	0		NOTE: ADS-B data transmissions may continue.	
3) CDTI Control Panel	D	-	0		May be inoperative provided: a) Flight ID can be set, and b) Screen Display is acceptable to the flight crew.	
4) Data Link Transmitter(s)	D	-	0			
5) Data Link Receiver(s)	D	-	0			

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY			
	2. NUMBER INSTALLED			
	3. NUMBER REQUIRED FOR DISPATCH			
	4. REMARKS AND EXCEPTIONS			
35 OXYGEN				
1. Passenger Oxygen System	C	1	0	As required by FAR. NOTE: Cockpit Crew Oxygen System must be operative.
2. External Oxygen Gauge	C	1	0	(M) May be inoperative provided the Internal Oxygen Gauge is monitored during servicing to avoid over-servicing.
3. Passenger Oxygen Mask	C	-	0	(M) May be inoperative provided: a) Corresponding passenger seat is blocked and placarded "DO NOT OCCUPY", and b) Affected mask does not permit flow when cabin oxygen system is activated.
4. Protective Breathing Equipment (PBE)	D	-	-	Any in excess of those required by FAR may be inoperative.

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY			
	2. NUMBER INSTALLED			
	3. NUMBER REQUIRED FOR DISPATCH			
	4. REMARKS AND EXCEPTIONS			
37 VACUUM/PRESSURE				
1. Gyro Suction Indicator	C	1	0	(O) May be inoperative provided; a) Both Instrument Air Valves are operative, b) Both L and R Bleed AIR FAIL Annunciator Systems are operative, c) Both Outflow/Safety Valves are operative, d) The Cabin Pressure System is operative, and e) Both Environmental Bleed Air Systems are operative.
2. Instrument Air Valve	C	2	1	(O) One may be inoperative provided: a) Inoperative valve is verified closed, and b) Aircraft is not operated in known or forecast icing conditions.

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY			
	2. NUMBER INSTALLED			
	3. NUMBER REQUIRED FOR DISPATCH			
	4. REMARKS AND EXCEPTIONS			
37 VACUUM/PRESSURE				
3. Pneumatic Pressure Gauge	C	1	0	(O) May be inoperative provided: a) Aircraft is not operated in known or forecast icing conditions, b) Both Instrument Air Valves are operative, c) Both L and R Bleed AIR FAIL Annunciator Systems are operative, d) Both Outflow/Safety Valves are operative, e) The Pressurization System is operative, and f) Both Environmental Bleed Air Systems are operative.
	C	1	0	(O) May be inoperative provided; a) The TAIL DEICE Annunciator is operative, b) The INBD WG DEICE and OUTBD WG DEICE Annunciators are operative, c) Both Instrument Air Valves are operative, d) Both L and R Bleed Air FAIL Annunciator Systems are operative, e) Both Outflow/Safety Valves are operative, f) The Pressurization System is operative, and g) Both Environmental Bleed Air Systems are operative.

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY			
	2. NUMBER INSTALLED			
	3. NUMBER REQUIRED FOR DISPATCH			
	4. REMARKS AND EXCEPTIONS			
38 WATER/WASTE				
1. Potable Water Systems ***	C	-	-	(M) Individual components may be inoperative provided: a) Associated components are deactivated or isolated, and b) Associated system components are verified not to have leaks. NOTE: Any portion of the system which operates normally may be used.
	C	-	-	(M) May be inoperative provided: a) System is drained, and b) Procedures are established to ensure that system is not serviced.
2. Lavatory Waste System ***	C	-	-	(M) Individual components may be inoperative provided: a) Associated components are deactivated or isolated, and b) Associated system components are verified not to have leaks. NOTE: Any portion of the system which operates normally may be used.
	C	-	-	(M) Associated Lavatory system(s) may be inoperative provided: a) Associated components are deactivated or isolated to prevent leaks. b) Lavatory door is secured closed and placarded: "INOPERATIVE-DO NOT USE".

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY				4. REMARKS AND EXCEPTIONS
	2. NUMBER INSTALLED			3. NUMBER REQUIRED FOR DISPATCH	
52 DOORS					
1. CABIN DOOR Annunciator System	C	1	0		May be inoperative provided a crewmember confirms, by visual inspection, that the door is latched prior to each departure.
2. CARGO DOOR Annunciator System	C	1	0		May be inoperative provided a crewmember confirms, by visual inspection, that the door is latched prior to each departure.
3. Cabin Door Lock Observe Light System	C	1	0		May be inoperative provided a flashlight is used by a crewmember to inspect the locking mechanism prior to each departure.
4. Entrance Door Snubber System	C	1	0		(O)
5. Airstair Door Cable Coverings	D	-	0		May be damaged or missing provided door cable does not interfere with door operation.
6. Cargo Door Snubber	A	4	3		(M) May be inoperative provided repairs are made within two flight days.
7. Cabin / Cargo Door Seals	C	2	0		May be damaged or inoperative provided: a) Door seal does not interfere with door operation, and b) The flight is conducted at or below 10,000 feet MSL.

DEPARTMENT OF TRANSPORTATION		MASTER MINIMUM EQUIPMENT LIST		
FEDERAL AVIATION ADMINISTRATION				
AIRCRAFT: HAWKER BEECHCRAFT BE-1900D		REVISION NO: 5 DATE: 02/07/2006		PAGE NO: 56-1
SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY			
	2. NUMBER INSTALLED			
	3. NUMBER REQUIRED FOR DISPATCH			
	4. REMARKS AND EXCEPTIONS			
56 WINDOWS				
1. Cockpit Windshields	A	2	1	(O) Relief is permitted only to the extent allowed for in the latest revision of the FAA Approved Flight Manual.
2. Side Windows (Cockpit or Cabin)	A	-	-	(O) Relief is permitted only to the extent allowed for in the latest revision of the FAA Approved Flight Manual. PRESSURIZED flight is PROHIBITED due to a cracked side window.

DEPARTMENT OF TRANSPORTATION		MASTER MINIMUM EQUIPMENT LIST			
FEDERAL AVIATION ADMINISTRATION					
AIRCRAFT: HAWKER BEECHCRAFT BE-1900D		REVISION NO: 5 DATE: 02/07/2006		PAGE NO: 61-1	
SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY				
	2. NUMBER INSTALLED				4. REMARKS AND EXCEPTIONS
	3. NUMBER REQUIRED FOR DISPATCH				
61 PROPELLERS					
1. Propeller Synchrophaser/ Synchronizer System	D	1	0		
2. Propeller Synchroscope	D	1	0		
3. Propeller Auto Feather Indication System					
1) AFX Indicators	C	2	0		May be inoperative provided L and R Auto Feather Annunciators are operative and illuminated prior to takeoff brake release.
2) L or R AUTO FEATHER Annunciators	C	2	0		May be inoperative provided AFX Indicators are operative.
3) AUTO FEATHER OFF Annunciator	A	1	0		May be inoperative provided: a) Auto Feather switches remain in the ARM position for the entire flight, and b) Repairs are made within three flight days.

SYSTEM SEQUENCE & NUMBERS	1. REPAIR CATEGORY			
	2. NUMBER INSTALLED			
	3. NUMBER REQUIRED FOR DISPATCH			
	4. REMARKS AND EXCEPTIONS			
73 ENGINE FUEL & CONTROL				
1. Fuel Flow Indicators	B	2	1	(O) One may be inoperative provided both Fuel Quantity Indication Systems and both Main Fuel Tank Indications are operative.
	B	2	1	(O) One may be inoperative with one or both Aux Fuel Tank Indications inoperative provided both Fuel Quantity Indicating Systems and both Main Fuel Tank Indications are operative.

DEPARTMENT OF TRANSPORTATION

MASTER MINIMUM EQUIPMENT LIST

FEDERAL AVIATION ADMINISTRATION

AIRCRAFT: HAWKER BEECHCRAFT
BE-1900D

REVISION NO: 5
DATE: 02/07/2006

PAGE NO:
74-1

SYSTEM
SEQUENCE &
NUMBERS

1. REPAIR CATEGORY

2. NUMBER INSTALLED

3. NUMBER REQUIRED FOR DISPATCH

4. REMARKS AND EXCEPTIONS

74 IGNITION

1. L or R Auto Ignition
System

DELETED Revision 4.

DEPARTMENT OF TRANSPORTATION		MASTER MINIMUM EQUIPMENT LIST			
FEDERAL AVIATION ADMINISTRATION					
AIRCRAFT: HAWKER BEECHCRAFT BE-1900D		REVISION NO: 5 DATE: 02/07/2006		PAGE NO: 77-1	
SYSTEM SEQUENCE & NUMBERS		1. REPAIR CATEGORY			
		2. NUMBER INSTALLED			
		3. NUMBER REQUIRED FOR DISPATCH			
		4. REMARKS AND EXCEPTIONS			
77	ENGINE INDICATING				
1.	Tachometers N1 Indicator	C	2	0	Digital display portion may be inoperative.
		D	2	0	The Decimal Point only of the digital display may be inoperative.